

DES-3010FA/GA
Release I

Layer 2 Switch

Managed 8-Port 10/100Base-TX with Gigabit & Fiber Uplinks

Web User Guide

Business Class Networking

Table of Contents

D-Link DES-3010FA/GA User Guide Overview	7
Using the Installation Guide	7
Using the Embedded Web Interface User Guide	7
Intended Audience	8
D-Link DES 3010FA/GA Installation Guide	9
Device Description	10
Viewing the Device	11
DES-3010FA Front Panel	11
DES-3010GA Front Panel	11
Ports Description	13
10/100Base-TX Fast Ethernet Ports	13
1000Base-T Gigabit Ethernet Ports	13
100Base-FX Fiber Ports	13
SFP Port	13
DB-9 Console Port	14
Cable Specifications	15
LED Definitions	16
Port LEDs	16
Power LED	19
Console LED	19
Cable, Port, and Pinout Information	20
Pin Connections for the 10/100/1000 Ethernet Interface	20
Physical Dimensions	21
Mounting Device	22
Preparing for Installation	23
Installation Precautions	23
Site Requirements	23
Unpacking	24
Installing the Device	25
Desktop or Shelf Installation	25
Rack Installation	25
Wall Installation	28
Connecting the Device	29
Connecting the Switch to a Terminal	29
AC Power Connection	30
Starting and Configuring the Device	31
Configuring the Terminal	32
Installation Procedure	32
Device Port Default Settings	32

Booting the Device	33
Configuration Overview	34
Initial Configuration	34
Advanced Configuration	39
Receiving an IP Address from a DHCP Server	39
Receiving an IP Address from a BOOTP Server	39
Security Management and Password Configuration	40
Startup Procedures	43
Startup Menu Procedures	43
Software Download and Reboot	44
D-Link DES 3010FA/GA EWS User Guide	48
Getting Started	49
Starting the D-Link Embedded Web Interface	50
Understanding the D-Link Embedded Web Interface	51
Device Representation	53
Using the D-Link Embedded Web Interface Management Buttons	53
Using Screen and Table Options	54
Adding Configuration Information	54
Modifying Configuration Information	54
Deleting Configuration Information	55
Resetting the Device	56
Logging off from the Device	58
Managing Device Information	59
Configuring Device Security	61
Configuring Management Security	62
Configuring Authentication Methods	62
Configuring Passwords	79
Configuring Network Security	83
Network Security Overview	83
Defining Network Authentication Properties	84
Defining Port Authentication	86
Configuring Traffic Control	92
Configuring Ports	97
Viewing Port Properties	100
Aggregating Ports	102
Aggregating Ports	103
Configuring LACP	105
Configuring VLANs	107
Defining VLAN Properties	108
Defining VLAN Membership	110
Defining VLAN Interface Settings	111

Defining Private VLANs	113
Configuring GARP	116
Defining GARP	116
Defining GVRP	118
Configuring IP Information	120
Configuring IP Interfaces	120
Defining IP Addresses	121
Defining Default Gateways	124
Configuring DHCP	125
Configuring ARP	127
Configuring Domain Name Servers	129
Defining DNS Servers.....	130
Defining DNS Host Mapping.....	132
Defining the Forwarding Database	134
Defining Static Forwarding Database Entries	135
Defining Dynamic Forwarding Database Entries	137
Configuring Spanning Tree	139
Defining Classic Spanning Tree	140
Defining STP on Interfaces.....	142
Defining Rapid Spanning Tree	145
Defining Multiple Spanning Tree	148
Defining MSTP Instance Settings	148
Defining MSTP Interface Settings.....	151
Configuring Multicast Forwarding	154
Defining IGMP Snooping	155
Defining Multicast Bridging Groups	157
Defining Multicast Forward All Settings	159
Configuring SNMP	161
SNMP v1 and v2c.....	161
SNMP v3	161
Configuring SNMP Security	162
Defining SNMP Security	162
Defining SNMP Views.....	164
Defining SNMP Group Profiles	166
Defining SNMP Group Members	169
Defining SNMP Communities	172
Configuring SNMP Notifications	175
Defining SNMP Notification Global Parameters	176
Defining SNMP Notification Filters.....	177
Defining SNMP Notification Recipients.....	179

Configuring Quality of Service	183
VPT Classification Information	183
CoS Services	184
Configuring Quality of Service General Settings	185
Defining QoS Settings	185
Defining Bandwidth Settings	187
Modifying QoS Interface Settings	188
Defining Queue Settings	190
Mapping QoS Queues	191
Mapping CoS Values to Queues	191
Mapping DSCP Values to Queues	192
Managing System Files	193
File Management Overview	194
Downloading System Files	195
Firmware Download	195
Configuration Download	196
Uploading System Files	197
Upload Type	197
Software Image Upload	198
Configuration Upload	198
Copying Files	199
Restoring the Default Configuration File	199
Managing System Logs	200
Enabling System Logs	201
Viewing the Device Memory Logs	203
Clearing Device Memory Logs	203
Viewing the FLASH Logs	204
Clearing FLASH Logs	204
Defining Servers Log Parameters	205
Managing Device Diagnostics	206
Configuring Port Mirroring	207
Viewing Integrated Cable Tests	209
Viewing Optical Transceivers	210
Viewing the CPU Utilization	211
Configuring System Time	212
Configuring Daylight Savings Time	213
Configuring SNTP	217
Polling for Unicast Time Information	217
Polling for Anycast Time Information	217
Broadcast Time Information	217
Defining SNTP Global Settings	219

Defining SNTP Authentication	221
Defining SNTP Servers	223
Defining SNTP Interface Settings	225
Viewing Statistics	227
Viewing Interface Statistics	227
Viewing Device Interface Statistics	228
Resetting Interface Statistics Counters	229
Viewing Etherlike Statistics	229
Resetting Etherlike Statistics Counters	230
Viewing GVRP Statistics	231
Resetting GVRP Statistics Counters	232
Viewing EAP Statistics	232
Managing RMON Statistics	233
Viewing RMON Statistics	234
Resetting RMON Statistics Counters	235
Configuring RMON History	236
Defining RMON Alarms	243
Problem Management	246
Troubleshooting Solutions	246
Contacting D-Link Technical Support	249
Warranty	276
Product Registration	279
International Offices	280

Preface

The *Embedded Web System* (EWS) is a network management system. The D-Link Embedded Web Interface configures, monitors, and troubleshoots network devices from a remote web browser. The D-Link Embedded Web Interface web pages are easy-to-use and easy-to-navigate. In addition, The D-Link Embedded Web Interface provides real time graphs and RMON statistics to help system administrators monitor network performance.

This preface provides an overview to the D-Link Embedded Interface User Guide, and includes the following sections:

- D-Link DES-3010FA/GA User Guide Overview
- Intended Audience

D-Link DES-3010FA/GA User Guide Overview

This user guide is divided into the following sections to provide concise information for installing, configuring, and managing the device:

- Using the Installation Guide
- Using the Embedded Web Interface User Guide

Using the Installation Guide

This section provides an overview of the D-Link 3010FA/GA Installation Guide, which includes the following sections:

- **Section 1. Device Description** — Provides a system description including the hardware components.
- **Section 2. Mounting Device** — Provides step-by-step instructions for installing the device.
- **Section 3. Starting and Configuring the Device** — Provides step-by-step instructions for the initial device configuration.

Using the Embedded Web Interface User Guide

This section provides an overview to the D-Link Web System Interface User Guide. The D-Link Web System Interface User Guide provides the following sections:

- **Section 4. Getting Started** — Provides information about using the EWS, including The D-Link Embedded Web Interface interface, management, and information buttons, as well as information about adding, modifying, and deleting device information.
- **Section 5. Managing Device Information** — Provides information about opening the device zoom view and defining general system information.
- **Section 6. Configuring Device Security** — Provides information about configuring device security for management security, traffic control, and network security.
- **Section 7. Configuring Ports** — Provides information about configuring ports.
- **Section 8. Aggregating Ports** — Provides information about configuring Link Aggregated Groups and LACP.
- **Section 9. Configuring VLANs** — Provides information about configuring and managing VLANs, including information about GARP and GVRP.
- **Section 10. Configuring IP Information** — Provides information about defining device IP addresses, ARP, and Domain Name Servers.
- **Section 11. Defining the Forwarding Database** — Provides information about configuring and managing both static and dynamic MAC addresses.
- **Section 12. Configuring Spanning Tree** — Provides information about configuring Spanning Tree Protocol and the Rapid Spanning Tree Protocol.
- **Section 13. Configuring Multicast Forwarding** — Provides information about Multicast Forwarding.
- **Section 14. Configuring SNMP** — Provides information about defining SNMP v1,v2c, and v3 management, including SNMP filters and notifications.
- **Section 15. Configuring Quality of Service** — Provides information about configuring Quality of Service on the device.
- **Section 16. Managing System Files** — Provides information about downloading, uploading, and copying system files.
- **Section 17. Managing System Logs** — Provides information about enabling and defining system logs.
- **Section 18. Managing Device Diagnostics** — Provides information about configuring port mirroring, testing copper and fiber cables, and viewing device health information.

- **Section 19. Configuring System Time** — Provides information about configuring system time, including Daylight Savings Time parameters and Simple Network Time Protocol (SNTP) parameters.
- **Section 20. Viewing Statistics** — Provides information about viewing device statistics, including RMON statistics, device history events, and port and LAG utilization statistics.
- **Appendix A, Troubleshooting** — Provides basic troubleshooting for installing the device.

Intended Audience

This guide is intended for network administrators familiar with IT concepts and terminology.

D-Link DES 3010FA/GA Installation Guide

Section 1. Device Description

This section contains a description of the D-Link DES-3010FA and D-Link DES-3010GA, and contains the following topics:

- Viewing the Device
- Ports Description
- Cable Specifications
- LED Definitions
- Cable, Port, and Pinout Information
- Physical Dimensions

Viewing the Device


The D-Link DES-3010FA and D-Link DES-3010GA are 10 port Fast Ethernet Managed Switches. The two devices contain 8 network ports on the front panel for network connectivity. Device management is performed using an Embedded Web Server (EWS) or through a Command Line Interface (CLI). The device configuration is performed via a DB-9 RS-232 interface. This section contains descriptions for:

- DES-3010FA Front Panel
- DES-3010GA Front Panel

DES-3010FA Front Panel

The following figure illustrates the DES-3010FA front panel.

Figure 1: DES-3010FA Front Panel



The device front panel is configured as follows:


- **8 Fast Ethernet ports** — RJ-45 ports designated as 10/100Base-TX. The RJ-45 ports are designated as ports Ports1-8.
- **DB-9 Console port** — An asynchronous serial console port supporting the RS-232 electrical specification. The port is used to connect the device to the console managing the device.
- **1000Base-T Copper port** — Copper RJ-45 Gigabit port designated on the device as port 9.
- **100Base-FX port** — Fiber port designated on the device as port 10.

On the front panel there are the Port activity LEDs on each port and the Power LED displayed separately.

DES-3010GA Front Panel

The following figure illustrates the DES-3010GA front panel.

Figure 2: DES-3010GA Front Panel



The device front panel is configured as follows:

- **8 Fast Ethernet ports** — RJ-45 ports designated as 10/100Base-TX. The RJ-45 ports are designated as ports Ports 1-8.
- **DB-9 Console port** — An asynchronous serial console port supporting the RS-232 electrical specification. The port is used to connect the device to the console managing the device.
- **1000Base-T port** — RJ-45 Gigabit port designated on the device as port 9.
- **SFP Port** — There is one SFP port, which contains 1000Base-X (fiber) connections.

On the front panel there are the Port activity LEDs on each port and the Power LED displayed separately.

DES-3010 Back Panel

The following figure illustrates the DES-3010 back panel.

Figure 3: DES-3010 Back Panel



The DES-3010 device back panel contains a AC power supply interface.

Ports Description

This section describes the device ports and includes the following topics:

- 10/100Base-TX Fast Ethernet Ports
- 1000Base-T Gigabit Ethernet Ports
- 100Base-FX Fiber port
- SFP Port
- DB-9 Console Port

10/100Base-TX Fast Ethernet Ports

The 10/100Base-TX Fast Ethernet ports are RJ-45.

1000Base-T Gigabit Ethernet Ports

The device contains a 1000 Base-TX Gigabit port. The port is an RJ-45 port which supports half- and full-duplex mode 10/100/1000 Mbps.

100Base-FX Fiber Ports


The 100Base-FX Fast Ethernet port in the DES-3010FA device is a Fiber ports.

SFP Port

Small Form Factor Pluggable (SFP) Optical Transceivers are integrated duplex data GBIC links for bi-directional communication over multimode optical fiber, designed for high-speed Fiber Channel data links. The SFP port is designated as 1000Base-X.

The SFP (GBIC) port can be removed and inserted as required. The following figure illustrates the GBIC insertion.

Figure 4: Inserting a GBIC into the Device



DB-9 Console Port

The DB-9 port is an asynchronous serial console port supporting the RS-232 electrical specification. The port is used to connect the device to a console managing the device. This interface configuration is as follows:

- Eight data bits.
- One stop bit.
- No parity.
- Baud rate is 9600 (default). The user can change the rate from 115200 down to 9600 bps.
- Console speeds of 57600 and 115200.

Cable Specifications

The following table contains the various cable specification for the DES-3010FA/GA:

Table 1: DES-3010FA/GA Cable Specifications

Cable Type	Description
10Base-TX	UTP Category 3, 4, 5 (100 meters max.) EIA/TIA- 568 150-ohm STP (100 meters max.)
100Base-TX	UTP Cat. 5 (100 meters max.) EIA/TIA-568 150-ohm STP (100 meters max.)
1000Base-T	UTP Cat. 5e (100 meters max.) UTP Cat. 5 (100 meters max.) EIA/TIA-568B 150-ohm STP (100 meters max.)
1000BASE-LX	Single-mode fiber module (10km)
1000BASE-SX	Multi-mode fiber module (550m)
1000BASE-LH	Single-mode fiber module (40km)
1000BASE-ZX	Single-mode fiber module (80km)
Mini-GBIC	SFP Transceiver for 1000BASE-LX Single-mode fiber module (10km) SFP Transceiver for 1000BASE-SX Multi-mode fiber module (550m) SFP Transceiver for 1000BASE-LH Single-mode fiber module (40km) SFP Transceiver for 1000BASE-ZX Single-mode fiber module (80km)

:

Table 2: DES-3010FA/GA Cable Lengths

Cable Type	Description
	DEM-310GT: SFP Transceiver for 1000BASE-LX, Single-mode fiber module 10km DEM-311GT: SFP Transceiver for 1000BASE-SX, Multi-mode fiber module 550m DEM-312GT2: SFP Transceiver for 1000BASE-SX+, Multi-mode module 2km DEM-314GT: SFP Transceiver for 1000BASE-LH, Single-mode fiber module 50km DEM-315GT: SFP Transceiver for 1000BASE-ZX, Single-mode fiber module 80km
1000Base-T	Category 5e UTP CableCategory 5 UTP Cable(1000 Mbps) 100m
100Base-TX	Category 5 UTP Cable (100 Mbps) 100m
10Base-TX	Category 3 UTP Cable (10 Mbps) 100m

LED Defiitions

The device front panels contain Light Emitting Diodes (LED) that indicate the device status. The different LED types are as follows:


- **Port LEDs** — Indicate each port status.
- **Power LED** — Indicating the device power supply status.

Port LEDs

10/100Base-TX Fast Ethernet RJ-45 Port LEDs

The following figure illustrates the port LEDs.

Figure 5: 10/100Base-TX Fast Ethernet RJ-45 Port LEDs



The RJ-45 ports have two LEDs, one for speed, and one for Link /activity. The LED indications are described in the following table:


Table 3: 10/100Base-TX Fast Ethernet RJ-45 Port LED Indications

Port Description	LED Indication	Description
Left LED - Speed	Green	A 100-Mbps link is established on the port.
	Off	A 10-Mbps link is established on the port or no link is established on the port.
Link/Activity LED	Green	A link is established on the port.
	Flashing Green	There is data transmission on the port.
	Off	No link is established on the link.

1000Base-T Gigabit Ethernet RJ-45 Port LEDs

The following figure illustrates the port LEDs.

Figure 6: 1000Base-T Gigabit Ethernet RJ-45 Port LEDs



The RJ-45 ports have two LEDs, one for speed, and one for Link /activity. The LED indications are described in the following table:


Table 4: 1000Base-T Gigabit Ethernet RJ-45 Port LED Indications

Port Description	LED Indication	Description
Left LED - Speed	Green	A 100/1000-Mbps link is established on the port.
	Off	No link is established on the port.
Link/Activity LED	Green	A link is established on the port.
	Flashing Green	There is data transmission on the port.
	Off	No link is established on the link.

Fiber Port LEDs

The following figure illustrates the port LEDs.

Figure 7: Fiber Port LEDs



The RJ-45 ports have two LEDs, one for speed, and one for Link /activity. The LED indications are described in the following table:


Table 5: Fiber Port LED Indications

Port Description	LED Indication	Description
Left LED - Speed	Green	A 100/1000-Mbps link is established on the port.
	Off	No link is established on the port.
Link/Activity LED	Green	A link is established on the port.
	Flashing Green	There is data transmission on the port.
	Off	No link is established on the link.

SFP Port LEDs

The following figure illustrates the port LEDs.

Figure 8: SFP Port LEDs



The RJ-45 ports have two LEDs, one for speed, and one for Link /Activity. The LED indications are described in the following table:

Table 6: SFP Port LED Indications

Port Description	LED Indication	Description
Left LED - Speed	Green	A 100/1000-Mbps link is established on the port.
	Off	No link is established on the port.
Link/Activity LED	Green	A link is established on the port.
	Flashing Green	There is data transmission on the port.
	Off	No link is established on the link.

Power LED

The power supply status is indicated by the Power Supply LED on the front panel of the device.

The power supply port LED indications are described in the following table:

Table 7: Power Supply LED Indications

Port Description	LED Indication	Description
Power	Off	The system is not powered up. (power off)
	Green	Main power is functional (normal operation)

Console LED

The console status is indicated by the Console LED on the front panel of the device.

The console LED indications are described in the following table:

Table 8: Console LED Indications

Port Description	LED Indication	Description
Console	Flashing Green	Power On Self Test (POST) is in progress.
	Green	POST failure. A problem has been discovered during the POST.


Cable, Port, and Pinout Information

This section describes the devices physical interfaces and provides information about cable connections. Stations are connected to the device ports through the physical interface ports on the front panel. For each station, the appropriate mode (Half/Full Duplex, Auto Negotiation) is set. The default is Auto Negotiation.

Pin Connections for the 10/100/1000 Ethernet Interface

The switching port can connect to stations wired in standard RJ-45 Ethernet station mode using straight cables. Transmission devices connected to each other use crossed cables. The following figure illustrates the pin allocation.

Figure 9: RJ-45 Pin Allocation



The following table describes the pin allocation

Table 9: RJ-45 Pin Connections for 10/100/1000 Base-TX

Pin	Use
1	TxRx 1+
2	TxRx 1-
3	TxRx 2+
4	TxRx 2-
5	TxRx 3+
6	TxRx 3-
7	TxRx 4+
8	TxRx 4-

Physical Dimensions

The device has the following physical dimensions:

- Width: 220 mm (8.66 inch)
- Depth: 155mm (6.10 inch)
- Height: 35 mm (1.38 inch)

Section 2. Mounting Device

This section contains information for installing the device, and includes the following sections:

- Preparing for Installation
- Installing the Device
- Connecting the Device
- Rack Installation
- Wall Installation

Preparing for Installation

This section provides an explanation for preparing the installation site, and includes the following topics:

- Installation Precautions
- Site Requirements
- Unpacking

Installation Precautions



Warnings

- The surface on which the switch is placed should be adequately secured to prevent it from becoming unstable and/or falling over.
- Ensure the power source circuits are properly grounded.
- Observe and follow service markings. Do not service any product except as explained in your system documentation. Opening or removing covers marked with a triangular symbol with a lightning bolt may cause electrical shock. These components are to be serviced by trained service technicians only.
- Ensure the power cable, extension cable, and/or plug is not damaged.
- Ensure the product is not exposed to water.
- Ensure the device is not exposed to radiators and/or heat sources.
- Do not push foreign objects into the device, as it may cause a fire or electric shock.
- Use the device only with approved equipment.
- Allow the product to cool before removing covers or touching internal equipment.
- Ensure the switch does not overload the power circuits, wiring, and over-current protection. To determine the possibility of overloading the supply circuits, add together the ampere ratings of all devices installed on the same circuit as the device being installed. Compare this total with the rating limit for the circuit. The maximum ampere ratings are usually printed on the switch, near their AC power connectors.



Cautions

- Ensure the air flow around the front, sides, and back of the switch is not restricted.
- Ensure the cooling vents are not blocked.
- Do not install the switch in an environment where the operating ambient temperature might exceed 40°C (104°F).

Site Requirements

The device is placed on a table-top. Before installing the unit, verify that the location chosen for installation meets the following site requirements.

- **General** — Ensure that the power supply is correctly installed.
- **Power** — The unit is installed within 1.5 m (5 feet) of a grounded, easily accessible outlet 100-250 VAC, 50-60 Hz.
- **Clearance** — There is adequate frontal clearance for operator access. Allow clearance for cabling, power connections and ventilation.
- **Cabling** — The cabling is routed to avoid sources of electrical noise such as radio transmitters, broadcast amplifiers, power lines and fluorescent lighting fixtures.

- **Ambient Requirements** — The ambient unit operating temperature range is 0 to 40°C (32 to 104°F) at a relative humidity of up to 95%, non-condensing. Verify that water or moisture cannot enter the device casing.

Unpacking

This section contains information for unpacking the device, and includes the following topics:

- Package Contents
- Unpacking Essentials

Package Contents

While unpacking the device, ensure that the following items are included:

- The device
- Four rubber feet with adhesive backing
- Rack kit
- An AC power cable
- Console RS-232 cable with DB-9 connector
- Documentation CD

Unpacking Essentials



Note

Before unpacking the device, inspect the package and report any evidence of damage immediately.

To unpack the device perform the following:

1. It is recommended to put on an ESD wrist strap and attach the ESD clip to a metal surface to act as ground. An ESD strap is not supplied with the device.
2. Place the container on a clean flat surface and cut all straps securing the container.
3. Open the container.
4. Carefully remove the device from the container and place it on a secure and clean surface.
5. Remove all packing material.
6. Inspect the product for damage. Report any damage immediately.

If any item is found missing or damaged, please contact your local D-Link reseller for replacement.

Installing the Device

The device can be installed on a flat surface or mounted in a rack. This section includes the following topics:

- Desktop or Shelf Installation
- Rack Installation

Desktop or Shelf Installation


When installing the switch on a desktop or shelf, the rubber feet included with the device should first be attached. Attach these cushioning feet on the bottom at each corner of the device.

Ensure the surface is able to support the weight of the device and the device cables.

To install the device on a surface, perform the following:

1. Attach the rubber feet on the bottom of the device. The following figure illustrates the rubber feet installation on the device.

Figure 10: Installing Rubber Feet



2. Set device down on a flat surface, while leaving 2 inches on each side and 5 inches at the back.
3. Ensure that the device has proper ventilation by allowing adequate space for ventilation between the device and the objects around the device.

Rack Installation

The device can be mounted in an EIA standard-sized, 19-inch rack, which can be placed in a wiring closet with other equipment. To install, the device the mounting brackets must first be attached on the devices's sides.




Notes

- Disconnect all cables from the unit before mounting the device in a rack or cabinet.
- When mounting multiple devices into a rack, mount the devices from the bottom up.

To install the device in a rack, perform the following:


1. Place the supplied rack-mounting bracket on one side of the device ensuring the mounting holes on the device line up to the mounting holes on the rack mounting bracket. The following figure illustrates where to mount the brackets.

Figure 11: Attaching the Mounting Brackets



2. Insert the supplied screws into the rack mounting holes and tighten with a screwdriver.
3. Repeat the process for the rack-mounting bracket on the other side of the device.
4. Insert the unit into the 19-inch rack ensuring the rack-mounting holes on the device line up to the mounting hole on the rack. The following figure illustrates lining up and mounting the device in the rack.

Figure 12: Mounting Device in a Rack



5. Secure the unit to the rack with the rack screws (not provided). Fasten the lower pair of screws before the upper pair of screws. This ensures that the weight of the unit is evenly distributed during installation. Ensure that the ventilation holes are not obstructed.


Wall Installation

The device can also be mounted on a wall inside a wiring closet.

To mount the device on a wall, perform the following:


1. Mark two holes 100mm apart on the wall.
2. Drill holes into the wall where the marks have been made. The hole diameter and depth is defined by the wall plug and screw combination being used to mount the device.
3. Insert the wall plugs into the holes.
4. Screw the screws into the wall plugs allowing the heads to protrude from the wall. The device is mounted on the protruded heads.

Figure 13: Inserting wall plugs and screws



5. Align the mounting holes on the back of the device with the screws in the wall, and mount the device on the wall.

Figure 14: Mounting the device on the wall



Connecting the Device

This section describes how to connect the device, and includes the following sections:

- Connecting the Switch to a Terminal
- AC Power Connection

Connecting the Switch to a Terminal

The device is connected to a terminal through an console port on the front panel, which enables a connection to a terminal desktop system running terminal emulation software for monitoring and configuring the device.

The terminal must be a VT100 compatible terminal or a desktop or portable system with a serial port and running VT100 terminal emulation software.

To connect a terminal to the device Console port, perform the following:

1. Connect a cable to the terminal running VT100 terminal emulation software.
2. Ensure that the terminal emulation software is set as follows:
 - a) Select the appropriate port to connect to the device.
 - b) Set the data rate to 9600 baud.
 - c) Set the data format to 8 data bits, 1 stop bit, and no parity.

- d) Set flow control to none.
- e) Under Properties, select VT100 for Emulation mode.
- f) Select **Terminal keys** for **Function**, **Arrow**, and **Ctrl** keys. Ensure that the setting is for Terminal keys (not Windows keys).



Note

When using HyperTerminal with Microsoft Windows 2000, ensure that you have Windows 2000 Service Pack 2 or later installed. With Windows 2000 Service Pack 2, the arrow keys function properly in HyperTerminal's VT100 emulation. Go to www.microsoft.com for information on Windows 2000 service packs.

- 3. Connect the cable to the console port on the device front panel.

AC Power Connection

To connect the power supply perform the following:

- 1. Using a 5-foot (1.5 m) standard power cable with safety ground connected, connect the power cable to the AC main socket located on the back panel.
- 2. Connect the power cable to a grounded AC outlet.
- 3. Confirm that the device is connected and operating by checking that the Power Supply LED on the front panel is green.

Section 3. Starting and Configuring the Device

This section describes initial device configuration and includes the following topics:

- Configuring the Terminal
- Installation Procedure
- Booting the Device
- Configuration Overview
- Advanced Configuration
- Startup Procedures

Configuring the Terminal

After completing all external connections, connect a terminal to the device to monitor the boot and other procedures.

To configure the device, the terminal must be running terminal emulation software.

Ensure that the terminal emulation software is configured as follows:

1. Connect the Chassis serial port to the switch module. The baud rate automatically boots up at 9600.
2. Set the data format to 8 data bits, 1 stop bit, and no parity.
3. Set Flow Control to none.
4. Under Properties, select VT100 for Emulation mode.
5. Select Terminal keys for Function, Arrow, and Ctrl keys. Ensure that the setting is for Terminal keys (not Windows keys).



Note

When using HyperTerminal with Microsoft® Windows 2000, make sure that Windows® 2000 Service Pack 2 or later is installed. With Windows 2000 Service Pack 2, the arrow keys function properly in HyperTerminal's VT100 emulation. Go to www.microsoft.com for information on Windows 2000 service packs.

Installation Procedure

The order of installation and configuration procedures is illustrated in the following figure. For the initial configuration, the standard device configuration is performed.

Performing other functions is described later in this section.

Device Port Default Settings

The following table describes the device port default settings.

Table 10: Port Default Setting

Function	Default Settings
Port speed and mode	100M Auto-negotiation
Port forwarding state	Enabled
Head of line blocking prevention	On (Enabled)
Flow Control	Off
Back Pressure	Off



Note

These default settings can be modified once the device is installed.

Booting the Device

The assumed bootup information is as follows:

- The device is delivered with a default configuration.
- The default user name is admin
- The default password is blank.

To login, perform the following steps:

1. Press Enter twice in rapid succession. The auto baud-rate process synchronizes the host and the device.
2. Enter the user name, admin. The default password is blank.

To boot the device, perform the following steps:

1. Ensure that the device port console is connected to a VT100 terminal device or VT100 terminal emulator.
2. Locate an AC power receptacle.
3. Deactivate the AC power receptacle.
4. Connect the device to the AC receptacle.
5. Activate the AC power receptacle.

The device goes through Power On Self Test (POST). POST runs every time the device is initialized and checks hardware components to determine if the device is fully operational before completely booting. If a critical problem is detected, the program flow stops. If POST passes successfully, a valid executable image is loaded into RAM. POST messages are displayed on the terminal and indicate test success or failure.

As the device boots, the bootup test first counts the device memory availability and then continues to boot. The following screen is an example of the displayed POST:

```
----- Performing the Power-On Self Test (POST) -----

UART Channel Loopback Test.....PASS
Testing the System SDRAM.....PASS
Boot1 Checksum Test.....PASS
Boot2 Checksum Test.....PASS
Flash Image Validation Test.....PASS
FRU Validation Test.....PASS

BOOT Software Version x.x.x.xx Built 22-Jan-2005 15:09:28
Processor: xxxxxx xxxxx , xxx MByte SDRAM.
I-Cache x KB. D-Cache x KB. Cache Enabled.

Autoboot in 2 seconds - press RETURN or Esc. to abort and enter prom.
Preparing to decompress...
```

The boot process runs for approximately 60 seconds.

The auto-boot message displayed at the end of POST (see the last lines) indicates that no problems were encountered during boot.

During boot, the Startup menu can be used to run special procedures. To enter the Startup menu, press **<Esc>** or **<Enter>** within the first two seconds after the auto-boot message is displayed.

If the system boot process is not interrupted by pressing **<Esc>** or **<Enter>**, the process continues decompressing and loading the code into RAM. The code starts running from RAM and the list of numbered system ports.

After the device boots successfully, a system prompt is displayed (console>) which is used to configure the device. However, before configuring the device, ensure that the latest software version is installed on the device. If it is not the latest version, download and install the latest version. For more information on downloading the latest version, see *Software Download and Reboot*.

Configuration Overview

Before assigning a static IP address to the device, obtain the following information:

- A specific IP address that has been allocated to the device in order for it to be configured.
- A default route.
- A network mask for the network.

There are two configuration types:

- Initial Configuration — Consists of configuration functions with basic security considerations.
- Advanced Configuration — Consists of dynamic IP configuration and more advanced security considerations.



Note

After making any configuration changes, the new configuration must be saved before rebooting. To save the configuration, enter:

console# **copy running-config startup-config**

Initial Configuration

Initial configuration, which starts after the device has booted successfully, includes static IP address and subnet mask configuration, and setting user names and privilege levels to allow remote management. If the device is to be managed from an SNMP-based management station, SNMP community strings must also be configured.

The following configurations are completed, and the initial configuration uses the following assumptions:

- The device was never configured before, and is in the same state as when it was received.
- The device booted successfully.
- The Serial connection is established and the console prompt is displayed on the screen of a VT100 terminal device. (Press **<Enter>** several times to verify that the prompt displays correctly.)
- The device is not configured with a default user name and password.

The initial device configuration is through the Serial port. After the initial configuration, the device can then be managed either from the already connected Serial port or remotely through an interface defined during the initial configuration.

During the initial configuration, you can:

- Configure a user name, a password, and the highest privilege level of 15.
- Configure the static IP address and the default gateway.
- Configure the SNMP read/write community string.
- Assign the IP address allocated by the DHCP server.

Before applying the initial configuration procedure to the device, the following information must be obtained from the network administrator:

- The IP address to be assigned to a VLAN through which the device is managed.
- The IP subnet mask for the network.

- The default gateway IP address.
- The SNMP community.

Static IP Address and Subnet Mask

IP interfaces can be configured on each port of the device. After entering the configuration command, it is recommended to check if a port was configured with the IP address by entering the `show ip interface` command.



Note

The commands to configure the device are port specific.

To manage the switch from a remote network, a static route must be configured, which is an IP address to where packets are sent when no entries are found in the device tables. The configured IP address must belong to the same subnet as one of the device IP interfaces.

To configure a static route, enter the command at the system prompt, as shown in the following configuration example, where 100.1.1.1 is the specific management station, the IP address is defined on VLAN 1, and the default gateway is defined as 100.1.1.10. Note that by default, all ports are members of VLAN 1, which is the default VLAN.

```
console# configure
console(config)# interface vlan 1
console(config-if)# ip address 100.1.1.1 255.255.255.0
console(config-if)# exit
console# default-gateway 100.1.1.10 255.255.255.0
```

Confirm that the IP address has been correctly configured as follows:

```
console# show ip interface
Proxy ARP is disabled
IP Address      I/F      Type
-----
100.1.1.1/24    vlan 1    static
```

Assigning Static IP Addresses on a Default VLAN

This example uses the following assumptions:

- The IP address to be assigned to the VLAN interface is 100.1.1.110
- The IP subnet mask for the network is 255.255.255.0
- The IP address of the default route is 192.168.1.1
- The read/write SNMP community string is "private"

```
console> enable
console# configure
console(config)# username admin password dlink level 15
console(config)# interface VLAN 1
console (config-if) # ip address 100.1.1.110
console (config-if) # exit
```

```
console (config) # ip default-gateway 100.1.1.110
console (config) # snmp-server community private rw
console(config)# exit
console#
```

Verifying the IP and Default Gateway Addresses

To ensure that the IP address and the default gateway were properly assigned, execute the following command and examine its output:

```
console # - ip interface
Gateway IP Address      Activity status
-----
192.168.1.1             Active

IP address              Interface      Type
-----
192.168.1.123/24        VLAN 1        Static
```

User Name

A user name is used to manage the device remotely, for example through SSH, Telnet, or the Web interface. To gain complete administrative (super-user) control over the device, the highest privilege (15) must be specified.



Note

Only the administrator (super-user) with the highest privilege level (15) is allowed to manage the device through the web browser interface.

For more information about the privilege level, see the CLI Reference Guide.

The configured user name is entered as a login name for remote management sessions. To configure a user name, password, and privilege level, enter the command at the system prompt as shown in the configuration example:

```
console> enable
console# configure
console(config)# username admin password lee privilege 15
```

SNMP Community Strings

Simple Network Management Protocol (SNMP) provides a method for managing network devices. Devices supporting SNMP run a local software agent. The SNMP agents maintain a list of variables, used to manage the device. The variables are defined in the Management Information Base (MIB). The SNMP agent defines the MIB specification format, as well as the format used to access the information over the network.

Access rights to the SNMP agents are controlled by access strings and SNMP community strings.

The device is SNMP-compliant, and contains an SNMP agent that supports a set of standard and private MIB variables. Developers of management stations require the exact structure of the MIB tree and receive the complete private MIBs information before being able to manage the MIBs.

All parameters are manageable from any SNMP management platform, except the SNMP management station IP address and community (community name and access rights). The SNMP management access to the switch is disabled if no community strings exist.



Note

The device is delivered with no community strings configured.

The community-string, community-access, and IP address can be configured through the local terminal during the initial configuration procedure.

The SNMP configuration options are:

- Community string
 - Access rights options: ro (read only), rw (read-and-write), and su (super).
 - An option to configure IP address or not. If an IP address is not configured, it means that all community members having the same community name are granted the same access rights.

Common practice is to use two community strings for the device, one (public community) with read-only access and the other (private community) with read-write access. The public string allows authorized management stations to retrieve MIB objects, while the private string allows authorized management stations to retrieve and modify MIB objects.

During initial configuration, it is recommended to configure the device according to the network administrator requirements, in accordance with using an SNMP-based management station. During the initial configuration procedure, the community-string, community-access, and IP address can be set through the local terminal.

The SNMP configuration options are:

- Community string.
 - **Read Only** — Community members can view configuration information, but cannot change any information.
 - **Read/Write** — Community members can view and modify configuration information.
 - **Super** — Community members have administration access.
- Configurable IP address. If an IP address is not configured, all community members with the same community name are granted the same access rights.

To configure an SNMP station IP address and community string(s), perform the following steps:

1. At the console prompt, enter the command **Enable**. The prompt is displayed as #.
2. Enter the command **configure** and press <Enter>.
3. In configuration mode, enter the SNMP configuration command with the parameters including community name (private), community access right (read and write), and IP address, as shown in the following example:

```

console# configure
config(config)# snmp-server community private rw 11.1.1.2 type router
config(config)# exit
console(config)# show snmp
Community-String      Community-Access      IP address
-----
private              readWrite              11.1.1.2
Traps are enabled.
Authentication-failure trap is enabled.

Trap-Rec-Address      Trap-Rec-Community      Version
-----
System
```

Contact:

System Location:

This completes the initial configuration of the device from a local terminal. The configured parameters enable further device configuration from any remote location.

Advanced Configuration

This section provides information about dynamic allocation of IP addresses and security management based on the authentication, authorization, and accounting (AAA) mechanism, and includes the following topics:

- Receiving an IP Address from a DHCP Server
- Receiving an IP Address from a BOOTP Server
- Security Management and Password Configuration

When configuring or receiving IP addresses through DHCP and BOOTP, the configuration received from these servers includes the IP address, and may include a subnet mask and default gateway.

Receiving an IP Address from a DHCP Server

When using the DHCP protocol to retrieve an IP address, the device acts as a DHCP client. To receive an IP address from a DHCP server, perform the following steps:

1. Select and connect any port to a DHCP server or to a subnet that has a DHCP server on it, in order to retrieve the IP address.
2. Enter the following commands to use the selected port for receiving the IP address. In the following example, the commands are based on the port type used for configuration.

```
console# configure
console(config)# interface ethernet 1
console(config-if)# ip address dhcp hostname admin-host
console(config-if)# exit
console(config)#
```

3. To verify the IP address, enter the **show ip interface** command at the system prompt as shown in the following example.

```
console# show ip interface
IP Address      I/F      Type
-----
100.1.1.1/24    vlan 1    dynamic
```



Notes

- The device configuration does not have to be deleted to retrieve an IP address for the DHCP server.
- When copying configuration files, avoid using a configuration file that contains an instruction to enable DHCP on an interface that connects to the same DHCP server, or to one with an identical configuration. As a result of the copying configuration, the switch retrieves the new configuration file and boots from it. The device then enables DHCP as instructed in the new configuration file, and the DHCP instructs it to reload the same file.

Receiving an IP Address from a BOOTP Server

The standard BOOTP protocol is supported and enables the switch to automatically download its IP host configuration from any standard BOOTP server in the network. In this case, the device acts as a BOOTP client.

To receive an IP address from a BOOTP server:

1. Select and connect any port to a BOOTP server or subnet containing such a server.
2. At the system prompt, enter the **delete startup configuration** command to delete the startup configuration from flash.

The device reboots with no configuration and in 60 seconds starts sending BOOTP requests. The device receives the IP address automatically.



Note

When the device reboot begins, any input at the ASCII terminal or keyboard automatically cancels the BOOTP process before completion, and the device does not receive an IP address from the BOOTP server.

The following example illustrates the process:

```
console# enable
console# delete startup-config
Startup file was deleted
console# reload
You haven't saved your changes. Are you sure you want to continue (y/n)[n]?
This command will reset the whole system and disconnect your current session.Do you want
to continue (y/n)[n]?
*****
/*the device reboots */
```

3. To verify the IP address, enter the **show ip interface** command. The device is now configured with an IP address.

Security Management and Password Configuration

System security is handled through the AAA (Authentication, Authorization, and Accounting) mechanism that manages user access rights, privileges, and management methods. AAA uses both local and remote user databases. Data encryption is handled through the SSH mechanism.

The system is delivered with the user name admin, and no default password configured; all user names and passwords are user-defined. If a user-defined user name and/or password is lost, a password recovery procedure can be initiated from the Startup menu. The procedure is applicable for the local terminal only and allows a one-time access to the device from the local terminal with no password entered.

The security passwords can be configured for the following services:

- Console
- Telnet
- SSH
- HTTP
- HTTPS



Note

When creating a user name, the default priority is 1, which allows access but not configuration rights. A priority of 15 must be set to enable full access and configuration rights to the device. Although user names can be assigned privilege level 15 without a password, it is recommended to always assign a password. If there is no specified password, privileged users can access the web interface with any password.

This section contains the following topics:

- Configuring an Initial Console Password
- Configuring an Initial Telnet Password
- Configuring an Initial SSH password
- Configuring an Initial HTTP Password
- Configuring an initial HTTPS Password

Configuring an Initial Console Password

To configure an initial console password, enter the following commands:

```
console(config)# aaa authentication login default line
console(config)# aaa authentication enable default line
console(config)# line console
console(config-line)# login authentication default
console(config-line)# enable authentication default
console(config-line)# password george
```

When initially logging on to a device through a console session, enter *george* at the password prompt.

When changing a device mode to enable, enter *george* at the password prompt.

Configuring an Initial Telnet Password

To configure an initial Telnet password, enter the following commands:

```
console(config)# aaa authentication login default line
console(config)# aaa authentication enable default line
console(config)# line telnet
console(config-line)# login authentication default
console(config-line)# enable authentication default
console(config-line)# password bob
```

When initially logging onto a device through a Telnet session, enter *bob* at the password prompt.

When changing a device mode to enable, enter *bob*.

Configuring an Initial SSH password

To configure an initial SSH password, enter the following commands:

```
console(config)# aaa authentication login default line
console(config)# aaa authentication enable default line
console(config)# line ssh
console(config-line)# login authentication default
console(config-line)# enable authentication default
console(config-line)# password jones
```

When initially logging onto a device through a SSH session, enter *jones* at the password prompt.

When changing a device mode to enable, enter *jones*.

Configuring an Initial HTTP Password

To configure an initial HTTP password, enter the following commands:

```
console(config)# ip http authentication local
console(config)# username admin password user1 level 15
```

Configuring an initial HTTPS Password

To configure an initial HTTPS password, enter the following commands:

```
console(config)# ip https authentication local
console(config)# username admin password user1 level 15
```

Enter the following commands when configuring to use a console, a Telnet, or an SSH session to use an HTTPS session.

In the Web browser, enable SSL 2.0 or greater for the content of the page to appear.

```
console(config)# crypto certificate generate key_generate
console(config)# ip https server
```

When initially enabling an http or https session, enter *admin* for user name and *user1* for password.



Note

HTTP and HTTPS services require level 15 access and connect directly to the configuration level access.

Startup Procedures

This section includes the following topics:

- Startup Menu Procedures
- Software Download and Reboot

Startup Menu Procedures

The procedures called from the Startup menu cover software download, flash handling, and password recovery. The diagnostics procedures are for use by technical support personnel *only* and are not disclosed in this document.

The Startup menu can be entered when booting the device. A user input must be entered immediately after the POST test.

To enter the Startup menu:

1. Turn the power on and watch for the auto-boot message.

This command will reset the whole system and disconnect your current session. Do you want to continue (y/n) [n] ?

y

```
*****
***** SYSTEM RESET *****
*****
```

----- Performing the Power-On Self Test (POST) -----

UART Channel Loopback Test.....PASS

Testing the System SDRAM.....PASS

I2C Bus Test.....PASS

Boot1 Checksum Test.....PASS

Boot2 Checksum Test.....PASS

Flash Image Validation Test.....PASS

BOOT Software Version 1.0.0.11 Built 10-Apr-2005 13:25:46

DES3010 D-LINK board - based on Samsung S3C2510A ARM940T processor.

32 MByte SDRAM. I-Cache 4 KB. D-Cache 4 KB. Cache Enabled.

Autoboot in 2 seconds - press RETURN or Esc. to abort and enter prom.

2. When the auto-boot message appears, press **<Enter>** to display the Startup menu. The Startup menu procedures can be done using the ASCII terminal or Windows HyperTerminal.

- [1] Download Software
- [2] Erase Flash File
- [3] Erase Flash Sectors
- [4] Password Recovery Procedure
- [5] Enter Diagnostic Mode
- [6] Back

Enter your choice or press 'ESC' to exit: Enter your choice or press 'ESC' to exit:

The following sections describe the available Startup menu options.



Note

When selecting an option from the Startup menu, time must be taken into account. If no selection is made within 35 seconds (default), the device times out. This default value can be changed through the CLI.

Only technical support personnel can use Diagnostics Mode. For this reason, Diagnostics Mode is not described in this guide.

Software Download and Reboot

This section describes the procedures for downloading software and rebooting the system, and includes the following topics:

- Software Download from the Startup Menu
- Erasing the Flash File
- Password Recovery
- Software Download through TFTP Server
- Software Download through XModem

Software Download from the Startup Menu

The software download procedure is performed when a new version must be downloaded to replace corrupted files, or when the system software must be upgraded. To download software from the Startup menu:

1. From the Startup menu, press [1]. The following prompt appears:
`Downloading code using XMODEM`
2. When using HyperTerminal, click **Transfer** on the HyperTerminal Menu Bar.
3. In the **Filename** field, enter the file path for the file to be downloaded.
4. Ensure that the Xmodem protocol is selected in the **Protocol** field.
5. Press **Send**. The software is downloaded.



Note

After software download, the device reboots automatically.

Erasing the Flash File

In some cases, the device configuration must be erased. If the configuration is erased, all parameters configured via CLI, EWS, or SNMP must be reconfigured.

To erase the device configuration:

1. From the Startup menu, press [2] within two seconds to erase the flash file. The following message is displayed:
`Warning! About to erase a Flash file.`
`Are you sure (Y/N)? y`
2. Press **Y**. The following message is displayed.
`Write Flash file name (Up to 8 characters, Enter for none.):config`
`File config (if present) will be erased after system initialization`
`===== Press Enter To Continue =====`
3. Enter `config` as the name of the flash file. The configuration is erased and the device reboots.

4. Repeat the initial device configuration.

Password Recovery

If a password is lost, you can perform the password recovery procedure from the Startup menu. The password recovery procedure enables entry to the device one time without a password.

To recover a lost password for the local terminal only:

1. From the Startup menu, type [4] and press <Enter>. The password is deleted.



Note

To ensure device security, reconfigure passwords for applicable management methods.

Software Download through TFTP Server

This section contains instructions for downloading device software (system and boot images) through a TFTP server. The TFTP server must be configured before beginning to download the software. This section contains the following topics:

- System Image Download
- Boot Image Download

System Image Download

The device boots and runs when decompressing the system image from the flash memory area where a copy of the system image is stored. When a new image is downloaded, it is saved in the area allocated for the other system image copy.

On the next boot, the device decompresses and runs the currently active system image unless otherwise directed.

To download a system image through the TFTP server:

1. Ensure that an IP address is configured on one of the device ports and pings can be sent to the TFTP server.
2. Make sure that the file to be downloaded is saved on the TFTP server (the `arc` file).
3. Enter **show version** to verify which software version is currently running on the device. The following is an example of the information that appears:

```
console# show version
SW version   1.0.0.42 (date 22-Jul-2004 time 13:42:41)
Boot version 1.0.0.18 (date 01-Jun-2004 time 15:12:20)
HW version
```

4. Enter **show bootvar** to verify which system image is currently active. The following is an example of the information that appears:

```
console# sh bootvar
Images currently available on the Flash
Image-1 active (selected for next boot)
Image-2 not active
console#
```

5. Enter **copy tftp://{tftp address}/{file name} image** to copy a new system image to the device. When the new image is downloaded, it is saved in the area allocated for the other copy of system image (image-2, as given in the example). The following is an example of the information that appears:

```
console# copy tftp://176.215.31.3/file1.ros image
```


Please download program using XMODEM.

console#

2. Specify the path of the source file within 20 seconds.
If the path is not specified within 20 seconds, the command times out.

To download a software image file using XModem:

1. Enter the command `console# xmodem:image`.
The switch is ready to receive the file via the XModem protocol.
2. Specify the path of the source file to begin the transfer process.
The following is an example of the information that appears:

```
console# copy xmodem: image
```

```
Please download program using XMODEM
```


D-Link DES 3010FA/GA EWS User Guide

Section 4. Getting Started

This section provides an introduction to the user interface, and includes the following topics:


- Starting the D-Link Embedded Web Interface
- Understanding the D-Link Embedded Web Interface
- Using Screen and Table Options
- Resetting the Device
- Logging off from the Device

Starting the D-Link Embedded Web Interface

This section contains information on starting the D-Link Embedded Web interface. To access the D-Link user interface:

1. Open an Internet browser.
2. Ensure that pop-up blockers are disabled. If pop-up blockers are enable, edit, add, and device information messages may not open.
3. Enter the device IP address in the address bar and press **<Enter>**. The *Enter Network Password Page* opens:

Figure 15: Enter Network Password Page



The screenshot shows the 'Enter Network Password Page' of the D-Link Embedded Web Interface. At the top, there is a blue header bar with the 'D-Link' logo. Below the header, the page has a light blue background. On the left side, there is a 'Log In' link. In the center, there is a white rectangular box with a gray border. Inside this box, the text 'Type in Username and Password, then click OK' is displayed. Below this text, there are two input fields: 'Username' and 'Password'. Below the input fields, there is a blue 'Ok' button.

4. Enter your user name and password.



Notes

- The device is configured with a user name that is admin and a password that is blank, and can be configured without entering a password.
- Passwords are case sensitive.
- To operate the device, disable all pop-ups with a popup blocker.


5. Click . The *D-Link Embedded Web Interface Home Page* opens:

Figure 16: D-Link Embedded Web Interface Home Page



Understanding the D-Link Embedded Web Interface

The *D-Link Embedded Web Interface Home Page* contains the following views:

- **Port LED Indicators** — Located at the top of the home page, the port LED indicators provide a visual representation of the ports on the D-Link front panel.
- **Tab Area** — Located under the LED indicators, the tab area contains a list of the device features and their components.
- **Device View** — Located in the main part of the home page, the device view provides a view of the device, an information or table area, and configuration instructions.

Figure 17: D-Link Embedded Web Interface Components



The following table lists the user interface components with their corresponding numbers:

Table 11: Interface Components

View	Description
1 Tree View	Tree View provides easy navigation through the configurable device features. The main branches expand to display the sub-features.
2 Device View	Device View provides information about device ports, current configuration and status, table information, and feature components. Device View also displays other device information and dialog boxes for configuring parameters.
3 Tab Area	The Tab Area enables navigation through the different device features. Click the tabs to view all the components under a specific feature.
4 Zoom View	Provides a graphic of the device on which D-Link Web Interface runs.
5 D-Link Web Interface Information Tabs	Provide access to online help, and contain information about the EWS.


This section provides the following additional information:

- **Device Representation** — Provides an explanation of the D-Link user interface buttons, including both management buttons and task icons.
- **Using the D-Link Embedded Web Interface Management Buttons** — Provides instructions for adding, modifying, and deleting configuration parameters.

Device Representation

The D-Link Embedded Web Interface Home Page contains a graphical panel representation of the device.

Figure 18: Device Representation



Using the D-Link Embedded Web Interface Management Buttons

Configuration Management buttons and icons provide an easy method of configuring device information, and include the following:

Table 12: D-Link Web Interface Configuration Buttons

Button	Button Name	Description
	Clear Logs	Clears system logs.
	Create	Enables creation of configuration entries.
	Edit	Modifies configuration settings.
	Submit	Saves configuration changes to the device.
	Test	Performs cable tests.
	Query	Queries the device table.

Table 13: D-Link Web Interface Information Tabs

Tab	Tab Name	Description
	Help	Opens the online help.
	Logout	Opens the Logout page.

Using Screen and Table Options

D-Link contains screens and tables for configuring devices. This section contains the following topics:

- Adding Configuration Information
- Modifying Configuration Information
- Deleting Configuration Information

Adding Configuration Information

User-defined information can be added to specific D-Link Web Interface pages, by opening a new Add page. To add information to tables or D-Link Web Interface pages:



1. Open an D-Link Web Interface page.
2. Click . An add page opens, such as the *Add SNMP Interface Page*:

Figure 19: Add SNMP Interface



3. Define the fields.
4. Click . The configuration information is saved, and the device is updated.

Modifying Configuration Information


1. Open The D-Link Embedded Web Interface page.
2. Select a table entry.
3. Click . A modification page, such as the *IP Interface Settings Page* opens:

Figure 20: IP Interface Settings Page

IP Interface Settings

IP Address	10.6.39.150
<input checked="" type="radio"/> Network Mask	255.255.255.0
<input type="radio"/> Prefix Length	/24
Interface	<input checked="" type="radio"/> Port 3 <input type="radio"/> LAG 1 <input type="radio"/> VLAN 1
Type	Static

Submit

4. Modify the fields as required.
5. Click **Submit**. The fields are modified, and the information is saved to the device.

Deleting Configuration Information

1. Open The D-Link Embedded Web Interface page.
2. Select a table row.
3. Select the *Remove* checkbox.
4. Click **Submit**. The information is deleted, and the device is updated.

Resetting the Device

The *Reset* page enables the device to be reset from a remote location.



Note

To prevent the current configuration from being lost, save all changes from the running configuration file to the startup configuration file before resetting the device. For instructions, see "Copying Files" on page 199.

To reset the device:


1. Click **System > General > Reset**. The *Reset* page opens.


Figure 21: Reset Page



2. Click **Reset Device**. A confirmation message is displayed.

Figure 22: Reset Confirmation Message





3. Click . The device is reset, and a prompt for a user name and password is displayed.
4. Enter a user name and password to reconnect to the web Interface.

Logging off from the Device

1. Click . The Logout Page opens.

Figure 23: Logout Page



2. Click . The *D-Link Embedded Web Interface Home Page* closes.

Section 5. Managing Device Information

The *System Information Page* contains parameters for configuring general device information, including the system name, location, and contact, the system MAC Address, System Object ID, System Up Time, System IP and MAC addresses, and both software and hardware versions. To define the general system information:


1. Click **System > General > Description**. The *System Information Page* opens:

Figure 24: System Information Page

Field	Value
Model Name	DES-3010GA
System Name	<input type="text"/>
System Location	<input type="text"/>
System Contact	<input type="text"/>
System Object ID	1.3.6.1.4.1.89.1.1.171.10.67.2
System up time	0 days, 1 hours, 9 minutes, 54 seconds
Base MAC Address	00:13:25:38:78:00
Hardware Version	00.00.01
Software Version	1.0.0.42
Boot Version	1.0.0.12

The *System Information Page* contains the following fields:

- **Model Name** — Displays the device model number and name.
- **System Name** — Defines the user-defined device name. The field range is 0-160 characters.
- **System Location** — Defines the location where the system is currently running. The field range is 0-160 characters.
- **System Contact** — Defines the name of the contact person. The field range is 0-160 characters.
- **System Object ID** — Displays the vendor's authoritative identification of the network management sub-system contained in the entity.
- **System Up Time** — Displays the amount of time since the most recent device reset. The system time is displayed in the following format: Days, Hours, Minutes, and Seconds. For example, 41 days, 2 hours, 22 minutes and 15 seconds.

- **Base MAC Address** — Displays the device MAC address.
 - **Hardware Version** — Displays the installed device hardware version number.
 - **Software Version** — Displays the installed software version number.
 - **Boot Version** — Displays the current boot version running on the device.
2. Define the *System Name*, *System Location*, and *System Contact* fields.
 3. Click . The device information is saved and the device is updated.

Section 6. Configuring Device Security

This section provides access to security pages that contain fields for setting security parameters for ports, device management methods, users, and server security. This section contains the following topics:

- Configuring Management Security
- Configuring Network Security

Configuring Management Security

This section provides information for configuring device management security. This section includes the following topics:

- Configuring Authentication Methods
- Configuring Passwords

Configuring Authentication Methods

This section provides information for configuring device authentication methods. This section includes the topics:

- Defining Access Profiles
- Defining Profile Rules
- Defining Authentication Profiles
- Mapping Authentication Methods
- Defining RADIUS Settings

Defining Access Profiles

Access profiles are profiles and rules for accessing the device. Access to management functions can be limited to user groups. User groups are defined for interfaces according to IP addresses or IP subnets. Access profiles contain management methods for accessing and managing the device. The device management methods include:


- All
- Telnet
- Secure Telnet (SSH)
- HTTP

Management access to different management methods may differ between user groups. For example, User Group 1 can access the switch module only via an HTTPS session, while User Group 2 can access the switch module via both HTTPS and Telnet sessions. The *Access Profile Page* contains the currently configured access profiles and their activity status.

Assigning an access profile to an interface denies access via other interfaces. If an access profile is assigned to any interface, the device can be accessed by all interfaces. To configure access profiles:

1. Click **System > Management Security > Authentication > Access Profiles**. The *Access Profile Page* opens.

Figure 25: Access Profile Page



The *Access Profile Page* contains the following fields:

- **Access Profile Name** — Defines the access profile name. The access profile name can contain up to 32 characters.

- **Current Active Access Profile** — Defines the access profile currently active.
 - **Remove** — Removes the selected access profile. The possible field values are:
 - *Checked* — Removes the selected access profile.
 - *Unchecked* — Maintains the access profiles.
2. Click **Create**. The *Add Access Profile Page* opens:

Figure 26: Add Access Profile Page

Add Access Profile

Access Profile Name

Rule Priority

Management Method


☐ Interface ☒ Port ☒ LAG ☒ VLAN

☐ Source IP Address ☒ Network Mask ☒ Prefix Length

Action

In addition to the fields in the *Access Profile Page*, the *Add Access Profile Page* contains the following fields:

- **Rule Priority** — Defines the rule priority. When the packet is matched to a rule, user groups are either granted permission or denied device management access. The rule number is essential to matching packets to rules, as packets are matched on a first-fit basis. The rule priorities are assigned in the *Profile Rules Page*.
- **Management Method** — Defines the management method for which the rule is defined. Users with this access profile can access the device using the management method selected. The possible field values are:
 - *All* — Assigns all management methods to the rule.
 - *Telnet* — Assigns Telnet access to the rule. If selected, users accessing the device using Telnet meeting access profile criteria are permitted or denied access to the device.
 - *Secure Telnet (SSH)* — Assigns SSH access to the rule. If selected, users accessing the device using Telnet meeting access profile criteria are permitted or denied access to the device.
 - *HTTP* — Assigns HTTP access to the rule. If selected, users accessing the device using HTTP meeting access profile criteria are permitted or denied access to the device.
 - *Secure HTTP (HTTPS)* — Assigns HTTPS access to the rule. If selected, users accessing the device using HTTPS meeting access profile criteria are permitted or denied access to the device.
 - *SNMP* — Assigns SNMP access to the rule. If selected, users accessing the device using SNMP meeting access profile criteria are permitted or denied access to the device.

- **Interface** — Defines the interface on which the access profile is defined. The possible field values are:
 - *Port* — Specifies the port on which the access profile is defined.
 - *LAG* — Specifies the LAG on which the access profile is defined.
 - *VLAN* — Specifies the VLAN on which the access profile is defined.
 - *Source IP Address* — Defines the interface source IP address to which the access profile applies. The *Source IP Address* field is valid for a subnetwork.
- 3. Define the *Access Profile Name*, *Rule Priority*, *Management Method*, *Interface*, *Source IP Address*, *Network Mask* or *Prefix Length*, and *Action* fields.
- 4. Click . The access profile is created, and the device is updated.

Defining Profile Rules


Access profiles can contain up to 128 rules that determine which users can manage the switch module, and by which methods. Users can also be blocked from accessing the device. Rules are composed of filters including:

- Rule Priority
- Interface
- Management Method
- IP Address
- Prefix Length
- Forwarding Action

The rule order in the profile rules table is important, since packets are matched to the first rule meeting the rule criteria. To define profile rules:

1. Click **System > Management Security > Authentication > Profile Rules**. The *Profile Rules Page* opens.

Figure 27: Profile Rules Page



The *Profile Rules Page* contains the following fields:

- **Access Profile Name** — Displays the access profile to which the rule is attached.
- **Priority** — Defines the rule priority. When the packet is matched to a rule, user groups are either granted permission or denied device management access. The rule number is essential to matching packets to rules, as packets are matched on a first-fit basis.
- **Interface** — Indicates the interface type to which the rule applies. The possible field values are:
 - *Port* — Attaches the rule to the selected port.


- *LAG* — Attaches the rule to the selected LAG.
 - *VLAN* — Attaches the rule to the selected VLAN.
 - **Management Method** — Defines the management method for which the rule is defined. Users with this access profile can access the device using the management method selected. The possible field values are:
 - *All* — Assigns all management methods to the rule.
 - *Telnet* — Assigns Telnet access to the rule. If selected, users accessing the device using Telnet meeting access profile criteria are permitted or denied access to the device.
 - *Secure Telnet (SSH)* — Assigns SSH access to the rule. If selected, users accessing the device using Telnet meeting access profile criteria are permitted or denied access to the device.
 - *HTTP* — Assigns HTTP access to the rule. If selected, users accessing the device using HTTP meeting access profile criteria are permitted or denied access to the device.
 - *Secure HTTP (HTTPS)* — Assigns HTTPS access to the rule. If selected, users accessing the device using HTTPS meeting access profile criteria are permitted or denied access to the device.
 - *SNMP* — Assigns SNMP access to the rule. If selected, users accessing the device using SNMP meeting access profile criteria are permitted or denied access to the device.
 - **Source IP Address** — Defines the interface source IP address to which the rule applies.
 - **Prefix Length** — Defines the number of bits that comprise the source IP address prefix, or the network mask of the source IP address.
 - **Action** — Defines the action attached to the rule. The possible field values are:
 - *Permit* — Permits access to the device.
 - *Deny* — Denies access to the device. This is the default.
 - **Remove** — Removes rules from the selected access profiles. The possible field values are:
 - *Checked* — Removes the selected rule from the access profile.
 - *Unchecked* — Maintains the rules attached to the access profile.
2. Click . The *Add Profile Rule Page* opens:

Figure 28: Add Profile Rule Page

Add Profile Rule

Access Profile Name

Priority

Management Method

☐ Interface ☒ Port ☐ LAG ☐ VLAN

☐ Source IP Address ☒ Network Mask ☐ Prefix Length

Action ☒ Permit

3. Define the *Access Profile Name*, *Priority*, *Management Method*, *Interface*, *Source IP Address*, *Network Mask* or *Prefix Length*, and *Action* fields.
4. Click . The profile rule is added to the access profile, and the device is updated.

To modify a Profile Rule:

1. Click **Security > Management Security > Authentication > Access Profile**. The *Access Profile Page* opens.
2. Click . The *Profile Rule Settings Page* opens:

Figure 29: Profile Rule Settings Page

Profile Rule Settings

Priority	<input type="text" value="7"/>
Management Method	<input type="text" value="Telnet"/>
<input type="checkbox"/> Source IP Address	<input type="text"/>
<input checked="" type="radio"/> Network Mask	<input type="text" value="0.0.0.0"/>
<input checked="" type="radio"/> Prefix Length	<input type="text" value="/0"/>
Action	<input type="text" value="Permit"/>

3. Modify the fields.
4. Click . The profile rule is modified, and the device is updated.

Defining Authentication Profiles

Authentication profiles allow network administrators to assign authentication methods for user authentication. User authentication can be performed locally or on an external server. User authentication occurs in the order the methods are selected. If the first authentication method is not available, the next selected method is used. For example, if the selected authentication methods are RADIUS and Local, and the RADIUS server is not available, then the user is authenticated locally. To define Authentication profiles:

1. Click **System > Management Security > Authentication > Authentication Profiles**. The *Authentication Profile Page* opens.

Figure 30: Authentication Profile Page

The screenshot shows the D-Link web interface for the DES-3010FA/GA switch. The top navigation bar includes 'System', 'Basic Setup', and 'Advanced Setup'. The left sidebar lists various configuration options, with 'Authentication' under 'Management Security' being selected. The main content area displays two tables for defining authentication profiles.

#	Profile Name	Methods	Edit	Remove
1	Console Default	Local		<input type="checkbox"/>
2	Network Default	Local		<input type="checkbox"/>

#	Profile Name	Methods	Edit	Remove
1	Console Default	Local		<input type="checkbox"/>
2	Network Default	Enable		<input type="checkbox"/>

A 'Submit' button is located at the bottom of the main content area.

The *Authentication Profile Page* contains the following fields:

- **Profile Name** — User-defined authentication profile lists to which user-defined authentication profiles are added.
- **Methods** — Defines the user authentication methods. The possible field values are:
 - *None* — Assigns no authentication method to the authentication profile.
 - *Local* — Authenticates the user at the device level. The device checks the user name and password for authentication.
 - *RADIUS* — Authenticates the user at the RADIUS server. For more information, see “Defining RADIUS Settings” on page 75.”
 - *Line* — Authenticates the user using a line password.
 - *Enable* — Authenticates the user using an enable password.

- **Remove** — Removes the selected authentication profile. The possible field values are:
 - *Checked* — Removes the selected authentication profile.
 - *Unchecked* — Maintains the authentication profiles.
2. Click **Create**. The *Add Authentication Profile Page* opens.

Figure 31: Add Authentication Profile Page

Add Authentication Profile

Profile Method ☒ Login ☐ Enable

Profile Name

Authentication Method

Optional Methods		Selected Methods
Line	←	
Enable		
Local	→	
RADIUS		

Submit

3. Define the *Profile Name* and *Authentication Methods* fields.
4. Click **Submit**. The authentication profile is defined, and the device is updated.

To modify an authentication profile:


1. Click **System > Management Security > Authentication > Authentication Profiles**. The *Authentication Profile Page* opens.
2. Click . The *Authentication Profile Settings Page* opens:

Figure 32: Authentication Profile Settings Page

Authentication Profile Settings

Profile Name

Authentication Method	
Optional Methods	Selected Methods
Local	
None	
RADIUS	
Line	

Submit

- 3. Select an authentication method from the *Optional Methods* list.
- 4. Click

Submit

. The authentication method is selected, and the device is updated.

Mapping Authentication Methods

After authentication profiles are defined, they can be applied to management access methods. For example, console users can be authenticated by Authentication Profile List 1, while Telnet users are authenticated by Authentication Method List 2.

Authentication methods are selected using arrows. The order in which the methods are selected is the order by which the authentication methods are used.

To map authentication methods:


1. Click **System > Management Security > Authentication > Authentication Mapping**. The *Authentication Mapping Page* opens.

Figure 33: Authentication Mapping Page

The screenshot shows the D-Link web interface for the Authentication Mapping page. The top header includes the D-Link logo and device status information. The left sidebar has a navigation tree with 'Authentication Mapping' selected. The main content area is divided into sections for different access methods: Console, Telnet, Secure Telnet (SSH), and Secure HTTP. Each section has a dropdown menu for selecting an authentication profile. Below the Secure HTTP and HTTP sections, there are tables for mapping authentication methods. The 'Optional Methods' column lists 'RADIUS' and 'None', and the 'Selected Methods' column lists 'Local'. Arrows indicate the mapping from optional to selected methods. A 'Submit' button is located at the bottom right of the page.

The *Authentication Mapping Page* contains the following fields:

- **Console** — Authentication profiles used to authenticate console users.
- **Telnet** — Authentication profiles used to authenticate Telnet users.
- **Secure Telnet (SSH)** — Authentication profiles used to authenticate Secure Shell (SSH) users. SSH provides clients secure and encrypted remote connections to a device.
- **Secure HTTP** — Authentication methods used for Secure HTTP access. Possible field values are:
 - *None* — No authentication method is used for access.
 - *Local* — Authentication occurs locally.
 - *RADIUS* — Authentication occurs at the RADIUS server.

- *Line* — Authentication using a line password.
 - *Enable* — Authentication using enable.
 - *Local, RADIUS* — Authentication first occurs locally. If authentication cannot be verified locally, the RADIUS server authenticates the management method. If the RADIUS server cannot authenticate the management method, the session is blocked.
 - *RADIUS, Local* — Authentication first occurs at the RADIUS server. If authentication cannot be verified at the RADIUS server, the session is authenticated locally. If the session cannot be authenticated locally, the session is blocked.
 - *Local, RADIUS, None* — Authentication first occurs locally. If authentication cannot be verified locally, the RADIUS server authenticates the management method. If the RADIUS server cannot authenticate the management method, the session is permitted.
 - *RADIUS, Local, None* — Authentication first occurs at the RADIUS server. If authentication cannot be verified at the RADIUS server, the session is authenticated locally. If the session cannot be authenticated locally, the session is permitted.
- **HTTP** — Authentication methods used for HTTP access. Possible field values are:
 - *None* — No authentication method is used for access.
 - *Local* — Authentication occurs locally.
 - *RADIUS* — Authentication occurs at the RADIUS server.
 - *Line* — Authentication using a line password.
 - *Enable* — Authentication using enable.
 - *Local, RADIUS* — Authentication first occurs locally. If authentication cannot be verified locally, the RADIUS server authenticates the management method. If the RADIUS server cannot authenticate the management method, the session is blocked.
 - *RADIUS, Local* — Authentication first occurs at the RADIUS server. If authentication cannot be verified at the RADIUS server, the session is authenticated locally. If the session cannot be authenticated locally, the session is blocked.
 - *Local, RADIUS, None* — Authentication first occurs locally. If authentication cannot be verified locally, the RADIUS server authenticates the management method. If the RADIUS server cannot authenticate the management method, the session is permitted.
 - *RADIUS, Local, None* — Authentication first occurs at the RADIUS server. If authentication cannot be verified at the RADIUS server, the session is authenticated locally. If the session cannot be authenticated locally, the session is permitted.
2. Define the *Console*, *Telnet*, and *Secure Telnet (SSH)* fields.
 3. Map the authentication method in the *Secure HTTP* selection box.
 4. Map the authentication method in the *HTTP* selection box.
 5. Click . The authentication mapping is saved, and the device is updated.

Defining RADIUS Settings

Remote Authorization Dial-In User Service (RADIUS) servers provide additional security for networks. RADIUS servers provide a centralized authentication method for web access.

Default parameters are user-defined, and are applied to newly defined RADIUS servers. If new default parameters are not defined, the system default values are applied to newly defined RADIUS servers.

To configure RADIUS servers:

1. Click **System > Management Security > Authentication > RADIUS**. The *RADIUS Page* opens:

Figure 34: RADIUS Page

D-Link

D-Link DES-3010GA 10/100 Fast Ethernet Switch

Power, Console, DCE 9600, n, 8, 1, 1, 2, 3, 4, 5, 6, 7, 8, Link/Act, Speed, Link/Act, Speed, Link/Act, Speed, Link/Act, Speed

System 10.6.39.150

Basic Setup Advanced Setup Help Logout

General

Description

Time

Reset

SNTP

Syslog

Management Security

Authentication

Access Profiles

Profile Rules

Authentication Profile

Authentication Map

RADIUS

Passwords

File Management

SNMP

Diagnostics

Create

Default Parameters

Default Retries 3

Default Timeout for Reply 3 (Sec)

Default Dead Time 0 (Min)

Default Key String

Source IP Address 0.0.0.0

Submit

#	IP Address	Priority	Authentication Port	Number of Retries	Timeout for Reply	Dead Time	Key String	Source IP Address	Usage Type	Edit	Remove
---	------------	----------	---------------------	-------------------	-------------------	-----------	------------	-------------------	------------	------	--------

The *RADIUS Page* contains the following fields:

- **Retries** — Defines the number of transmitted requests sent to the RADIUS server before a failure occurs. Possible field values are 1-10.
- **Timeout for Reply** — Defines the amount of time (in seconds) the device waits for an answer from the RADIUS server before retrying the query, or switching to the next server. Possible field values are 1-30.
- **Dead Time** — Defines the default amount of time (in minutes) that a RADIUS server is bypassed for service requests. The range is 0-2000.
- **Key String** — Defines the default key string used for authenticating and encrypting all RADIUS-communications between the device and the RADIUS server. This key must match the RADIUS encryption.
- **Source IP Address** — Defines the default IP address of a device accessing the RADIUS server.

The *RADIUS Page* also contains the following fields:



- **IP Address** — Lists the RADIUS server IP addresses.
 - **Priority** — Displays the RADIUS server priority. The possible values are 1-65535, where 1 is the highest value. The RADIUS server priority is used to configure the server query order.
 - **Authentication Port** — Identifies the authentication port. The authentication port is used to verify the RADIUS server authentication. The authenticated port default is 1812.
 - **Number of Retries** — Defines the number of transmitted requests sent to the RADIUS server before a failure occurs. The possible field values are 1-10. Three is the default value.
 - **Timeout for Reply** — Defines the amount of time (in seconds) the device waits for an answer from the RADIUS server before retrying the query, or switching to the next server. The possible field values are 1-30. Three is the default value.
 - **Dead Time** — Defines the amount of time (in minutes) that a RADIUS server is bypassed for service requests. The range is 0-2000. The default is 0 minutes.
 - **Source IP Address** — Defines the source IP address that is used for communication with RADIUS servers.
 - **Usage Type** — Specifies the RADIUS server authentication type. The default value is *All*. The possible field values are:
 - *Log in* — The RADIUS server is used for authenticating user name and passwords.
 - *802.1X* — The RADIUS server is used for 802.1X authentication.
 - *All* — The RADIUS server is used for authenticating user names and passwords, and 802.1X port authentication.
 - **Remove** — Removes a RADIUS server. The possible field values are:
 - *Checked* — Removes the selected RADIUS server.
 - *Unchecked* — Maintains the RADIUS servers.
2. Click . The *Add Radius Server Page* opens:

Figure 35: Add Radius Server Page

Add RADIUS Server		
Host IP Address	<input type="text"/>	
Priority	<input type="text" value="0"/>	
Authentication Port	<input type="text" value="1812"/>	
Number of Retries	<input type="text" value="Default"/>	<input checked="" type="checkbox"/> Use Default
Timeout for Reply	<input type="text" value="Default"/> (Sec)	<input checked="" type="checkbox"/> Use Default
Dead Time	<input type="text" value="Default"/> (Min)	<input checked="" type="checkbox"/> Use Default
Key String	<input type="text"/> (Alpha Numeric)	<input type="checkbox"/> Use Default
Source IP Address	<input type="text" value="Default"/>	<input checked="" type="checkbox"/> Use Default
Usage Type	<input type="text" value="All"/>	

3. Define the *Host IP Address*, *Priority*, *Authenticated Port*, *Timeout for Reply*, *Dead Time*, and *Usage Type* fields.
4. Click . The RADIUS server is added, and the device is updated.

To edit RADIUS Server Settings:


1. Click **System > Management Security > Authentication > Radius**. The *RADIUS Page* opens.
2. Click . The *RADIUS Server Settings Page* opens:

Figure 36: RADIUS Server Settings Page

RADIUS Server Settings

IP Address	<input type="text" value="10.6.39.151"/>	
Priority	<input type="text" value="0"/>	
Authentication Port	<input type="text" value="1812"/>	
Number of Retries	<input type="text" value="Default"/>	<input checked="" type="checkbox"/> Use Default
Timeout for Reply	<input type="text" value="Default"/> (Sec)	<input checked="" type="checkbox"/> Use Default
Dead Time	<input type="text" value="Default"/> (Min)	<input checked="" type="checkbox"/> Use Default
Key String	<input type="text"/> (Alpha Numeric)	<input type="checkbox"/> Use Default
Source IP Address	<input type="text" value="Default"/> (X.X.X.X)	<input checked="" type="checkbox"/> Use Default
Usage Type	<input type="text" value="All"/>	

3. Define the *Priority*, *Source IP Address*, *Key String*, *Authentication Port*, *Timeout for Reply*, *Dead Time*, and *Usage Type* fields.
4. Click . The RADIUS server settings are saved, and the device is updated.

Configuring Passwords

This section contains information for defining device passwords, and includes the following topics.


- Defining Local Users
- Defining Line Passwords
- Defining Enable Passwords

Defining Local Users

Network administrators can define users, passwords, and access levels for users using the *Local User Page*. To define local users:

1. Click **System > Management Security > Passwords > Local Users**. The *Local User Page* opens:

Figure 37: Local User Page



The *Local User Page* contains the following fields:

- **User Name** — Displays the user name.
- **Access Level** — Displays the user access level. The lowest user access level is 1 and the highest is 15. Users with access level 15 are Privileged Users, and only they can access and use the OpenManage Switch Administrator.
- **Lockout Status**— Displays the user access status.
- **Remove** — Removes the user from the **User Name** list. The possible field values are:
 - *Checked* — Removes the selected local user.

- *Unchecked* — Maintains the local users.

2. Click **Create**. The *Add Local User Page* opens:

Figure 38: Add Local User Page

The screenshot shows a web page titled "Add Local User" in blue text. Below the title is a form with four rows of input fields. The first row is "User Name" with a text input field. The second row is "Access Level" with a dropdown menu showing the number "1". The third row is "Password" with a text input field. The fourth row is "Confirm Password" with a text input field. Below the form is a blue "Submit" button.

In addition to the fields in the *Local User Page*, the *Add Local User Page* contains the following fields:

- **Password** — Defines the local user password. Local user passwords can contain up to 159 characters.
- **Confirm Password** — Verifies the password.

Defining Line Passwords

Network administrators can define line passwords in the *Line Password Page*. After the line password is defined, a management method is assigned to the password. The device can be accessed using the following methods:

- Console
- Telnet
- Secure Telnet

To define line passwords:

1. Click **System > Management Security > Passwords > Line Password**. The *Line Password Page* opens:

Figure 39: Line Password Page

	Password	Confirm Password
Console Line Password	*****	*****
Telnet Line Password	*****	*****
Secure Telnet Line Password	*****	*****

Submit

The *Line Password Page* contains the following fields:

- **Console Line Password** — Defines the line password for accessing the device via a Console session. Passwords can contain a maximum of 159 characters.
 - **Telnet Line Password** — Defines the line password for accessing the device via a Telnet session. Passwords can contain a maximum of 159 characters.
 - **Secure Telnet Line Password** — Defines the line password for accessing the device via a secure Telnet session. Passwords can contain a maximum of 159 characters.
 - **Confirm Password** — Confirms the new line password. The password appears in the ***** format.
2. Define the *Console Line Password*, *Telnet Line Password*, and *Secure Telnet Line Password* fields.
 3. Redefine the *Confirm Password* field for each of the passwords defined in the previous steps to verify the passwords.
 4. Click **Submit**. The line passwords are saved, and the device is updated.

Defining Enable Passwords

The *Enable Password Page* sets a local password for a particular access level. To enable passwords:

1. Click **System > Management Security > Passwords > Enable Password**. The *Enable Password Page* opens:

Figure 40: Enable Password Page

The Enable Password Page contains the following fields:

The screenshot shows the D-Link web interface for the DES-3010FA/GA switch. The top status bar displays device details like 'D-Link DES-3010GA', '10/100 Fast Ethernet Switch', and various port status indicators. The left sidebar shows a navigation menu with 'System' selected, and 'Management Security > Passwords > Enable Password' highlighted. The main content area, under the 'Basic Setup' tab, contains the 'Enable Password' configuration fields: 'Level' (set to 1), 'Password' (masked with dots), and 'Confirm Password' (masked with dots). A 'Submit' button is positioned below the password fields.

- **Level** — Defines the access level associated with the enable password. Possible field values are 1-15.
 - **Password** — Defines the enable password.
 - **Confirm Password** — Confirms the new enable password. The password appears in the ***** format.
2. Define the *Select Enable Access Level*, *Password*, and *Confirm Password* fields.
 3. Click **Submit**. The enable password is defined, and the device is updated.

Configuring Network Security

Network security manages both access control lists and locked ports. This section contains the following topics:

- Network Security Overview
- Defining Network Authentication Properties
- Defining Port Authentication
- Configuring Traffic Control

Network Security Overview

This section provides an overview of network security and contains the following topics:

- Port-Based Authentication
- Advanced Port-Based Authentication

Port-Based Authentication

Port-based authentication authenticates users on a per-port basis via an external server. Only authenticated and approved system users can transmit and receive data. Ports are authenticated via the RADIUS server using the Extensible Authentication Protocol (EAP). Port-based authentication includes:

- **Authenticators** — Specifies the device port which is authenticated before permitting system access.
- **Supplicants** — Specifies the host connected to the authenticated port requesting to access the system services.
- **Authentication Server** — Specifies the server that performs the authentication on behalf of the authenticator, and indicates whether the supplicant is authorized to access system services.

Port-based authentication creates two access states:

- **Controlled Access** — Permits communication between the supplicant and the system, if the supplicant is authorized.
- **Uncontrolled Access** — Permits uncontrolled communication regardless of the port state.

The device currently supports port-based authentication via RADIUS servers.

Advanced Port-Based Authentication

Advanced port-based authentication enables multiple hosts to be attached to a single port. Advanced port-based authentication requires only one host to be authorized for all hosts to have system access. If the port is unauthorized, all attached hosts are denied access to the network.

Advanced port-based authentication also enables user-based authentication. Specific VLANs in the device are always available, even if specific ports attached to the VLAN are unauthorized. For example, Voice over IP does not require authentication, while data traffic requires authentication. VLANs for which authorization is not required can be defined. Unauthenticated VLANs are available to users, even if the ports attached to the VLAN are defined as authorized.

Advanced port-based authentication is implemented in the following modes:

- **Single Host Mode** — Only the authorized host can access the port.
- **Multiple Host Mode** — Multiple hosts can be attached to a single port. Only one host must be authorized for all hosts to access the network. If the host authentication fails, or an EAPOL-logoff message is received, all attached clients are denied access to the network.

- **Guest VLANs** — Provides limited network access to authorized ports. If a port is denied network access via port-based authorization, but the Guest VLAN is enabled, the port receives limited network access. For example, a network administrator can use Guest VLANs to deny network access via port-based authentication, but grant Internet access to unauthorized users.
- **Unauthenticated VLANs** — Are available to users, even if the ports attached to the VLAN are defined as unauthorized.

Defining Network Authentication Properties

The *Network Authentication Properties Page* allows network managers to configure network authentication parameters. In addition, Guest VLANs are enabled from the *Network Authentication Properties Page*. To define the network authentication properties:

1. Click **Advanced Setup > Network Security > Authentication > Properties**. The *Network Authentication Properties Page* opens.

Figure 41: Network Authentication Properties Page


The screenshot shows the D-Link web interface for the DES-3010GA switch. The top navigation bar includes 'System', 'Basic Setup', 'Advanced Setup', 'Help', and 'Logout'. The left sidebar shows a tree structure with 'Advanced Setup' expanded, and 'Network Security > Authentication > Properties' selected. The main configuration area contains the following fields:

Port Based Authentication State	Disable
Authentication Method	RADIUS
Guest VLAN	Disable
VLAN List	

A 'Submit' button is located at the bottom right of the configuration area.

The *Network Authentication Properties Page* contains the following fields:

- **Port-based Authentication State** — Enables and disables port-based authentication on the device. The possible field values are:
 - *Enable* — Enables port-based authentication on the device.
 - *Disable* — Disables port-based authentication on the device.

- **Authentication Method** — Specifies the authentication method used. The possible field values are:
 - *None* — No authentication method is used to authenticate the port.
 - *RADIUS* — Port authentication is performed via RADIUS server.
 - *RADIUS, None* — Port authentication is performed first via the RADIUS server. If the port is not authenticated, then no authentication method is used, and the session is permitted.
 - **Guest VLAN** — Specifies whether the Guest VLAN is enabled on the device. The possible field values are:
 - *Enable* — Enables using a Guest VLAN for unauthorized ports. If a Guest VLAN is enabled, the unauthorized port automatically joins the VLAN selected in the *VLAN List* field.
 - *Disable* — Disables port-based authentication on the device. This is the default.
 - **VLAN List** — Contains a list of VLANs. The Guest VLAN is selected from the VLAN list.
2. Define the Port-based *Authentication State*, *Authentication Method*, *Guest VLAN*, and *VLAN List* fields.
 3. Click . The network authentication properties are set, and the device is updated.

Defining Port Authentication

The *Port Authentication Page* allows network managers to configure port-based authentication global parameters. To define the port-based authentication global properties:

1. Click **Advanced Setup > Network Security > Authentication > Port Authentication**. The *Port Authentication Page* opens.

Figure 42: Port Authentication Page

The screenshot shows the D-Link web interface for the DES-3010FA/GA switch. The 'Advanced Setup' tab is selected, and the 'Port Authentication' page is displayed. The page includes a navigation tree on the left with options like System, Basic Setup, and Advanced Setup. The main content area features a table for configuring port authentication. At the top of the table is a 'Copy from Entry Number' field. The table has 13 columns: #, Port, User Name, Admin Port Control, Current Port Control, Enable Periodic Reauthentication, Reauthentication Period, Authenticator State, Quiet Period, Resending EAP, Max EAP Requests, Supplicant Timeout, Server Timeout, and Termination Cause. The table contains 10 rows of data for ports 1 through 10. A 'Submit' button is located at the bottom of the table.

#	Port	User Name	Admin Port Control	Current Port Control	Enable Periodic Reauthentication	Reauthentication Period	Authenticator State	Quiet Period	Resending EAP	Max EAP Requests	Supplicant Timeout	Server Timeout	Termination Cause
1	1		*	*	False	3600	Initialize	60	30	2	30	30	Port re-initialize
2	2		*	*	False	3600	Initialize	60	30	2	30	30	Port re-initialize
3	3		Force Authorized	*	False	3600	Force Authorized	60	30	2	30	30	Not terminated yet
4	4		*	*	False	3600	Initialize	60	30	2	30	30	Port re-initialize
5	5		*	*	False	3600	Initialize	60	30	2	30	30	Port re-initialize
6	6		*	*	False	3600	Initialize	60	30	2	30	30	Port re-initialize
7	7		*	*	False	3600	Initialize	60	30	2	30	30	Port re-initialize
8	8		*	*	False	3600	Initialize	60	30	2	30	30	Port re-initialize
9	9		*	*	False	3600	Initialize	60	30	2	30	30	Port re-initialize
10	10		*	*	False	3600	Initialize	60	30	2	30	30	Port re-initialize

The *Port Authentication Page* contains the following fields:

- **Copy from Entry Number** — The port from which authentication information is copied.
- **to Row Number(s)** — The port to which the port authentication information is copied.
- **Port** — A list of interfaces on which port-based authentication is enabled.
- **User Name** — Displays the supplicant user name.
- **Admin Port Control** — Displays the current port authorization state. The possible field values are:
 - *Auto* — Port-based authentication is enabled on the device. The interface moves between an authorized or unauthorized state based on the authentication exchange between the device and the client.
 - *Authorized* — The interface is in an authorized state without being authenticated. The interface re-sends and receives normal traffic without client port-based authentication.
 - *Unauthorized* — Denies the selected interface system access by moving the interface into unauthorized state. The device cannot provide authentication services to the client through the interface.
- **Current Port Control** — Displays the current port authorization state.



- **Enable Periodic Reauthentication** — Permits immediate port reauthentication. The possible field values are:
 - *Enable* — Immediate port reauthentication is enabled. This is the default value.
 - *Disable* — Immediate port reauthentication is disabled.
 - **Reauthentication Period** — Displays the time span (in seconds) in which the selected port is reauthenticated. The field default is 3600 seconds.
 - **Reauthenticate Now** — Reauthenticates the selected ports immediately. Select All selects all ports for reauthentication.
 - **Authenticator State** — Displays the current authenticator state.
 - **Quiet Period** — Displays the number of seconds that the device remains in the quiet state following a failed authentication exchange. The possible field range is 0-65535. The field default is 60 seconds.
 - **Resending EAP** — Defines the amount of time (in seconds) that lapses before EAP requests are resent. The field default is 30 seconds.
 - **Max EAP Requests** — Displays the total amount of EAP requests sent. If a response is not received after the defined period, the authentication process is restarted. The field default is 2 retries.
 - **Supplicant Timeout** — Displays the amount of time (in seconds) that lapses before EAP requests are resent to the supplicant. The field default is 30 seconds.
 - **Server Timeout** — Displays the amount of time (in seconds) that lapses before the device re-sends a request to the authentication server. The field default is 30 seconds.
 - **Termination Cause** — Indicates the reason for which the port authentication was terminated.
2. Click  . The *Port Authentication Settings Page* opens:

Figure 43: Port Authentication Settings Page

Port Authentication Settings



Port	3 ▼
User Name	
Admin Port Control	forceAuthorized ▼
Guest VLAN ID	None ▼
Make Guest VLAN	Disable ▼
Enable Periodic Reauthentication	<input type="checkbox"/>
Reauthentication Period	3600
Reauthenticate Now	<input type="checkbox"/>
Authenticator State	Force Authorized
Quiet Period	60
Resending EAP	30
Max EAP Requests	2
Supplicant Timeout	30
Server Timeout	30
Termination Cause	Not terminated yet


3. Modify the *Admin Port Control*, *Enable Periodic Reauthentication*, *Quiet Period*, *Resending EAP*, *Supplicant Timeout*, and *Server Timeout* fields.
4. Click . The port authentication settings are defined, and the device is updated.

Configuring Multiple Hosts

The *Multiple Host Page* allows network managers to configure advanced port-based authentication settings for specific ports and VLANs. For more information on advanced port-based authentication, see “*Advanced Port-Based Authentication*” on page 83. To define the network authentication global properties:

1. Click **Advanced Setup > Network Security > Authentication > Multiple Host**. The *Multiple Host Page* opens.

Figure 44: Multiple Host Page




The *Multiple Host Page* contains the following fields:

- **Port** — Displays the port number for which advanced port-based authentication is enabled.
- **Multiple Hosts** — Indicates whether multiple hosts are enabled. Multiple hosts must be enabled in order to either disable the ingress-filter, or to use port-lock security on the selected port. The possible field values are:
 - *Multiple* — Multiple hosts are enabled.
 - *Disable* — Multiple hosts are disabled.
- **Action on Violation** — Defines the action to be applied to packets arriving in single-host mode, from a host whose MAC address is not the supplicant MAC address. The possible field values are:
 - *Forward* — Forwards the packet.
 - *Discard* — Discards the packets. This is the default value.
 - *Shutdown* — Discards the packets and shuts down the port. The ports remains shut down until reactivated, or until the device is reset.

- **Traps** — Indicates if traps are enabled for Multiple Hosts. The possible field values are:
 - *True* — Indicates that traps are enabled for Multiple hosts.
 - *False* — Indicates that traps are disabled for Multiple hosts.
- **Trap Frequency** — Defines the time period by which traps are sent to the host. The Trap Frequency (1-1000000) field can be defined only if multiple hosts are disabled. The default is 10 seconds.
- **Status** — Indicates the host status. If there is an asterisk (*), the port is either not linked or is down. The possible field values are:
 - *Unauthorized* — Indicates that either the port control is Force Unauthorized and the port link is down, or the port control is Auto but a client has not been authenticated via the port.
 - *Not in Auto Mode* — Indicates that the port control is Forced Authorized, and clients have full port access.
 - *Single-host Lock* — Indicates that the port control is Auto and a single client has been authenticated via the port.
 - *No Single Host* — Indicates that Multiple Host is enabled.
- **Number of Violations** — Indicates the number of packets that arrived on the interface in single-host mode, from a host whose MAC address is not the supplicant MAC address.


2. Click . The *Multiple Host Settings Page* opens:

Figure 45: Multiple Host Settings Page



Port	1
Enable Multiple Hosts	<input checked="" type="checkbox"/>
Action on Violation	discard
Enable Traps	<input type="checkbox"/>
Trap Frequency	10

Submit


3. Modify the *Port*, *Enable Multiple Hosts*, *Action on Violation*, *Enable Traps*, and *Trap Frequency* fields.
4. Click . The multiple host settings are modified, and the device is updated.

Defining Authentication Hosts

The *Authenticated Host Page* contains a list of authenticated users. To define authenticated users:

1. Click **Advanced Setup > Network Security > Authentication > Authenticated Host**. The *Authenticated Host Page* opens:

Figure 46: Authenticated Host Page



The *Authenticated Host Page* contains the following fields:

- **User Name** — Lists the supplicants that were authenticated, and are permitted on each port.
- **Port** — Displays the port number.
- **Session Time** — Displays the amount of time (in seconds) the supplicant was logged on the port.
- **Authentication Method** — Displays the method by which the last session was authenticated. The possible field values are:
 - *Remote* — 802.1x authentication is not used on this port (port is forced-authorized).
 - *None* — The supplicant was not authenticated.
 - *RADIUS* — The supplicant was authenticated by a RADIUS server.
- **MAC Address** — Displays the supplicant MAC address.

Configuring Traffic Control

This section contains information for managing both port security and storm control, and includes the following topics:

- Managing Port Security
- Enabling Storm Control

Managing Port Security

Network security can be increased by limiting access on a specific port only to users with specific MAC addresses. The MAC addresses can be dynamically learned or statically configured. Locked port security monitors both received and learned packets that are received on specific ports. Access to the locked port is limited to users with specific MAC addresses. These addresses are either manually defined on the port, or learned on that port up to the point when it is locked. When a packet is received on a locked port, and the packet D-Link source MAC address is not tied to that port (either it was learned on a different port, or it is unknown to the system), the protection mechanism is invoked, and can provide various options. Unauthorized packets arriving at a locked port are either:


- Forwarded
- Discarded with no trap
- Discarded with a trap
- The port is shut down

Locked port security also enables storing a list of MAC addresses in the configuration file. The MAC address list can be restored after the device has been reset.

Disabled ports are activated from the *Port Security Page*. To define port security:

1. Click **Advanced Setup > Network Security > Traffic Control > Port Security**. The *Port Security Page* opens.

Figure 47: Port Security Page




The *Port Security Page* contains the following fields:

- **Interface** — The port or LAG name.
- **Interface Status** — Indicates the host status. The possible field values are:
 - *Unauthorized* — Indicates that the port control is Force Unauthorized, the port link is down or the port control is Auto, but a client has not been authenticated via the port.
 - *Not in Auto Mode* — Indicates that the port control is Forced Authorized, and clients have full port access.
 - *Single-host Lock* — Indicates that the port control is Auto and a single client has been authenticated via the port.
- **Learning Mode** — Defines the locked port type. The Learning Mode field is enabled only if Locked is selected in the Set Port field. The possible field values are:
 - *Classic Lock* — Locks the port using the classic lock mechanism. The port is immediately locked, regardless of the number of addresses that have already been learned.
 - *Limited Dynamic Lock* — Locks the port by deleting the current dynamic MAC addresses associated with the port. The port learns up to the maximum addresses allowed on the port. Both relearning and aging MAC addresses are enabled.
- **Max Entries** — Specifies the number of MAC address that can be learned on the port. The Max Entries field is enabled only if Locked is selected in the Set Port field. In addition, the Limited Dynamic Lock mode is selected. The default is 1.

- **Action** — The action to be applied to packets arriving on a locked port. The possible field values are:
 - *Forward* — Forwards packets from an unknown source without learning the MAC address.
 - *Discard* — Discards packets from any unlearned source. This is the default value.
 - *Shutdown* — Discards packets from any unlearned source and shuts down the port. The port remains shut down until reactivated, or until the device is reset.
- **Trap** — Enables traps when a packet is received on a locked port. The possible field values are:
 - Checked — Enables traps.
 - Unchecked — Disables traps.
- **Trap Frequency (Sec)** — The amount of time (in seconds) between traps. The default value is 10 seconds.

2. Click . The *Port Security Settings Page* opens:


Figure 48: Port Security Settings Page



The screenshot shows the 'Interface Table Settings' page. It contains a table with the following fields and values:

Interface	Port 1	LAG
Lock Interface	<input type="checkbox"/>	<input type="checkbox"/>
Learning Mode	Classic Lock	
Max Entries	1	
Action on Violation	discard	
Enable Trap	<input type="checkbox"/>	
Trap Frequency	10	

Below the table is a 'Submit' button.

3. Modify the *Interface*, *Lock Interface*, *Action on Violation*, *Enable Trap*, *Port Status*, and *Trap Frequency* fields.
4. Click . The port security settings are defined, and the device is updated.

Enabling Storm Control

Storm control limits the amount of Multicast and Broadcast frames accepted and forwarded by the device. When Layer 2 frames are forwarded, Broadcast and Multicast frames are flooded to all ports on the relevant VLAN. This occupies bandwidth, and loads all nodes on all ports.

A Broadcast Storm is a result of an excessive amount of broadcast messages simultaneously transmitted across a network by a single port. Forwarded message responses are heaped onto the network, straining network resources or causing the network to time out.

Storm control is enabled for all Gigabit ports by defining the packet type and the rate the packets are transmitted. The system measures the incoming Broadcast and Multicast frame rates separately on each port, and discards the frames when the rate exceeds a user-defined rate.

The *Storm Control Page* provides fields for configuring broadcast storm control. To enable storm control:

1. Click **Advanced Setup > Network Security > Traffic Control > Storm Control**. The *Storm Control Page* opens.

Figure 49: Storm Control Page

D-Link DES-30100A 10/100 Fast Ethernet Switch

System Basic Setup **Advanced Setup** Help Logout

10.6.39.150

- Interface
 - LACP Parameters
 - LAG Membership
- Forwarding Database
- Network Security
 - Authentication
 - Properties
 - Port Authentication
 - Multiple Host
 - Authenticated Host
 - Traffic Control
 - Port Security
 - Storm Control**
- Spanning Tree
- Multicast Support
- Interface Statistics
- RMON

Copy from Entry Number to Entry Number(s)

Port	Enable Broadcast Control	Broadcast Mode	Broadcast Rate Threshold	Edit
1	Disabled	Broadcast Only	100	
2	Disabled	Broadcast Only	100	
3	Disabled	Broadcast Only	100	
4	Disabled	Broadcast Only	100	
5	Disabled	Broadcast Only	100	
6	Disabled	Broadcast Only	100	
7	Disabled	Broadcast Only	100	
8	Disabled	Broadcast Only	100	
9	Disabled	Broadcast Only	100	
10	Disabled	Broadcast Only	100	

The *Storm Control Page* contains the following fields:

- **Port** — Indicates the port from which storm control is enabled. The possible field values are:
 - *Enable* — Enables storm control on the selected port.
 - *Disable* — Disables storm control on the selected port.
- **Enable Broadcast Control** — Indicates if forwarding Broadcast packet types on the interface.



- **Broadcast Mode** — Specifies the Broadcast mode currently enabled on the device. The possible field values are:
 - *Unknown Unicast, Multicast & Broadcast* — Counts Unicast, Multicast, and Broadcast traffic.
 - *Multicast & Broadcast* — Counts Broadcast and Multicast traffic together.
 - *Broadcast Only* — Counts only Broadcast traffic.
 - **Broadcast Rate Threshold** — The maximum rate (kilobytes per second) at which unknown packets are forwarded. The range is 0-1,000,000. The default value is zero. All values are rounded to the nearest 64Kbps. If the field value is under 64Kbps, the value is rounded up to 64Kbps, with the exception of the value zero.
2. Click . The *Storm Control Settings Page* opens:


Figure 50: Storm Control Settings Page



Storm Control Settings

Port	1
Enable Broadcast Control	<input type="checkbox"/>
Broadcast Mode	Broadcast Only
Broadcast Rate Threshold	100

Submit


3. Modify the *Port*, *Enable Broadcast Control*, *Broadcast Mode*, and *Broadcast Rate Threshold* fields.
4. Click . Storm control is enabled on the device.

Section 7. Configuring Ports

The *Interface Configuration Page* contains fields for defining port parameters. To define port parameters:

1. Click **Basic Setup > Interface > Interface Configuration**. The *Interface Configuration Page* opens.

Figure 51: Interface Configuration Page



The *Interface Configuration Page* is divided into the following sections:

- Interface Configuration ports table
- Interface Configuration LAG table

The Interface Configuration ports table contains the following fields:

- **Interface** — Displays the port number.
- **Port Status** — Indicates whether the port is currently operational or non-operational. The possible field values are:
 - *Up* — Indicates the port is currently operating.
 - *Down* — Indicates the port is currently not operating.
- **Port Speed** — Displays the configured rate for the port. The port type determines what speed setting options are available. Port speeds can only be configured when auto negotiation is disabled. The possible field values are:
 - *10* — Indicates the port is currently operating at 10 Mbps.

- 100 — Indicates the port is currently operating at 100 Mbps.
 - 1000 — Indicates the port is currently operating at 1000 Mbps.
- **Duplex Mode** — Displays the port duplex mode. This field is configurable only when auto negotiation is disabled, and the port speed is set to 10M or 100M. This field cannot be configured on LAGs. The possible field values are:
 - *Full* — The interface supports transmission between the device and its link partner in both directions simultaneously.
 - *Half* — The interface supports transmission between the device and the client in only one direction at a time.
- **Auto Negotiation** — Displays the auto negotiation status on the port. Auto negotiation is a protocol between two link partners that enables a port to advertise its transmission rate, duplex mode, and flow control abilities to its partner.
- **Advertisement** — Defines the auto negotiation setting the port advertises. The possible field values are:
 - *Max Capability* — Indicates that all port speeds and duplex mode settings are accepted.
 - *10 Half* — Indicates that the port advertises for a 10 Mbps speed port and half duplex mode setting.
 - *10 Full* — Indicates that the port advertises for a 10 Mbps speed port and full duplex mode setting.
 - *100 Half* — Indicates that the port advertises for a 100 Mbps speed port and half duplex mode setting.
 - *100 Full* — Indicates that the port advertises for a 100 Mbps speed port and full duplex mode setting.
- **Back Pressure** — Displays the back pressure mode on the Port. Back pressure mode is used with half duplex mode to disable ports from receiving messages.
- **Flow Control** — Displays the flow control status on the port. Operates when the port is in full duplex mode.
- **MDI/MDIX** — Displays the MDI/MDIX status on the port. Hubs and switches are deliberately wired opposite the way end stations are wired, so that when a hub or switch is connected to an end station, a straight through Ethernet cable can be used, and the pairs are matched up properly. When two hubs or switches are connected to each other, or two end stations are connected to each other, a crossover cable is used to ensure that the correct pairs are connected. The possible field values are:
 - *Auto* — Use to automatically detect the cable type.
 - *MDI (Media Dependent Interface)* — Use for end stations.
 - *MDIX (Media Dependent Interface with Crossover)* — Use for hubs and switches.
- **LAG** — Indicates whether the port is part of a Link Aggregation (LAG).

The Interface Configuration LAG table contains the following fields:

- **LAG** — Indicates whether the port is part of a Link Aggregation (LAG).
- **LAG Type** — Indicates the type of LAG defined by the first port assigned to the LAG. For example, 100-Copper, or 100-Fiber.
- **LAG Status** — Indicates whether the LAG is up or down.
- **LAG Speed** — Displays the configured aggregated rate for the LAG. The possible field values are:
 - 10 — Indicates the port is currently operating at 10 Mbps.
 - 100 — Indicates the port is currently operating at 100 Mbps.
 - 1000 — Indicates the port is currently operating at 1000 Mbps.
- **Auto Negotiation** — Displays the auto negotiation status of the LAG. Auto negotiation is a protocol between two link partners that enables a port to advertise its transmission rate, duplex mode, and flow control abilities to its partner.
- **Back Pressure** — Displays the back pressure mode on the LAG. Back pressure mode is used with half duplex mode to disable ports in the LAG from receiving messages.
- **Flow Control** — Displays the flow control status of the LAG.

2. Click  . The *Port or LAG Interface Settings Page* opens:



Note

In addition to the fields in the *Interface Configuration Page*, the *Port or LAG Configuration Settings Page* includes the field **Reactivate Suspended Port** or **Reactivate Suspended Lag**. Select this field to return a suspended port or LAG to active status.

Figure 52: Port Configuration Settings Page

Port Configuration Settings

Port

1

Admin Status

Up

Current Port Status

Down

Reactivate Suspended Port

☐

Operational Status

Active

Admin Speed

100M

Current Port Speed

Admin Duplex

Full

Current Duplex Mode

Auto Negotiation

Enable

Current Auto Negotiation

Admin Advertisement

☒ Max Capability ☐ 10 Half ☐ 10 Full ☐ 100 Half ☐ 100 Full ☐ 1000 Full

Current Advertisement

Unknown

Neighbor Advertisement

Unknown

Back Pressure

Disable

Current Back Pressure

Flow Control

Disable

Current Flow Control


MDI/MDIX

AUTO

Current MDI/MDIX

LAG

Submit


3. Modify the *Admin Speed*, *Admin Duplex*, and *Admin Advertisement* fields.
4. Click  . The parameters are saved, and the device is updated.

Viewing Port Properties

The *Interface Properties Page* contains fields for defining port parameters. To define port parameters:

1. Click **Basic Setup > Interface > Interface Properties**. The *Interface Configuration Page* opens.

Figure 53: Interface Properties Page




The *Interface Properties Page* contains the following fields:

- **Interface** — Displays the port number.
- **Port Type** — Displays the port type. The possible field values are:
 - Copper — Indicates the port has a copper port connection.
 - Fiber — Indicates the port has a fiber optic port connection.
- **Description** - Provides a user-defined port description

To edit the port properties:

1. Click **Basic Setup > Interface > Interface Properties**. The *Interface Configuration Page* opens.
2. Click . The *Interface Properties Page* opens

Figure 54: Interface Properties Page



Port Properties

Port	1
Description	
Port Type	100M-copper

Submit

3. Define the fields.
4. Click **Submit**. The interface properties are modified, and the device is updated.

Section 8. Aggregating Ports

Link Aggregation optimizes port usage by linking a group of ports together to form a single LAG (aggregated group). Aggregating ports multiplies the bandwidth between the devices, increases port flexibility, and provides link redundancy.

The device supports both static LAGs and Link Aggregation Control Protocol (LACP) LAGs. LACP LAGs negotiate aggregating ports' links with other LACP ports located on a different device. If the other device ports are also LACP ports, the devices establish a LAG between them.

- Consider the following when aggregating ports:
- All ports within a LAG must be the same media type.
- A VLAN is not configured on the port.
- The port is not assigned to a different LAG.
- Auto-negotiation mode is not configured on the port.
- The port is in full-duplex mode.
- All ports in the LAG have the same ingress filtering and tagged modes.
- All ports in the LAG have the same back pressure and flow control modes.
- All ports in the LAG have the same priority.
- All ports in the LAG have the same transceiver type.
- The device supports up to eight LAGs, and eight ports in each LAG.
- Ports can be configured as LACP ports only if the ports are not part of a previously configured LAG.
- Ports added to a LAG lose their individual port configuration. When ports are removed from the LAG, the original port configuration is applied to the ports.

The device uses a hash function to determine which packets are carried on which aggregated-link member. The hash function statistically load-balances the aggregated link members. The device considers an Aggregated Link a single logical port. This section contains the following topics:

- Aggregating Ports
- Configuring LACP

Aggregating Ports


Link Aggregated Groups optimize port usage by linking a group of ports together to form a single aggregated group. Link aggregated groups multiply the bandwidth between the devices, increase port flexibility, and provide link redundancy.

The *LAG Membership Page* contains fields for configuring parameters for configured LAGs. The device supports up to eight ports per LAG, and eight LAGs per system.

To define LAG parameters:

1. Click **Advanced Setup > Interface > LAG Membership**. The *LAG Membership Page* opens.

Figure 55: LAG Membership Page



The *LAG Membership Page* contains the following fields:

- **LAG Port** — Displays the LAG number.
- **Name** — Displays the user-defined port name.
- **Link State** — Displays the link operational status.
- **Member** — Displays the ports configured to the LAG.
- **Remove** — Removes the LAG. The possible field values:
 - *Checked* — Removes the selected LAG.
 - *Unchecked* — Maintains the LAGs.

2. Click . The *LAG Membership Settings Page* opens:

Figure 56: LAG Membership Settings Page

LAG Membership Settings

LAG Port

1

LAG Name

Port	1	2	3	4	5	6	7	8	9	10
	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
LACP	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Submit

- 3. Define the *Port* and *LACP* fields.
- 4. Click

Submit

. The LAG membership settings are saved, and the device is updated.


Configuring LACP

Aggregate ports can be linked into link-aggregation port-groups. Each group is comprised of ports with the same speed, set to full-duplex operations.

LAG ports can contain different media types if the ports are operating at the same speed. Aggregated links can be set up manually or automatically established by enabling Link Aggregation Control Protocol (LACP) on the relevant links. Aggregate ports can be linked into link-aggregation port-groups. Each group is comprised of ports with the same speed. The *LACP Parameters Page* contains fields for configuring LACP LAGs. To configure LACP for LAGs:

1. Click **Advanced Setup > Interface > LACP Parameters** tab. The *LACP Parameters Page* opens.

Figure 57: LACP Parameters Page




The *LACP Parameters Page* contains the following fields:

- **Port** — Displays the port number to which timeout and priority values are assigned.
- **Port-Priority** — Displays the LACP priority value for the port. The field range is 1-65535.
- **LACP Timeout** — Displays the administrative LACP timeout.

2. Click . The *LACP Parameters Settings Page* opens:

Figure 58: LACP Parameters Settings Page



LACP Parameters Settings

Port	1 ▾
LACP Port Priority	1
LACP Timeout	Long ▾
<input type="button" value="Submit"/>	

3. Edit the *Port Priority* and *LACP Timeout* fields.
4. Click . The LACP settings are saved, and the device is updated

Section 9. Configuring VLANs

VLANs are logical subgroups with a Local Area Network (LAN) which combine user stations and network devices into a single unit, regardless of the physical LAN segment to which they are attached. VLANs allow network traffic to flow more efficiently within subgroups. VLANs use software to reduce the amount of time it takes for network changes, additions, and moves to be implemented.

VLANs have no minimum number of ports, and can be created per unit, per device, or through any other logical connection combination, since they are software-based and not defined by physical attributes.

VLANs function at Layer 2. Since VLANs isolate traffic within the VLAN, a Layer 3 router working at a protocol level is required to allow traffic flow between VLANs. Layer 3 routers identify segments and coordinate with VLANs. VLANs are Broadcast and Multicast domains. Broadcast and Multicast traffic is transmitted only in the VLAN in which the traffic is generated.

VLAN tagging provides a method of transferring VLAN information between VLAN groups. VLAN tagging attaches a 4-byte tag to packet headers. The VLAN tag indicates to which VLAN the packets belong. VLAN tags are attached to the VLAN by either the end station or the network device. VLAN tags also contain VLAN network priority information.

Combining VLANs and GARP (Generic Attribute Registration Protocol) allows network managers to define network nodes into Broadcast domains.

This section contains the following topics:


- Defining VLAN Properties
- Defining VLAN Membership
- Defining VLAN Interface Settings
- Defining Private VLANs
- Configuring GARP

Defining VLAN Properties

The *VLAN Membership Properties* page provides information and global parameters for configuring and working with VLANs. To define VLAN properties:

1. Click **Basic Setup > VLAN > Membership > Properties**. The *VLAN Properties Page* opens.

Figure 59: VLAN Properties Page




The *VLAN Properties* page contains the following fields:

- **VLAN ID** — Displays the VLAN ID.
- **Name** — Displays the user-defined VLAN name.
- **Type** — Displays the VLAN type. The possible field values are:
 - *Dynamic* — The VLAN was dynamically created through GARP.
 - *Static* — The VLAN is user-defined.
 - *Default* — The VLAN is the default VLAN.
- **Authentication** — Indicates whether unauthorized users can access a Guest VLAN. The possible field values are:
 - *Enable* — Enables unauthorized users to use the Guest VLAN.
 - *Disable* — Disables unauthorized users from using the Guest VLAN.
- **Remove** — Removes VLANs. The possible field values are:
 - *Checked* — Removes the selected VLAN.
 - *Unchecked* — Maintains VLANs.

2. Click **Create**. The *Add VLAN* page opens:

Figure 60: Add VLAN Page



The screenshot shows a web interface titled "Add VLAN" in blue text. Below the title is a form with two input fields: "VLAN ID" and "VLAN Name". The "VLAN ID" field is a small text box, and the "VLAN Name" field is a larger text box. Below these fields is a blue "Submit" button.


3. Define the *VLAN ID* and *VLAN Name* fields.
4. Click **Submit**. The VLAN ID is defined, and the device is updated.

Defining VLAN Membership

The *VLAN Membership Page* contains a table that maps VLAN parameters to ports. Ports are assigned VLAN membership by toggling through the Port Control settings. To define VLAN membership:

1. Click **Basic Setup > VLAN > Membership > Membership**. The *VLAN Membership Page* opens.

Figure 61: VLAN Membership Page



The *VLAN Membership Page* contains the following fields:

- **VLAN ID** — Displays the user-defined VLAN ID.
- **VLAN Name** — Displays the name of the VLAN
- **VLAN Type**— Indicates the VLAN type. The possible field values are:
 - *Dynamic* — The VLAN was dynamically created through GARP.
 - *Static* — The VLAN is user-defined.
 - *Default* — The VLAN is the default VLAN.
- **Port** — Indicates the port membership.
- **LAG** — Indicates the LAG membership.
- **Untagged (Orange)** — Indicates the interface is an untagged VLAN member. Packets forwarded by the interface are untagged.
- **Tagged (Blue)** — Indicates the interface is a tagged member of a VLAN. All packets forwarded by the interface are tagged. The packets contain VLAN information.
- **Include (Green)** — Includes the port in the VLAN.


- **Exclude (Gray)** — Excludes the interface from the VLAN. However, the interface can be added to the VLAN through GARP.
- **Forbidden (Red)** — Denies the interface VLAN membership, even if GARP indicates the port is to be added.

Defining VLAN Interface Settings

The *VLAN Interface Settings Page* contains fields for managing ports that are part of a VLAN. The port default VLAN ID (PVID) is configured on the *VLAN Interface Settings Page*. All untagged packets arriving at the device are tagged with the port PVID. To define VLAN interfaces:

1. Click **Basic Setup > VLAN > Membership > Interface Settings**. The *VLAN Interface Settings Page* opens.

Figure 62: VLAN Interface Settings Page



The *VLAN Interface Settings Page* contains the following fields:

- **Interface** — Displays the port number included in the VLAN.
- **Interface VLAN Mode** — Displays the port mode. The possible values are:
 - *General* — Indicates the port belongs to VLANs, and each VLAN is user-defined as tagged or untagged (full IEEE802.1q mode).
 - *Access* — Indicates a port belongs to a single untagged VLAN. When a port is in Access mode, the packet types which are accepted on the port cannot be designated. Ingress filtering cannot be enabled or disabled on an access port.
 - *Trunk* — Indicates the port belongs to VLANs in which all ports are tagged, except for one port that can be untagged.



- *PV - Promiscuous* — Indicates the port is part of a PV Promiscuous VLAN.
 - *PV - Isolated* — Indicates the port is part of a PV Isolated VLAN.
 - *PV - Community* — Indicates the port is part of a PV Community VLAN.
 - **Dynamic** — Assigns a port to a VLAN based on the host source MAC address connected to the port.
 - **PVID** — Assigns a VLAN ID to untagged packets. The possible values are 1-4094. VLAN 4095 is defined as per standard and industry practice as the Discard VLAN. Packets classified to the Discard VLAN are dropped.
 - **Frame Type** — Specifies the packet type accepted on the port. The possible field values are:
 - *Admit Tag Only* — Only tagged packets are accepted on the port.
 - *Admit All* — Both tagged and untagged packets are accepted on the port.
 - **Ingress Filtering** — Indicates whether ingress filtering is enabled on the port. The possible field values are:
 - *Enable* — Enables ingress filtering on the device. Ingress filtering discards packets that are defined to VLANs of which the specific port is not a member.
 - *Disable* — Disables ingress filtering on the device.
 - **Reserve VLAN** — Indicates the VLAN selected by the user to be the reserved VLAN if not in use by the system.
2. Select a port.
 3. Click  . The *VLAN Interface Settings Page* opens:

Figure 63: VLAN Interface Settings Page



Interface	1
Port VLAN Mode	Access
PVID	1
Frame Type	Admit All
Ingress Filtering	Enable
Current Reserved VLAN	
Reserve VLAN for Internal Use	

Submit

4. Define the *Interface*, *Port VLAN Mode*, *Dynamic*, *PVID*, *Frame Type*, *Ingress Filtering*, and *Reserve VLAN for Internal Use* fields.
5. Click **Submit**. The VLAN interface settings are modified, and the device is updated.

Defining Private VLANs

Private VLANs (PVLAN) increase network security by limiting inter-port communication within a VLAN. Private VLANs limit network traffic at the Layer 2 level. Network administrators define a Primary VLAN. Within the Primary VLAN there are Isolated and Community VLANs. Private VLAN ports can have the following states:

- **Promiscuous** — Promiscuous ports can communicate with all ports within a PVLAN. All promiscuous packets are automatically assigned to both the Isolated and the Community VLANs.
- **Isolated** — Isolated ports are completely isolated from other ports in the same PVLAN. However isolated ports can communicate with promiscuous ports. In addition, all traffic to and from isolated ports with a VLANs is blocked, except for traffic from promiscuous ports. All isolated ports are automatically assigned to the Isolated VLAN.
- **Community** — Community ports communicate with other community ports and with promiscuous ports. Community ports are separated from all other interfaces in other communities or isolated ports in the same PVLAN. All community ports are automatically assigned to the Community VLAN and to the Private VLAN.



Notes

- Ports cannot be defined as either promiscuous or isolated port if the ports are existing VLAN members.



Notes

- Previously created VLANs cannot be configured as isolated or community VLANs.



Notes

- Isolated and Community VLANs are included in the total VLAN count.

If the Primary VLAN is deleted, both the Isolated and the Community VLANs are also deleted. In addition, the Isolated and Community VLANs only forward untagged traffic. To define Private VLANs:

1. Click **Basic Setup > VLAN > Private VLANs**. The *Private VLANs Page* opens.

Figure 64: Private VLANs Page




The *Private VLANs Page* contains the following fields:

- **Private VLAN** — Contains a list of user-defined Private VLANs. The Private VLANs are defined in the Add Private VLAN page.
- **Isolated Ports** — Indicates which VLAN to which isolated ports are assigned.
- **Community Ports** — Adds a Community VLAN to which community ports are assigned.
- **Remove** — Removes a Private VLAN when checked. The possible field values are:
 - *Checked* — Removes the selected Private VLAN.
 - *Unchecked* — Maintains Private VLANs.

2. Click **Create**. The *VLAN Interface Settings Page* opens:

Figure 65: Add Private VLAN



The screenshot shows a web-based configuration form for adding a new private VLAN. The form is titled "New Private VLAN" and is set against a light gray background. It contains several input fields and a submit button. At the top right, there is a small icon of a book with a downward arrow. Below this, there are two rows of input fields. The first row has a checkbox labeled "Community VLAN (2-4093)" and a corresponding text input field. The second row has a checkbox labeled "Isolated VLAN (2-4093)" and a corresponding text input field. At the bottom center of the form, there is a blue "Submit" button.

3. Define the *New Private VLAN* and *Community VLAN (2-4093)* or *Isolated VLAN (2-4093)* fields.
4. Click **Submit**. The Private VLAN is created, and the device is updated.

Configuring GARP

This section contains information for configuring This section includes the following topics:

- Defining GARP
- Defining GVRP

Defining GARP

Generic Attribute Registration Protocol (GARP) protocol is a general-purpose protocol that registers any network connectivity or membership-style information. GARP defines a set of devices interested in a given network attribute, such as VLAN or multicast address. When configuring GARP, ensure the following:

- The leave time must be greater than or equal to three times the join time.
- The leave-all time must be greater than the leave time.
- Set the same GARP timer values on all Layer 2-connected devices. If the GARP timers are set differently on the Layer 2-connected devices, the GARP application does not operate successfully.

To define GARP on the device:

1. Click **Basic Setup > VLAN > GARP**. The *GARP Parameters Page* opens:

Figure 66: GARP Parameters Page

The screenshot shows the D-Link web interface for the DES-3010FA/GA switch. The left sidebar shows the navigation menu with 'Basic Setup' selected. Under 'Basic Setup', 'VLAN' is expanded, and 'GARP' is selected. The main content area displays the 'GARP Parameters Page'. At the top, there is a 'Copy from Entry Number' field and a 'to Entry Number(s)' field. Below this is a table with the following data:

	Interface	Join Timer	Leave Timer	Leave All Timer	Edit
1	1	200	600	10000	
2	2	200	600	10000	
3	3	200	600	10000	
4	4	200	600	10000	
5	5	200	600	10000	
6	6	200	600	10000	
7	7	200	600	10000	
8	8	200	600	10000	
9	9	200	600	10000	
10	10	200	600	10000	

At the bottom of the table is a 'Submit' button.


The *GARP Parameters Page* contains the following fields:

- **Copy from Entry Number** — Indicates the row number from which GARP parameters are copied.
- **To Row Number** — Indicates the row number to which GARP parameters are copied.
- **Interface** — Displays the port or LAG on which GARP is enabled.

- **Join Timer**— Indicates the amount of time, in centiseconds, that PDUs are transmitted. The default value is 20 centiseconds.
- **Leave Timer**— Indicates the amount of time lapse, in centiseconds, that the device waits before leaving its GARP state. Leave time is activated by a Leave All Time message sent/received, and cancelled by the Join message received. Leave time must be greater than or equal to three times the join time. The default value is 60 centiseconds.
- **Leave All Timer** — Indicates the amount of time lapse, in centiseconds, that all device waits before leaving the GARP state. The leave all time must be greater than the leave time. The default value is 1000 centiseconds.

2. Click  . The *GARP Parameters Settings Page* opens:

Figure 67: GARP Parameters Settings Page



GARP Parameters Settings

Interface ☒ Port ☐ LAG

GARP Timers

Join Timer (centiseconds)	<input type="text" value="200"/>
Leave Timer (centiseconds)	<input type="text" value="600"/>
Leave All Timer (centiseconds)	<input type="text" value="10000"/>

3. Modify the *Interface*, *Join Timer (centiseconds)*, *Leave Timer (centiseconds)*, and *Leave All Timer (centiseconds)* fields.
4. Click . The GARP parameters are defined, and the device is updated.

Defining GVRP

GARP VLAN Registration Protocol (GVRP) is specifically provided for automatic distribution of VLAN membership information among VLAN-aware bridges. GVRP allows VLAN-aware bridges to automatically learn VLANs to bridge ports mapping, without having to individually configure each bridge and register VLAN membership. To define GARP. To define GVRP on the device:

1. Click **Basic Setup > GARP > GVRP**. The *GVRP Parameters Page* opens:

Figure 68: GVRP Parameters Page

GVRP Global Status Disable

Copy from Entry Number to Entry Number(s)

#	Port	GVRP State	Dynamic VLAN Creation	GVRP Registration	Edit
1	1	Disabled	Disabled	Disabled	
2	2	Disabled	Disabled	Disabled	
3	3	Disabled	Disabled	Disabled	
4	4	Disabled	Disabled	Disabled	
5	5	Disabled	Disabled	Disabled	
6	6	Disabled	Disabled	Disabled	
7	7	Disabled	Disabled	Disabled	
8	8	Disabled	Disabled	Disabled	
9	9	Disabled	Disabled	Disabled	
10	10	Disabled	Disabled	Disabled	

Global System LAGs

11	LAG 1	Disabled	Disabled	Disabled	
12	LAG 2	Disabled	Disabled	Disabled	
13	LAG 3	Disabled	Disabled	Disabled	
14	LAG 4	Disabled	Disabled	Disabled	
15	LAG 5	Disabled	Disabled	Disabled	


The *GVRP Parameters Page* is divided into port and LAG parameters. The field definitions are the same. The *GVRP Parameters Page* contains the following fields:

- **GVRP Global Status** — Indicates if GVRP is enabled on the device. The possible field values are:
 - *Enable* — Enables GVRP on the selected device.
 - *Disable* — Disables GVRP on the selected device.
- **Copy from Entry Number** — Indicates the row number from which GARP parameters are copied.
- **To Row Number** — Indicates the row number to which GARP parameters are copied.
- **Port** — Displays the port on which GVRP is enabled. The possible field values are:
 - *Port* — Indicates the port number on which GVRP is enabled.
 - *LAG* — Indicates the LAG number on which GVRP is enabled.
- **GVRP State** — Indicates if GVRP is enabled on the port. The possible field values are:
 - *Enable* — Enables GVRP on the selected port.
 - *Disable* — Disables GVRP on the selected port.


- **Dynamic VLAN Creation** — Indicates if Dynamic VLAN creation is enabled on the interface. The possible field values are:
 - *Enable* — Enables Dynamic VLAN creation on the interface.
 - *Disable* — Disables Dynamic VLAN creation on the interface.
- **GVRP Registration** — Indicates if VLAN registration through GVRP is enabled on the device. The possible field values are:
 - *Enable* — Enables GVRP registration on the device.
 - *Disable* — Disables GVRP registration on the device.

2. Click  . The *GVRP Parameters Page* opens:

Figure 69: GVRP Parameters Page



GVRP Parameters Settings	
Interface	<input checked="" type="radio"/> Port 1 <input type="radio"/> LAG
GVRP State	Disable
Dynamic VLAN Creation	Disable
GVRP Registration	Disable
<input type="button" value="Submit"/>	

3. Define the *GVRP State*, *Dynamic VLAN Creation*, and *GVRP Registration* fields.
4. Click  . The GVRP Interface parameters are sent, and the device is updated.

Section 10. Configuring IP Information

This section provides information for defining device IP addresses, and includes the following topics:

- Configuring IP Interfaces
- Configuring Domain Name Servers

Configuring IP Interfaces

This section contains information for defining IP interfaces, and includes the following sections:

- Defining IP Addresses
- Defining Default Gateways
- Configuring DHCP
- Configuring ARP

Defining IP Addresses

The *IP Interface Page* contains fields for assigning IP parameters to interfaces, and for assigning gateway devices. Packets are forwarded to the default IP when frames are sent to a remote network. The configured IP address must belong to the same IP address subnet of one of the IP interfaces.

To define an IP interface:

1. Click **Basic Setup > IP Configuration > IP Addressing > IP Interface**. The *IP Interface Page* opens.

Figure 70: IP Interface Page




The *IP Interface Page* contains the following fields:

- **IP Address** — Displays the currently configured IP address.
- **Mask** — Displays the currently configured IP address mask.
- **Interface** — Displays the interface used to manage the device.
- **Remove** — Removes the selected IP address from the interface. The possible field values are:
 - *Checked* — Removes the IP address from the interface.
 - *Unchecked* — Maintains the IP address assigned to the Interface.

2. Click **Create**. The *Add IP Interface Page* opens:


Figure 71: Add IP Interface Page



The 'Add IP Interface' page features a form with the following fields and controls:

Source IP Address	<input type="text"/>
<input checked="" type="radio"/> Network Mask	<input type="text"/>
<input type="radio"/> Prefix Length	<input type="text"/>
Interface	<input checked="" type="radio"/> Port <input type="text" value="1"/> <input type="radio"/> LAG <input type="text" value="1"/> <input type="radio"/> VLAN <input type="text" value="1"/>

At the bottom of the form is a 'Submit' button.

3. Define the *IP Address*, *Network Mask* or *Prefix Length*, and *Interface* fields.
4. Click . The IP configuration fields are saved, and the device is updated.

To modify an IP interface:



1. Click **Basic Setup > IP Configuration > IP Addressing > IP Interface**. The *IP Interface Page* opens.
2. Click . The *IP Interface Settings Page* opens:


Figure 72: IP Interface Settings Page



The 'IP Interface Settings' page features a form with the following fields and controls:

IP Address	<input type="text" value="10.6.39.150"/>
<input checked="" type="radio"/> Network Mask	<input type="text" value="255.255.255.0"/>
<input type="radio"/> Prefix Length	<input type="text" value="/24"/>
Interface	<input checked="" type="radio"/> Port <input type="text" value="3"/> <input type="radio"/> LAG <input type="text" value="1"/> <input type="radio"/> VLAN <input type="text" value="1"/>
Type	Static

At the bottom of the form is a 'Submit' button.

3. Modify the *IP Address*, *Network Mask* or *Prefix Length*, and *Interface* fields.
4. Click . The IP Interface is modified, and the device is updated.

Defining Default Gateways

Packets are forwarded to the default IP when frames are sent to a remote network via the default gateway. The configured IP address must belong to the same subnet of one of the IP interfaces. To define a default gateway:

1. Click **Basic Setup > IP Configuration > IP Addressing > Default Gateway**. The *Default Gateway Page* opens:

Figure 73: Default Gateway Page



The *Default Gateway Page* contains the following fields:


- **User Defined Default Gateway** — Defines the default gateway IP address.
 - **Active Default Gateway** — Indicates if the default gateway is active. The possible field values are:
 - *Checked* — Activates the default gateway.
 - *Unchecked* — Maintains the default gateway as inactive. This is the default value.
 - **Remove** — Removes the default gateway. The possible field values are:
 - *Checked* — Removes the selected default gateway.
 - *Unchecked* — Maintains the default gateway.
2. Select an IP address in the *User Defined Default Gateway* field.
 3. Select the *Active Default Gateway* check box.
 4. Click **Submit**. The device's default gateway is defined, and the device is updated.

Configuring DHCP

The *Dynamic Host Configuration Protocol* (DHCP) assigns dynamic IP addresses to devices on a network. DHCP ensures that network devices can have a different IP address every time the device connects to the network. To define a DHCP Interface:

1. Click **Basic Setup > IP Configuration > IP Addressing > DHCP**. The *DCHP Page* opens:

Figure 74: DCHP Page



The *DCHP Page* contains the following fields:

- **Interface** — Displays the interface D-Link IP address which is connected to the device.
- **Host Name** — Displays the system name.
- **Remove** — Removes DHCP interfaces. The possible field values are:
 - *Checked* — Removes the selected DHCP interface.
 - *Unchecked* — Maintains the DHCP interfaces.

2. Click **Create**. The *Add DHCP IP Interface Page* opens:

Figure 75: Add DHCP IP Interface Page

Add DHCP IP Interface

Interface ☒ Port ☐ LAG ☐ VLAN

Host Name

Submit

3. Define the *Interface* and *Host Name* fields.
4. Click . The DHCP interface is added, and the device is updated.

Configuring ARP

The *Address Resolution Protocol* (ARP) converts IP addresses into physical addresses, and maps the IP address to a MAC address. ARP allows a host to communicate with other hosts only when the IP address of its neighbors is known. To define ARP information:

1. Click **Basic Setup > IP Configuration > IP Addressing > ARP**. The *ARP Page* opens:

Figure 76: ARP Page

The screenshot shows the D-Link web interface for configuring ARP. The sidebar on the left lists various configuration options under 'System', 'Basic Setup', and 'Advanced Setup'. The 'Basic Setup' section is expanded, showing 'Interface Configuration', 'Interface Properties', 'IP Configuration', 'IP Addressing', 'IP Interface', 'Default Gateway', 'DHCP', 'ARP', 'Domain Name System', 'DNS Server', 'Host Mapping', 'VLAN', and 'Quality of Service'. The 'ARP' option is selected. The main content area displays the 'ARP Entry Age Out' field set to 300 seconds and the 'Clear ARP Table Entries' dropdown set to 'None'. Below these fields is a 'Create' button. A table lists the current ARP entries, with one entry for interface 3, IP 10.6.39.17, and MAC 00061bc9dc0e, with a status of 'Dynamic'. The table has columns for '#', 'Interface', 'IP Address', 'MAC Address', 'Status', 'Edit', and 'Remove'. A 'Submit' button is located at the bottom of the table.

#	Interface	IP Address	MAC Address	Status	Edit	Remove
1	3	10.6.39.17	00061bc9dc0e	Dynamic		<input type="checkbox"/>

The *ARP Page* contains the following fields:

- **ARP Entry Age Out** — Specifies the amount of time (in seconds) that passes between *ARP Table* entry requests. Following the *ARP Entry Age* period, the entry is deleted from the table. The range is **1 - 40000000**. The default value is 60000 seconds.
- **Clear ARP Table Entries** — Specifies the types of ARP entries that are cleared. The possible values are:
 - *None* — Does not clear ARP entries.
 - *All* — Clears all ARP entries.
 - *Dynamic* — Clears only dynamic ARP entries.
 - *Static* — Clears only static ARP entries.
- **Interface** — Displays the interface type for which ARP parameters are displayed. The possible field values are:
 - *Port* — The port for which ARP parameters are defined.
 - *LAG* — The LAG for which ARP parameters are defined.
 - *VLAN* — The VLAN for which ARP parameters are defined.

- **IP Address** — Indicates the station IP address, which is associated with the MAC address filled in below.
 - **MAC Address** — Displays the station MAC address, which is associated in the ARP table with the IP address.
 - **Status** — Displays the ARP table entry type. Possible field values are:
 - *Dynamic* — The ARP entry is learned dynamically.
 - *Static* — The ARP entry is a static entry.
 - **Remove** — Removes a specific ARP entry. The possible field values are:
 - *Checked* — Removes the selected ARP entries.
 - *Unchecked* — Maintains the current ARP entries.
2. Define the *ARP Entry Age Out* and *Clear ARP Table Entries* fields.
 3. Click **Submit**. The ARP parameters are defined, and the device is updated.

To create a new ARP entry:

1. Click **Basic Setup > IP Configuration > IP Addressing > ARP**. The *ARP Page* opens.
2. Click **Create**. The *Add ARP Entry Page* opens:

Figure 77: Add ARP Entry Page

ARP Settings

Interface	<input checked="" type="radio"/> Port 1 <input type="radio"/> LAG <input type="radio"/> VLAN
IP Address	<input type="text" value="0.0.0.0"/>
MAC Address	<input type="text"/>

Submit

3. Define the *Interface*, *IP Address*, and *MAC Address* fields.
4. Click **Submit**. The ARP interface is added, and the device is updated.

Configuring Domain Name Servers

Domain Name System (DNS) converts user-defined domain names into IP addresses. Each time a domain name is assigned, the DNS service translates the name into a numeric IP address. For example, **www.ipexample.com** is translated into 192.87.56.2. DNS servers maintain databases of domain names and their corresponding IP addresses.

This section contains the following topics:


- Defining DNS Servers
- Defining DNS Host Mapping

Defining DNS Servers

The *DNS Server Page* contains fields for enabling and activating specific DNS servers. To enable a DNS server:

1. Click **Basic Setup > IP Configuration > Domain Name System > DNS Server**. The *DNS Server Page* opens:

Figure 78: DNS Server Page



The *DNS Server Page* contains the following fields:

- **Enable DNS** — Enables translating the DNS names into IP addresses. The possible field values are:
 - *Enable* — Translates the domains into IP addresses.
 - *Disable* — Disables translating domains into IP addresses.
- **Default Domain Name** — Specifies the user-defined DNS server name.
- **Type** — Displays the IP address type. The possible field values are:
 - *Dynamic* — The IP address is dynamically created.
 - *Static* — The IP address is a static IP address.
- **Remove** — Removes DNS servers. The possible field values are:
 - *Checked* — Removes the selected DNS server
 - *Unchecked* — Maintains the current DNS server list.
- **DNS Server** — Displays the DNS server D-Link IP address. DNS servers are added in the *Add DNS Server Page*.
- **Active Server** — Specifies the DNS server that is currently active.



Notes

- All DNS servers can be selected by clicking Select All in DNS Server Table.
2. Select *Enable DNS*.
 3. Define the *Default Domain Name* and *Active Server* fields.
 4. Click . The DNS server is enabled, and the device is updated.

To add a new DNS Server:

1. Click **Basic Setup > IP Configuration > Domain Name System > DNS Server**. The *DNS Server Page* opens.
2. Click . The *Add DNS Server Page* opens:

Figure 79: Add DNS Server Page

Add DNS Server

DNS Server	<input type="text"/>
DNS Server Currently Active	<input type="text"/>
Set DNS Server Active	<input type="checkbox"/>

3. Define the *DNS Server*, *DNS Server Currently Active*, and *Set DNS Server Active* fields.
4. Click . The DNS server is added, and the device is updated.

Defining DNS Host Mapping

The *DNS Host Mapping Page* provides information for defining default DNS domain names. To define DNS host mapping:

1. Click **Basic Setup > IP Configuration > Domain Name System > Host Mapping**. The *DNS Host Mapping Page* opens:

Figure 80: DNS Host Mapping Page



The *DNS Host Mapping Page* contains the following fields:


- **Host Names** — Displays a user-defined default domain name. When defined, the default domain name is applied to all unqualified host names. The *Host Name* field can contain up to 158 characters.
- **IP Address** — Displays the DNS host D-Link IP address.
- **Remove** — Removes default domain names. The possible field values are:
 - *Checked* — Removes the selected DNS host.
 - *Unchecked* — Maintains the current DNS host mapping list.

2. Click **Create**. The *Add DNS Host Page* opens:

Figure 81: Add DNS Host Page



The screenshot shows a web form titled "Add DNS Host" in blue text. Below the title, there are two input fields: "Host Name" and "IP Address", each with a corresponding text box. At the bottom right of the form, there is a blue "Submit" button.

3. Define the *Host Name* and *IP Address* fields.
4. Click . The DNS host is added, and the device is updated.

Section 11. Defining the Forwarding Database

Packets addressed to destinations stored in either the Static or Dynamic databases are immediately forwarded to the port. The Dynamic MAC Address Table can be sorted by interface, VLAN, or MAC Address, whereas MAC addresses are dynamically learned as packets from sources that arrive at the device. Static addresses are configured manually.

An address becomes associated with a port by learning the port from the frame's source address, but if a frame that is addressed to a destination MAC address is not associated with a port, that frame is flooded to all relevant VLAN ports. To prevent the bridging table from overflowing, a dynamic MAC address, from which no traffic arrives for a set period, is erased.

This section contains information for defining both static and dynamic forwarding database entries, and includes the following topics:

- Defining Static Forwarding Database Entries
- Defining Dynamic Forwarding Database Entries


Defining Static Forwarding Database Entries

The *Forwarding Database Static Addresses Page* contains parameters for defining the age interval on the device. To prevent static MAC addresses from being deleted when the device is reset, ensure that the port attached to the MAC address is locked.

To configure the static forwarding database:

1. Click **Advanced Setup > Forwarding Database > Static Addresses**. The *Forwarding Database Static Addresses Page* opens.

Figure 82: Forwarding Database Static Addresses Page



The *Forwarding Database Static Addresses Page* contains the following fields:

- **MAC Address** — Displays the MAC address to which the entry refers.
- **VLAN ID** — Displays the VLAN ID number to which the entry refers.
- **Interface** — Displays the interface to which the entry refers:
 - Port — The specific port number to which the forwarding database parameters refer.
 - LAG — The specific LAG number to which the forwarding database parameters refer.
- **Status** — Displays how the entry was created. The possible field values are:
 - *Secure* — The MAC Address is defined for locked ports.
 - *Permanent* — The MAC address is permanent.
 - *Delete on Reset* — The MAC address is deleted when the device is reset.
 - *Delete on Timeout* — The MAC address is deleted when a timeout occurs.

- **Remove** — Removes the entry. The possible field values are:
 - *Checked* — Removes the selected entry.
 - *Unchecked* — Maintains the current static forwarding database.



Note

To prevent static MAC addresses from being deleted when the device is reset, make sure that the port attached to the MAC address is locked.

To add a new static forwarding database entry:

1. Click **Advanced Setup > Forwarding Database > Static Addresses**. The *Forwarding Database Static Addresses Page* opens.
2. Click **Create**. The *Add Forwarding Database Page* opens:

Figure 83: Add Forwarding Database Page

Add Forwarding Database

Interface	<input checked="" type="radio"/> Port <input type="text" value="1"/> <input type="radio"/> LAG <input type="text" value="1"/>
MAC Address	<input type="text"/>
<input checked="" type="radio"/> VLAN ID	<input type="text" value="1"/>
<input type="radio"/> VLAN Name	<input type="text"/>
Status	<input type="text" value="Permanent"/>

3. Define the *Interface*, *MAC Address*, *VLAN ID* or *VLAN Name*, and *Status* fields.
4. Click **Submit**. The forwarding database information is modified, and the device is updated.

Defining Dynamic Forwarding Database Entries

The *Dynamic Addresses Page* contains parameters for querying information in the Dynamic MAC Address Table, including the interface type, MAC addresses, VLAN, and table storing. The Dynamic MAC Address table contains information about the aging time before a dynamic MAC address is erased, and includes parameters for querying and viewing the Dynamic MAC Address table. The Dynamic MAC Address table contains address parameters by which packets are directly forwarded to the ports. The Dynamic Address Table can be sorted by interface, VLAN, and MAC Address.

To configure the Dynamic MAC Address table:

1. Click **Advanced Setup > Forwarding Database > Dynamic Addresses**. The *Dynamic Addresses Page* opens.

Figure 84: Dynamic Addresses Page

D-Link

D-Link DES-3010G4 10/100 Fast Ethernet Switch

Power Diagnostics B8-330 Console LCE, 9000, a, b, 1

1 2 3 4 5 6 7 8 C1 Link/Act C2

System Basic Setup **Advanced Setup** Help Logout

10.6.39.150

- Interface
 - LACP Parameters
 - LAG Membership
- Forwarding Database**
 - Static Addresses
 - Dynamic Addresses
- Network Security
- Spanning Tree
- Multicast Support
- Interface Statistics
- RMON

Aging Interval (secs) 300 (Sec)

Submit

Query by:

☐ Interface ☒ Port 1 ☐ LAG 1

☐ MAC Address

☐ VLAN ID


Query

Current Address Table


#	VLAN ID	MAC	Interface
1	Internal Use	000045433443	3
2	Internal Use	000347cc01ce	3
3	Internal Use	00051c1a32a5	3
4	Internal Use	00061bc96fc5	3
5	Internal Use	00061bc9dc0e	3
6	Internal Use	00060222e439	3

The *Dynamic Addresses Page* contains the following fields:

- **Aging Interval (secs)**— Specifies the amount of time the MAC address remains in the Dynamic MAC Address table before it is timed out, if no traffic from the source is detected. The default value is 300 seconds.
- **Port** — Specifies the interface for which the table is queried. There are two interface types from which to select.
- **MAC Address** — Specifies the MAC address for which the table is queried.
- **VLAN ID** — Specifies the VLAN ID for which the table is queried.
- **Address Table Sort Key** —Specifies the means by which the Dynamic MAC Address Table is sorted. The address table can be sorted by address, VLAN, or interface.

2. Define the fields.
3. Click . The *Dynamic Address Aging* field is defined, and the device is updated.

To query the Dynamic MAC Address Table:

1. Click **Advanced Setup > Forwarding Database > Dynamic Addresses**. The *Dynamic Addresses Page* opens.
2. Select a *port*, *MAC Address*, and *VLAN ID*.
3. Select an *Address Table Sort Key*.
4. Click . The Dynamic MAC Address Table is queried, and the results are displayed.

Section 12. Configuring Spanning Tree

Spanning Tree Protocol (STP) provides tree topography for any arrangement of bridges. STP also provides a single path between end stations on a network, eliminating loops.

Loops occur when alternate routes exist between hosts. Loops in an extended network can cause bridges to forward traffic indefinitely, resulting in increased traffic and reducing network efficiency.

The device supports the following STP versions:

- **Classic STP** — Provides a single path between end stations, avoiding and eliminating loops. For more information on configuring Classic STP, see *Defining Classic Spanning Tree*.
- **Rapid STP** — Detects and uses network topologies that provide faster convergence of the spanning tree, without creating forwarding loops. For more information on configuring Rapid STP, see *Defining Rapid Spanning Tree*.
- **Multiple STP** — Provides various load balancing scenarios. For example, if port A is blocked in one STP instance, the same port can be placed in the *Forwarding State* in another STP instance. For more information on configuring Multiple STP, see *Defining Multiple Spanning Tree*.

This section contains the following topics:

- Defining Classic Spanning Tree
- Defining STP on Interfaces
- Defining Rapid Spanning Tree
- Defining Multiple Spanning Tree

Defining Classic Spanning Tree

The *STP Properties Page* contains parameters for enabling STP on the device. To enable STP on the device:

1. Click **Advanced Setup > Spanning Tree > STP > Properties**. The *STP Properties Page* opens:

Figure 85: STP Properties Page

D-Link

D-Link DES-3010FA 10/100 Fast Ethernet Switch

Power Diagnostics R8432 Console DCL, WOL, s, b, l

1 2 3 4 5 6 7 8 C1 Link Act C2

System Basic Setup **Advanced Setup** Help Logout

10.6.39.150

- Interface
 - LACP Parameters
 - LAG Membership
- Forwarding Database
- Network Security
- Spanning Tree
 - STP**
 - Properties
 - Interface Settings
 - RSTP
 - MSTP
- Multicast Support
- Interface Statistics
- RMON
 - Statistics
 - History
 - History Control
 - History Table
- Events
- Alarm

Global Settings

Spanning Tree State

STP Operation Mode

BPDUs Handling

Path Cost Default Values

Bridge Settings

Priority

☒ Hello Time (Sec)

☐ Max Age (Sec)

☐ Forward Delay (Sec)

Designated Root

Bridge ID 32768-00:13:25:38:78:00

Root Bridge ID 0-00:0d:56:2f:42:c0

Root Port 3


Root Path Cost 23

Topology Changes Counts 1

Last Topology Change 0D/ 1H/ 33M/ 22S

The *STP Properties Page* contains the following fields:

- **Spanning Tree State** — Indicates whether STP is enabled on the device. The possible field values are:
 - *Enable* — Enables STP on the device.
 - *Disable* — Disables STP on the device.
- **STP Operation Mode** — Specifies the STP mode that is enabled on the device. The possible field values are:
 - *Classic STP* — Enables Classic STP on the device. This is the default value.
 - *Rapid STP* — Enables Rapid STP on the device.
 - *Multiple STP* — Enables Multiple STP on the device.
- **BPDUs Handling** — Determines how BPDU packets are managed when STP is disabled on the port or device. BPDUs are used to transmit spanning tree information. The possible field values are:
 - *Filtering* — Filters BPDU packets when spanning tree is disabled on an interface. This is the default value.
 - *Flooding* — Floods BPDU packets when spanning tree is disabled on an interface.
- **Path Cost Default Values** — Specifies the method used to assign default path cost to STP ports. The possible field values are:

- *Short* — Specifies 1 through 65,535 range for port path cost. This is the default value.
 - *Long* — Specifies 1 through 200,000,000 range for port path cost. The default path cost assigned to an interface varies according to the selected method (*Hello Time*, *Max Age*, or *Forward Delay*).
 - **Priority (0-65535)** — Specifies the bridge priority value. When switches or bridges are running STP, each is assigned a priority. After exchanging BPDUs, the device with the lowest priority value becomes the Root Bridge. The default value is 32768. The port priority value is provided in increments of 4096.
 - **Hello Time (1-10)** — Specifies the device Hello Time. The Hello Time indicates the amount of time in seconds a Root Bridge waits between configuration messages. The default is 2 seconds.
 - **Max Age (6-40)** — Specifies the device Maximum Age Time. The Maximum Age Time is the amount of time in seconds a bridge waits before sending configuration messages. The default Maximum Age Time is 20 seconds.
 - **Forward Delay (4-30)** — Specifies the device Forward Delay Time. The Forward Delay Time is the amount of time in seconds a bridge remains in a listening and learning state before forwarding packets. The default is 10 seconds.
 - **Bridge ID** — Identifies the Bridge priority and MAC address.
 - **Root Bridge ID** — Identifies the Root Bridge priority and MAC address.
 - **Root Port** — Indicates the port number that offers the lowest cost path from this bridge to the Root Bridge. This field is significant when the bridge is not the Root Bridge. The default is zero.
 - **Root Path Cost** — The cost of the path from this bridge to the Root Bridge.
 - **Topology Changes Counts** — Specifies the total amount of STP state changes that have occurred.
 - **Last Topology Change** — Indicates the amount of time that has elapsed since the bridge was initialized or reset, and the last topographic change that occurred. The time is displayed in a day-hour-minute-second format, such as 2 days 5 hours 10 minutes and 4 seconds.
2. Select *Enable* in the *Spanning Tree State* field.
 3. Select an STP type in the *STP Operation Mode* field.
 4. Define the *BPDU Handling* and *Path Cost Default Values* fields.
 5. Select either the *Hello Time*, *Max Age*, or *Forward Delay* field.
 6. Click . STP is enabled, and the device is updated.

Defining STP on Interfaces

Network administrators can assign STP settings to specific interfaces using the *STP Interface Page*. The Global LAGs section displays the STP information for Link Aggregated Groups. To assign STP settings to an interface:

1. Click **Advanced Setup > Spanning Tree > STP > Interface Settings**. The *STP Interface Page* opens:

Figure 86: STP Interface Page

The screenshot shows the D-Link web interface for the DES-3010FA/GA switch. The left sidebar contains a navigation menu with options like System, Basic Setup, and Advanced Setup. The main content area is titled 'Advanced Setup' and shows the 'STP Interface Page'. It features a table with 12 columns: #, Port, STP, Fast Link, Guard Root, Port State, Port Role, Path Cost, Priority, Designated Bridge ID, Designated Port ID, Designated Cost, Forward Transitions, and Edit. The table lists 10 ports, all with STP enabled. Below the table is a section for 'Global System LAGs' with a similar table structure.

#	Port	STP	Fast Link	Guard Root	Port State	Port Role	Path Cost	Priority	Designated Bridge ID	Designated Port ID	Designated Cost	Forward Transitions	Edit
1	1	Enabled	Disabled	Disabled	Disabled	Disabled	100	128	N/A	N/A	N/A	N/A	
2	2	Enabled	Disabled	Disabled	Disabled	Disabled	100	128	N/A	N/A	N/A	N/A	
3	3	Enabled	Disabled	Disabled	Forwarding	Root	19	128	32768-00:13:25:38:78:00	128-3	23	1	
4	4	Enabled	Disabled	Disabled	Disabled	Disabled	100	128	N/A	N/A	N/A	N/A	
5	5	Enabled	Disabled	Disabled	Disabled	Disabled	100	128	N/A	N/A	N/A	N/A	
6	6	Enabled	Disabled	Disabled	Disabled	Disabled	100	128	N/A	N/A	N/A	N/A	
7	7	Enabled	Disabled	Disabled	Disabled	Disabled	100	128	N/A	N/A	N/A	N/A	
8	8	Enabled	Disabled	Disabled	Disabled	Disabled	100	128	N/A	N/A	N/A	N/A	
9	9	Enabled	Disabled	Disabled	Disabled	Disabled	100	128	N/A	N/A	N/A	N/A	
10	10	Enabled	Disabled	Disabled	Disabled	Disabled	100	128	N/A	N/A	N/A	N/A	

Global System LAGs											
LAG	STP	Fast Link	Guard Root	State	Path Cost	Priority	Designated Bridge ID	Designated Port ID	Designated Cost	Forward Transitions	Edit

The *STP Interface Page* contains the following fields:

- **Port** — The interface for which the information is displayed.
- **STP Status** — Indicates if STP is enabled on the port. The possible field values are:
 - *Enabled* — Indicates that STP is enabled on the port.
 - *Disabled* — Indicates that STP is disabled on the port.
- **Fast Link** — Indicates if Fast Link is enabled on the port. If Fast Link mode is enabled for a port, the *Port State* is automatically placed in the *Forwarding* state when the port link is up. Fast Link optimizes the STP protocol convergence. STP convergence can take 30-60 seconds in large networks.
- **Root Guard** — Prevents devices outside the network core from being assigned the spanning tree root.
- **Port State** — Displays the current STP state of a port. If enabled, the port state determines what forwarding action is taken on traffic. Possible port states are:
 - *Disabled* — Indicates that STP is currently disabled on the port. The port forwards traffic while learning MAC addresses.
 - *Blocking* — Indicates that the port is currently blocked and cannot forward traffic or learn MAC addresses. Blocking is displayed when Classic STP is enabled.



- **Speed** — Indicates the speed at which the port is operating.
 - **Path Cost** — Indicates the port contribution to the root path cost. The path cost is adjusted to a higher or lower value, and is used to forward traffic when a path is re-routed.
 - **Priority** — Priority value of the port. The priority value influences the port choice when a bridge has two ports connected in a loop. The priority value is between 0 -240. The priority value is determined in increments of 16.
 - **Designated Bridge ID** — Indicates the bridge priority and the MAC Address of the designated bridge.
 - **Designated Port ID** — Indicates the selected port D-Link priority and interface.
 - **Designated Cost** — Indicates the cost of the port participating in the STP topology. Ports with a lower cost are less likely to be blocked if STP detects loops.
 - **Forward Transitions** — Indicates the number of times the port has changed from *Forwarding* state to *Blocking* state.
 - **LAG** — Indicates the LAG to which the port belongs.
2. Click . The *STP Interface Settings Page* opens:


Figure 87: STP Interface Settings Page



Port	1
STP	Enable
Fast Link	<input type="checkbox"/>
Enable Root Guard	<input type="checkbox"/>
Port State	Disabled
Path Cost	100
Default Path Cost	<input type="checkbox"/>
Priority	128
Designated Bridge ID	N/A
Designated Port ID	N/A
Designated Cost	N/A
Forward Transitions	N/A

Submit

3. Select *Enable* in the *STP* field.


4. Define the *Fast Link*, *Enable Root Guard*, *Path Cost*, *Default Path Cost*, and *Priority* fields.
5. Click . STP is enabled on the interface, and the device is updated.

Defining Rapid Spanning Tree

While Classic STP prevents Layer 2 forwarding loops in a general network topology, convergence can take between 30-60 seconds. This time may delay detecting possible loops and propagating status topology changes. *Rapid Spanning Tree Protocol* (RSTP) detects and uses network topologies that allow a faster STP convergence without creating forwarding loops. The Global System LAG information displays the same field information as the ports, but represent the LAG RSTP information. To define RSTP on the device:

1. Click **Advanced Setup > Spanning Tree > RSTP > RSTP**. The *RSTP Page* opens:

Figure 88: RSTP Page



The *RSTP Page* contains the following fields:

- **Interface** — Displays the port or LAG on which Rapid STP is enabled.
- **Role** — Displays the port role assigned by the STP algorithm to provide to STP paths. The possible field values are:
 - *Root* — Provides the lowest cost path to forward packets to the root switch.
 - *Designated* — The port or LAG through which the designated switch is attached to the LAN.
 - *Alternate* — Provides an alternate path to the root switch from the root interface.
 - *Backup* — Provides a backup path to the designated port path toward the Spanning Tree leaves. Backup ports occur only when two ports are connected in a loop by a point-to-point link, or when a LAN has two or more connections connected to a shared segment.
 - *Disabled* — The port is not participating in the Spanning Tree.

- **Mode**—Displays the current STP mode. The STP mode is selected in the *STP Properties Page*. The possible field values are:
 - *STP* — Classic STP is enabled on the device.
 - *Rapid STP* — Rapid STP is enabled on the device.
 - *Multiple STP* — Multiple STP is enabled on the device.
- **Fast Link Operational Status** — Indicates whether Fast Link is enabled or disabled for the port or LAG. If Fast Link is enabled for a port, the port is automatically placed in the forwarding state.
- **Port Status** — Displays the RSTP status for the port on which RSTP is enabled. The possible field values are:
 - *Disable* — indicates the port is currently disabled.
 - *Forwarding* — Indicates the port is currently linked and forwarding traffic.
- **Point-to-Point Admin Status** — Indicates whether a point-to-point link is established, or if the device is permitted to establish a point-to-point link. The possible field values are:
 - *Enable* — The device is permitted to establish a point-to-point link, or is configured to automatically establish a point-to-point link. To establish communications over a point-to-point link, the originating PPP first sends *Link Control Protocol* (LCP) packets to configure and test the data link. After a link is established and optional facilities are negotiated as needed by the LCP, the originating PPP sends *Network Control Protocol* (NCP) packets to select and configure one or more network layer protocols. When each of the chosen network layer protocols has been configured, packets from each network layer protocol can be sent over the link. The link remains configured for communications until explicit LCP or NCP packets close the link, or until some external event occurs. This is the actual switch port link type. It may differ from the administrative state.
 - *Disable* — Disables point-to-point link.
- **Point-to-Point Operational Status** — Displays the point-to-point operating state.
- **Activate Protocol Migration** — Indicates whether sending Link Control Protocol (LCP) packets to configure and test the data link is enabled. The possible field values are:
 - *Checked* — Protocol Migration is enabled.
 - *Unchecked* — Protocol Migration is disabled.

2. Click  . The *RSTP Settings Page* opens:

Figure 89: RSTP Settings Page

Rapid Spanning Tree Settings

Interface	<input checked="" type="radio"/> Port <input type="text" value="1"/> <input type="button" value="v"/> <input type="radio"/> LAG <input type="button" value="v"/>
Role	Disable
Mode	RSTP
Fast Link Operational Status	Disable
Port State	Disabled
Point to Point Admin Status	<input type="text" value="Auto"/> <input type="button" value="v"/>
Point to Point Operational Status	Enable
Activate Protocol Migration Test	<input type="checkbox"/>

3. Define the *Interface*, *Point-to-Point Admin Status* and *Activate Protocol Migration* fields.
4. Click . RSTP is defined for the interface, and the device is updated.

Defining Multiple Spanning Tree

Multiple Spanning Tree (MSTP) provides differing load balancing scenarios. For example, while port A is blocked in one STP instance, the same port can be placed in the *Forwarding* state in another STP instance. The *MSTP Properties Page* contains information for defining global MSTP settings, including region names, MSTP revisions, and maximum hops. To define MSTP:

1. Click **Advanced Setup > Spanning Tree > MSTP > Properties**. The *MSTP Properties Page* opens:

Figure 90: MSTP Properties Page



The *MSTP Properties Page* contains the following fields:

- **Region Name** — User-defined STP region name.
 - **Revision** — An unsigned 16-bit number that identifies the revision of the current MSTP configuration. The revision number is required as part of the MSTP configuration. The possible field range is 0-65535.
 - **Max Hops** — Specifies the total number of hops that occur in a specific region before the BPDU is discarded. Once the BPDU is discarded, the port information is aged out. The possible field range is 1-40. The field default is 20 hops.
 - **IST Master** — Identifies the Spanning Tree Master instance. The IST Master is the specified instance root.
2. Define the *Region Name*, *Revision*, and *Max Hops* fields.
 3. Click **Submit**. The MSTP properties are defined, and the device is updated.

Defining MSTP Instance Settings

MSTP maps VLANs into STP instances. Packets assigned to various VLANs are transmitted along different paths within *Multiple Spanning Tree Regions* (MST Regions). Regions are one or more Multiple Spanning Tree bridges

by which frames can be transmitted. In configuring MSTP, the MST region to which the device belongs is defined. A configuration consists of the name, revision, and region to which the device belongs.

Network administrators can define the MSTP instance settings using the *MSTP Instance Settings Page*. To define MSTP instance settings:

1. Click **Advanced Setup > Spanning Tree > MSTP > Instance Settings**. The *MSTP Instance Settings Page* opens:

Figure 91: MSTP Instance Settings Page

The screenshot shows the D-Link web management interface. The top navigation bar includes 'System', 'Basic Setup', and 'Advanced Setup'. The left sidebar shows a tree view with 'Spanning Tree' expanded, leading to 'MSTP' and then 'Instance Settings'. The main content area is titled 'Vlan Instance Configuration'. It features a table of configuration fields for a specific MSTP instance (ID 1). The fields include 'Included VLAN' (a list box), 'Bridge Priority' (32768), 'Designated Root Bridge ID' (32768-00 13 25 38 78 00), 'Root Port' (0), 'Root Path Cost' (0), 'Bridge ID' (32768-00 13 25 38 78 00), and 'Remaining Hops' (20). A 'Submit' button is located at the bottom right of the configuration area.

The *MSTP Instance Settings Page* contains the following fields:

- **Instance ID** — Specifies the VLAN group to which the interface is assigned.
- **Included VLAN** — Maps the selected VLANs to the selected instance. Each VLAN belongs to one instance.
- **Bridge Priority** — Specifies the selected spanning tree instance device priority. The field range is 0-61440
- **Designated Root Bridge ID** — Indicates the ID of the bridge with the lowest path cost to the instance ID.
- **Root Port** — Indicates the selected instance's root port.
- **Root Path Cost** — Indicates the selected instance's path cost.
- **Bridge ID** — Indicates the bridge ID of the selected instance.
- **Remaining Hops** — Indicates the number of hops remaining to the next destination.

2. Click **Vlan Instance Configuration**. The *VLAN Instance Configuration Table* opens:

Figure 92: VLAN Instance Configuration Table

#	VLAN	Instance ID (0-15)
1	Vlan 1	<input type="text" value="0"/>
2	Vlan 2	<input type="text" value="0"/>
3	Vlan 3	<input type="text" value="0"/>
4	Vlan 4	<input type="text" value="0"/>
5	Vlan 5	<input type="text" value="0"/>
6	Vlan 6	<input type="text" value="0"/>
7	Vlan 7	<input type="text" value="0"/>
8	Vlan 8	<input type="text" value="0"/>
9	Vlan 9	<input type="text" value="0"/>
10	Vlan 10	<input type="text" value="0"/>
11	Vlan 11	<input type="text" value="0"/>
12	Vlan 12	<input type="text" value="0"/>
13	Vlan 13	<input type="text" value="0"/>
14	Vlan 14	<input type="text" value="0"/>
15	Vlan 15	<input type="text" value="0"/>
16	Vlan 16	<input type="text" value="0"/>
17	Vlan 17	<input type="text" value="0"/>
18	Vlan 18	<input type="text" value="0"/>
19	Vlan 19	<input type="text" value="0"/>
20	Vlan 20	<input type="text" value="0"/>
21	Vlan 21	<input type="text" value="0"/>
22	Vlan 22	<input type="text" value="0"/>
23	Vlan 23	<input type="text" value="0"/>
24	Vlan 24	<input type="text" value="0"/>
25	Vlan 25	<input type="text" value="0"/>

- 3. Define the *Instance ID* field.
- 4. Click **Submit** . The MSTP Instances are assigned, and the device is updated.

Defining MSTP Interface Settings

Network Administrators can assign MSTP Interface settings in the *MSTP Instance Settings Page*. To define MSTP interface settings:

1. Click **Advanced Setup > Spanning Tree > MSTP > Interface Settings**. The *MSTP Interface Settings Page* opens:

Figure 93: MSTP Interface Settings Page

Interface Table	
Instance ID	1
Interface	Port 1
MSTP	Enabled
Port State	N/A
Type	N/A
Role	N/A
Mode	N/A
Interface Priority	128
Path Cost	100
Designated Bridge ID	N/A
Designated Port ID	N/A
Designated Cost	N/A
Forward Transitions	N/A
Remain Hops	N/A

The *MSTP Instance Settings Page* contains the following fields:

- **Instance ID** — Lists the MSTP instances configured on the device. Possible field range is 0-15.
- **Interface** — Displays the interface for which the MSTP settings are displayed. The possible field values are:
 - *Port* — Specifies the port for which the MSTP settings are displayed.
 - *LAG* — Specifies the LAG for which the MSTP settings are displayed.
- **MSTP** — Specifies whether or not MSTP is enable on the interface. The possible field values are:
 - *Enabled* — Enables MSTP on the interface.
 - *Disabled* — Disables MSTP on the interface.
- **Port State** — Indicates whether the port is enabled for the specific instance. The possible field values are:
 - *Enabled* — Enables the port for the specific instance.
 - *Disabled* — Disables the port for the specific instance.

- **Type** — Indicates whether the port is a Boundary or Master port. The possible field values are:
 - *Boundary Port* — Indicates that the port is a Boundary port. A Boundary port attaches MST bridges to LANs in an outlying region. If the port is a Boundary port, this field also indicates whether the device on the other side of the link is working in RSTP or STP mode
 - *Master Port* — Indicates the port is a master port. A Master port provides connectivity from a MSTP region to the outlying CIST root.
 - **Role** — Indicates the port role assigned by the STP algorithm to provide to STP paths. The possible field values are:
 - *Root* — Provides the lowest cost path to forward packets to the root device.
 - *Designated* — Indicates the port or LAG through which the designated device is attached to the LAN.
 - *Alternate* — Provides an alternate path to the root device from the root interface.
 - *Backup* — Provides a backup path to the designated port path toward the Spanning Tree leaves. Backup ports occur only when two ports are connected in a loop by a point-to-point link or when a LAN has two or more connections connected to a shared segment.
 - *Disabled* — Indicates the port is not participating in the Spanning Tree.
 - **Mode** — Indicates the STP mode by which STP is enabled on the device. The possible field values are:
 - *Classic STP* — Classic STP is enabled on the device. This is the default value.
 - *Rapid STP* — Rapid STP is enabled on the device.
 - *Multiple STP* — Multiple STP is enabled on the device.
 - **Interface Priority** — Defines the interface priority for the specified instance. The default value is 128.
 - **Path Cost** — Indicates the port contribution to the Spanning Tree instance. The range should always be 1-200,000,000.
 - **Designated Bridge ID** — Displays the ID of the bridge that connects the link or shared LAN to the root.
 - **Designated Port ID** — Displays the ID of the port on the designated bridge that connects the link or the shared LAN to the root.
 - **Designated Cost** — Indicates that the default path cost is assigned according to the method selected on the Spanning Tree Global Settings page.
 - **Forward Transitions** — Indicates the number of times the LAG State has changed from a *Forwarding* state to a *Blocking* state.
 - **Remain Hops** — Indicates the hops remaining to the next destination.
2. Click Interface Table . The *MSTP Interface Table* opens.

Figure 94: MSTP Interface Table

Instance 1

#	Interface	Role	Mode	Type	Port Priority	Path Cost	Port State	Designated Cost	Designated Bridge ID	Designated Port ID	Remain Hops
1	1	N/A	N/A	N/A	120	100	N/A	N/A	N/A	N/A	N/A
2	2	N/A	N/A	N/A	128	100	N/A	N/A	N/A	N/A	N/A
3	3	N/A	N/A	N/A	128	10	N/A	N/A	N/A	N/A	N/A
4	4	N/A	N/A	N/A	120	100	N/A	N/A	N/A	N/A	N/A
5	5	N/A	N/A	N/A	128	100	N/A	N/A	N/A	N/A	N/A
6	6	N/A	N/A	N/A	128	100	N/A	N/A	N/A	N/A	N/A
7	7	N/A	N/A	N/A	128	100	N/A	N/A	N/A	N/A	N/A
8	8	N/A	N/A	N/A	120	100	N/A	N/A	N/A	N/A	N/A
9	9	N/A	N/A	N/A	128	100	N/A	N/A	N/A	N/A	N/A
10	10	N/A	N/A	N/A	128	100	N/A	N/A	N/A	N/A	N/A

Submit

- Define the *Port Priority* and the *Path Cost* fields.
- Click **Submit**. The MSTP interface settings are defined, and the device is updated.

Section 13. Configuring Multicast Forwarding

This section contains the following topics:

- Defining IGMP Snooping
- Defining Multicast Bridging Groups
- Defining Multicast Forward All Settings

Defining IGMP Snooping

When IGMP Snooping is enabled globally, all IGMP packets are forwarded to the CPU. The CPU analyzes the incoming packets and determines:

- Which ports want to join which Multicast groups.
- Which ports have Multicast routers generating IGMP queries.
- Which routing protocols are forwarding packets and Multicast traffic.

Ports requesting to join a specific Multicast group issue an IGMP report, specifying that Multicast group is accepting members. This results in the creation of the Multicast filtering database. To enable IGMP Snooping:

1. Click **Multicast Support > IGMP**. The *IGMP Snooping Page* opens:

Figure 95: IGMP Snooping Page

D-Link 10/100 Fast Ethernet Switch

System Basic Setup **Advanced Setup** Help Logout

10.6.39.150

- Interface
 - LACP Parameters
 - LAG Membership
- Forwarding Database
- Network Security
- Spanning Tree
- Multicast Support**
 - Bridge Multicast
 - Multicast Group
 - Multicast Forward All
 - IGMP
- Interface Statistics
- RMON

Enable IGMP Snooping Status ☐

#	VLAN ID	IGMP Snooping Status	Auto Learn	Host Timeout	MRouter Timeout	Leave Timeout	Edit
1	1	Disabled	Enabled	260	300	10	

Submit

The *IGMP Snooping Page* contains the following fields:

- **Enable IGMP Snooping Status** — Indicates if IGMP Snooping is enabled on the device. IGMP Snooping can be enabled only if Bridge Multicast Filtering is enabled. The possible field values are:
 - *Checked* — Enables IGMP Snooping on the device.
 - *Unchecked* — Disables IGMP Snooping on the device.
- **VLAN ID** — Specifies the VLAN ID.
- **IGMP Snooping Status** — Indicates if IGMP snooping is enabled on the VLAN. The possible field values are:
 - *Enable* — Enables IGMP Snooping on the VLAN.
 - *Disable* — Disables IGMP Snooping on the VLAN.




- **Auto Learn** — Indicates if Auto Learn is enabled on the device. If Auto Learn is enabled, the devices automatically learns where other Multicast groups are located. Enables or disables Auto Learn on the Ethernet device. The possible field values are:
 - *Enable* — Enables auto learn
 - *Disable* — Disables auto learn.
 - **Host Timeout** — Indicates the amount of time host waits to receive a message before timing out. The default time is 260 seconds.
 - **Multicast Router Timeout** — Indicates the amount of the time the Multicast router waits to receive a message before it times out. The default value is 300 seconds.
 - **Leave Timeout** — Indicates the amount of time the host waits, after requesting to leave the IGMP group and not receiving a Join message from another station, before timing out. If a Leave Timeout occurs, the switch notifies the Multicast device to stop sending traffic. The Leave Timeout value is either user-defined, or an immediate leave value. The default timeout is 10 seconds.
2. Check the *Enable IGMP Snooping Status* checkbox.
 3. Click  . The *Multicast Global Parameters Settings Page* opens:

Figure 96: Multicast Global Parameters Settings Page



VLAN ID	1
IGMP Status Enable	Disable
Auto-Learn	Enable
Host Timeout	260
MRouter Timeout	300
Leave Timeout	<input checked="" type="radio"/> 10 <input type="radio"/> Immediate Leave

Submit

4. Modify the *VLAN ID*, *IGMP Status Enable*, *Auto Learn*, *Host Timeout*, *MRouter Timeout*, and *Leave Timeout* fields.
5. Click  . The IGMP global parameters are sent, and the device is updated.

Defining Multicast Bridging Groups

The *Multicast Group Page* displays the ports and LAGs attached to the Multicast service group in the Ports and LAGs tables. The Port and LAG tables also reflect the manner in which the port or LAGs joined the Multicast group. Ports can be added either to existing groups or to new Multicast service groups. The *Multicast Group Page* permits new Multicast service groups to be created. The *Multicast Group Page* also assigns ports to a specific Multicast service address group. To define Multicast groups:

1. Click **Advanced Setup > Multicast Support > Bridge Multicast > Multicast Group**. The *Multicast Group Page* opens:

Figure 97: Multicast Group Page

The screenshot shows the D-Link web interface for configuring Multicast groups. The top navigation bar includes 'System', 'Basic Setup', 'Advanced Setup', 'Help', and 'Logout'. The left sidebar shows a tree view with 'Multicast Support' expanded, leading to 'Bridge Multicast' and then 'Multicast Group'. The main content area has a 'Create' button and a checkbox for 'Enable Bridge Multicast Filtering'. Below this is a table with columns 'VLAN ID' and 'Bridge Multicast address' (1-10). A legend at the bottom indicates 'S' for Static, 'D' for Dynamic, 'N' for Non, and 'F' for Forbidden. A 'Submit' button is at the bottom.

The *Multicast Group Page* contains the following information:

- **Enables Bridge Multicast Filtering** — Indicate if bridge Multicast filtering is enabled on the device. The possible field values are:
 - *Checked* — Enables Multicast filtering on the device.
 - *Unchecked* — Disables Multicast filtering on the device. If Multicast filtering is disabled, Multicast frames are flooded to all ports in the relevant VLAN. Disabled is the default value.
- **VLAN ID** — Identifies a VLAN and contains information about the Multicast group address.
- **Bridge Multicast Address** — Identifies the Multicast group MAC address/IP address.
- **Ports** — Displays Port that can be added to a Multicast service.

The following table contains the IGMP port and LAG members management settings:

Table 14: IGMP Port/LAG Members Table Control Settings

Port Control	Definition
D	Dynamically joins ports/LAG to the Multicast group in the Current Row.
S	Attaches the port to the Multicast group as static member in the Static Row. The port/LAG has joined the Multicast group statically in the Current Row.
F	Forbidden ports are not included the Multicast group, even if IGMP snooping designated the port to join a Multicast group.
Blank	The port is not attached to a Multicast group.

- Click **Create**. The *Add Multicast Group Page* opens:

Figure 98: Add Multicast Group Page


- Define the *VLAN ID*, *Bridge Multicast IP Address*, and *Bridge Multicast MAC Address* fields.
- Select ports to join the Multicast group.
- Define the Multicast port settings.
- Click **Submit**. The Multicast group is defined, and the device is updated.

Defining Multicast Forward All Settings

The Bridge Multicast Forward All page contains fields for attaching ports or LAGs to a device that is attached to a neighboring Multicast router/switch. Once IGMP Snooping is enabled, Multicast packets are forwarded to the appropriate port or VLAN. Unless LAGs are defined, only a Multicast Forward All table displays. To define Multicast forward all settings:

1. Click **Advanced Setup > Multicast Support > Bridge Multicast > Multicast Forward All**. The *Multicast Forward All Page* opens:

Figure 99: Multicast Forward All Page



The *Multicast Forward All Page* contains the following fields:

- **VLAN ID** — Displays the VLAN for which Multicast parameters are displayed.
- **Ports** — Ports that can be added to a Multicast service.


The following table summarizes the Multicast settings which can be assigned to ports in the *Multicast Forward All Page*.

Table 15: Bridge Multicast Forward All Router/Port Control Settings Table

Port Control	Definition
D	Attaches the port to the Multicast router or switch as a dynamic port.
S	Attaches the port to the Multicast router or switch as a static port.

Table 15: Bridge Multicast Forward All Router/Port Control Settings Table

Port Control	Definition
F	Forbidden.
Blank	The port is not attached to a Multicast router or switch.

2. Select a VLAN in the *VLAN ID* drop-down box.
3. Define the VLAN port settings.
4. Click . The Multicast forward all settings are defined, and the device is updated.

Section 14. Configuring SNMP

Simple Network Management Protocol (SNMP) provides a method for managing network devices. The device supports the following SNMP versions:

- SNMP version 1
- SNMP version 2c
- SNMP version 3

SNMP v1 and v2c

The SNMP agents maintain a list of variables, which are used to manage the device. The variables are defined in the Management Information Base (MIB). The SNMP agent defines the MIB specification format, as well as the format used to access the information over the network. Access rights to the SNMP agents are controlled by access strings.

SNMP v3

SNMP v3 applies access control and a new traps mechanism. In addition, User Security Model (USM) parameters are defined for SNMPv3, including:

- **Authentication** — Provides data integrity and data origin authentication.
- **Privacy** — Protects against the disclosure of message content. Cipher Block-Chaining (CBC) is used for encryption. Either authentication is enabled on a SNMP message, or both authentication and privacy are enabled on a SNMP message. However, privacy cannot be enabled without authentication.
- **Timeliness** — Protects against message delay or message redundancy. The SNMP agent compares incoming message to the message time information.
- **Key Management** — Defines key generation, key updates, and key use.

The device supports SNMP notification filters based on Object IDs (OIDs). OIDs are used by the system to manage device features.

SNMP v3 supports the following features:


- Security
- Feature Access Control
- Traps

The device generates the following traps:

- Copy trap

This section contains the following topics:

- Configuring SNMP Security
- Configuring SNMP Notifications

- **Use Default** — Uses the device-generated Engine ID. The default Engine ID is based on the device MAC address and is defined per standard as:
 - *First 4 octets* — first bit = 1, the rest is IANA Enterprise number.
 - *Fifth octet* — Set to 3 to indicate the MAC address that follows.
 - *Last 6 octets* — MAC address of the device.
- 2. Define the *Local Engine ID* and *Use Default* fields.
- 3. Click . The SNMP global security parameters are set, and the device is updated.

Defining SNMP Views

SNMP views provide or block access to device features or portions of features. For example, a view can be defined which provides that SNMP group A has *Read Only* (R/O) access to Multicast groups, while SNMP group B has *Read-Write* (R/W) access to Multicast groups. Feature access is granted via the MIB name or MIB Object ID. To define SNMP views:

1. Click **System > SNMP > Security > Views**. The *SNMP Security Views Page* opens:

Figure 101: SNMP Security Views Page




The *SNMP Security Views Page* contains the following fields:

- **View Name** — Displays the user-defined views. The view name can contain a maximum of 30 alphanumeric characters.
- **Object ID Subtree** — Displays the device feature OID included in or excluded from the selected SNMP view.
- **View Type** — Indicates whether the defined OID branch will be included in or excluded from the selected SNMP view.
- **Remove** — Deletes the currently selected view. The possible field values are:
 - Checked — Removes the selected view.
 - Unchecked — Maintains the list of views.

2. Click **Create**. The *Add SNMP View Page* opens:

Figure 102: Add SNMP View Page



The image shows a web-based configuration page titled "Add SNMP View". It contains several input fields and buttons. At the top, there is a "View Name" label followed by a text input field. Below this, there is a "Subtree ID Tree" label, a radio button labeled "Select from List", a large empty square box, and two buttons labeled "Up" and "Down". To the right of the "Up" and "Down" buttons is a radio button labeled "Insert" followed by a text input field. Below the "Subtree ID Tree" section, there is a "View Type" label followed by a dropdown menu currently showing "Included". At the bottom right of the form is a "Submit" button.

3. Define the *View Name* field.
4. Define the view using **Up** and **Down**.
5. Define the *View Type* field.
6. Click **Submit**. The view is defined, and the device is updated.

Defining SNMP Group Profiles

The *SNMP Group Profile Page* provides information for creating SNMP groups, and assigning SNMP access control privileges to SNMP groups. Groups allow network managers to assign access rights to specific device features, or feature aspects. To define an SNMP group:

1. Click **System > SNMP > Security > Group Profile**. The *SNMP Group Profile Page* opens:

Figure 103: SNMP Group Profile Page



The *SNMP Group Profile Page* contains the following fields:

- **Group Name** — Displays the user-defined group to which access control rules are applied. The field range is up to 30 characters.
- **Security Model** — Defines the SNMP version attached to the group. The possible field values are:
 - *SNMPv1* — SNMPv1 is defined for the group.
 - *SNMPv2c* — SNMPv2c is defined for the group.
 - *SNMPv3* — SNMPv3 is defined for the group.
- **Security Level** — Defines the security level attached to the group. Security levels apply to SNMPv3 only. The possible field values are:
 - *No Authentication* — Indicates that neither the Authentication nor the Privacy security levels are assigned to the group.

- *Authentication* — Authenticates SNMP messages, and ensures that the SNMP message's origin is authenticated.
 - *Privacy* — Encrypts SNMP messages.
 - **Operation** — Defines the group access rights. The possible field values are:
 - *Read* — Management access is restricted to read-only, and changes cannot be made to the assigned SNMP view.
 - *Write* — Management access is read-write and changes can be made to the assigned SNMP view.
 - *Notify* — Sends traps for the assigned SNMP view.
 - **Remove** — Removes SNMP groups. The possible field values are:
 - *Checked* — Removes the selected SNMP group.
 - *Unchecked* — Maintains the SNMP groups.
2. Click **Create** . The *Add SNMP Group Profile Page* opens:

Figure 104: Add SNMP Group Profile Page

Add SNMP Group Profile

Group Name	<input type="text"/>
Security Model	SNMPv1
Security Level	No Authentication
Operation	<input type="checkbox"/> Read <input type="text" value="Default"/> <input type="checkbox"/> Write <input type="text" value="Default"/> <input type="checkbox"/> Notify <input type="text" value="Default"/>

Submit

3. Define the *Group Name*, *Security Model*, *Security Level*, and *Operation* fields.
4. Click **Submit** . The SNMP group profile is added, and the device is updated.

To modify SNMP Group Settings:



1. Click **System > SNMP > Security > Group Profile**. The *SNMP Group Profile Page* opens.
2. Click  . The *SNMP Group Profile Settings Page* opens:


Figure 105: SNMP Group Profile Settings Page



The image shows a web form titled "SNMP Group Profile Settings". It contains four main sections: "Group Name" with a text input field; "Security Model" with a dropdown menu showing "SNMPv1"; "Security Level" with a dropdown menu showing "No Authentication"; and "Operation" with three checkboxes labeled "Read", "Write", and "Notify", each followed by a small dropdown menu. A "Submit" button is located at the bottom right of the form.

Group Name			
Security Model	SNMPv1		
Security Level	No Authentication		
Operation	<input type="checkbox"/> Read	<input type="checkbox"/> Write	<input type="checkbox"/> Notify

Submit

3. Modify the *Group Name*, *Security Model*, *Security Level*, and *Operation* fields.
4. Click . The SNMP group profile is modified, and the device is updated.

Defining SNMP Group Members

The *SNMP Group Membership Page* enables assigning system users to SNMP groups, as well as defining the user authentication method.

1. Click **System > SNMP > Security > Group Membership**. The *SNMP Group Membership Page* opens:

Figure 106: SNMP Group Membership Page



The *SNMP Group Membership Page* contains the following fields:

- **User Name** — Contains a list of user-defined user names. The field range is up to 30 alphanumeric characters.
- **Group Name** — Contains a list of user-defined SNMP groups. SNMP groups are defined in the *SNMP Group Profile Page*.
- **Engine ID** — Displays either the local or remote SNMP entity to which the user is connected. Changing or removing the local SNMP Engine ID deletes the SNMPv3 user database.
 - *Local* — Indicates that the user is connected to a local SNMP entity.
 - *Remote* — Indicates that the user is connected to a remote SNMP entity. If the Engine ID is defined, remote devices receive inform messages.
- **Authentication** — Displays the method used to authenticate users. The possible field values are:
 - *MD5 Key* — Users are authenticated using the HMAC-MD5 algorithm.
 - *SHA Key* — Users are authenticated using the HMAC-SHA-96 authentication level.
 - *MD5 Password* — The HMAC-MD5-96 password is used for authentication. The user should enter a password.
 - *SHA Password* — Users are authenticated using the HMAC-SHA-96 authentication level. The user should enter a password.



- *No Authentication* — No user authentication is used.
 - **Remove** — Removes users from a specified group. The possible field values are:
 - *Checked* — Removes the selected user.
 - *Unchecked* — Maintains the list of users.
2. Click . The *Add SNMP Group Membership Page* opens:

Figure 107: Add SNMP Group Membership Page



In addition to the fields in the *SNMP Group Membership Page*, the *Add SNMP Group Membership Page* contains the following fields:

- **Authentication Method** — Defines the SNMP Authentication Method.
 - **Authentication Key** — Defines the HMAC-MD5-96 or HMAC-SHA-96 authentication level. The authentication and privacy keys are entered to define the authentication key. If only authentication is required, 16 bytes are defined. If both privacy and authentication are required, 32 bytes are defined. Each byte in hexadecimal character strings is two hexadecimal digits. Each byte can be separated by a period or a colon.
 - **Privacy Key** — Defines the privacy key (LSB). If only authentication is required, 20 bytes are defined. If both privacy and authentication are required, 36 bytes are defined. Each byte in hexadecimal character strings is two hexadecimal digits. Each byte can be separated by a period or colon.
 - **Password** — Defines the password for the group member
3. Define the *User Name*, *Group Name*, *Engine ID*, *Authentication Method*, *Password*, *Authentication Key*, and *Privacy Key* fields.
4. Click . The SNMP group membership is modified, and the device is updated.

To modify SNMP Group Membership Settings:




1. Click **System > SNMP > Security > Group Membership**. The *SNMP Group Membership Page* opens.
2. Click . The *SNMP Group Membership Settings Page* opens:

Figure 108: SNMP Group Membership Settings Page



The image shows a web form titled "SNMP Group Membership Settings". The form contains the following fields and controls:

- User Name**: A text input field.
- Group Name**: A dropdown menu.
- Engine ID**: Two radio buttons labeled "Local" and "Remote", followed by a dropdown menu.
- Authentication Method**: A dropdown menu with "None" selected.
- Password**: A text input field.
- Authentication Key**: A text input field.
- Privacy Key (16 Hexa Chars)**: A text input field.
- Submit**: A button located below the form fields.


3. Modify the *Group Name*, *Engine ID*, *Authentication Method*, *Password*, *Authentication Key*, and *Privacy Key* fields.
4. Click . The SNMP group membership is modified, and the device is updated.

Defining SNMP Communities

Access rights are managed by defining communities in the *SNMP Communities Page*. When the community names are changed, access rights are also changed. SNMP communities are defined only for SNMP v1 and SNMP v2c. To define SNMP communities:

1. Click **System > SNMP > Security > Communities**. The *SNMP Communities Page* opens:

Figure 109: SNMP Communities Page



The *SNMP Communities Page* is divided into the following tables:

- Basic Table
- Advanced Table

SNMP Communities Basic Table

The *SNMP Communities Basic Table* contains the following fields:

- **Management Station** — Displays the management station IP address for which the basic SNMP community is defined.
- **Community String** — Defines the password used to authenticate the management station to the device.
- **Access Mode** — Defines the access rights of the community. The possible field values are:
 - *Read Only* — Management access is restricted to read-only, and changes cannot be made to the community.
 - *Read Write* — Management access is read-write and changes can be made to the device configuration, but not to the community.

- *SNMP Admin* — User has access to all device configuration options, as well as permissions to modify the community.
- **View Name** — Contains a list of user-defined SNMP views
- **Remove** — Removes a community. The possible field values are:
 - *Checked* — Removes the selected SNMP community.
 - *Unchecked* — Maintains the SNMP communities.

SNMP Communities Advanced Tables

The *SNMP Communities Advanced Tables* contains the following fields:




- **Management Station** — Displays the management station IP address for which the advanced SNMP community is defined.
 - **Community String** — Defines the password used to authenticate the management station to the device.
 - **Group Name** — Defines advanced SNMP community group names.
 - **Remove** — Removes a community. The possible field values are:
 - *Checked* — Removes the selected SNMP communities.
 - *Unchecked* — Maintains the SNMP communities.
2. Click . The *Add SNMP Community Page* opens:

Figure 110: Add SNMP Community Page




The image shows a web form titled "Add SNMP Community". It contains several input fields and a "Submit" button. The form is divided into two main sections: "Basic" and "Advanced". The "Basic" section includes fields for "SNMP Management Station" (with a radio button and a text input), "Community String" (with a radio button and a text input), "Access Mode" (a dropdown menu), and "View Name" (a checkbox and a dropdown menu). The "Advanced" section includes a "Group Name" field (a dropdown menu). The "Submit" button is located at the bottom right of the form.

3. Define the *SNMP Management Station*, *Community String*, and *Basic or Advanced* fields.
4. Click . The SNMP community is added, and the device is updated.

To modify SNMP Group Membership Settings:

1. Click **System > SNMP > Security > Communities**. The *SNMP Communities Page* opens.
2. Click . The *SNMP Community Settings Page* opens:

Figure 111: SNMP Community Settings Page



The image shows a web interface titled "SNMP Community Settings". It contains several input fields and a submit button. The "SNMP Management Station" field is a text box. The "Community String" field is a text box. There are two radio buttons: "Basic" and "Advanced". The "Basic" radio button is selected. The "Access Mode" is a dropdown menu with "Read Only" selected. The "View Name" is a checkbox that is unchecked. The "Group Name" is a dropdown menu. The "Manage OOB" is a checkbox that is unchecked. A "Submit" button is at the bottom.

SNMP Community Settings

SNMP Management Station


Community String

☐ Basic Access Mode Read Only ☐ View Name

☐ Advanced Group Name

Manage OOB

Submit

3. Modify the *SNMP Management Station*, *Community String*, and *Basic or Advanced* fields.
4. Click . The SNMP community is modified, and the device is updated.

Configuring SNMP Notifications

This section contains information for configuring SNMP Notifications, and contains the following topics:

- Defining SNMP Notification Global Parameters
- Defining SNMP Notification Filters
- Defining SNMP Notification Recipients

Defining SNMP Notification Global Parameters

The *SNMP Notification Properties Page* contains parameters for defining SNMP notification parameters. To define SNMP notification global parameters:

1. Click **System > SNMP > Notification > Properties**. The *SNMP Notification Properties Page* opens:

Figure 112: SNMP Notification Properties Page



The *SNMP Notification Properties Page* contains the following fields:

- **Enable SNMP Notifications** — Specifies whether the device can send SNMP notifications. The possible field values are:
 - *Enable* — Enables SNMP notifications.
 - *Disable* — Disables SNMP notifications.
 - **Enable Authentication Notifications** — Specifies whether SNMP authentication failure notification is enabled on the device. The possible field values are:
 - *Enable* — Enables the device to send authentication failure notifications.
 - *Disable* — Disables the device from sending authentication failure notifications.
2. Define the *Enable SNMP Notification* and *Enable Authentication Notifications* fields.
 3. Click **Submit**. The SNMP notification properties are defined, and the device is updated.

Defining SNMP Notification Filters

The *SNMP Notification Filter Page* permits filtering traps based on OIDs. Each OID is linked to a device feature or a portion of a feature. The *SNMP Notification Filter Page* also allows network managers to filter notifications. To define SNMP notification filters:

1. Click **System > SNMP > Notification > Notification Filter**. The *SNMP Notification Filter Page* opens:

Figure 113: SNMP Notification Filter Page



The *SNMP Notification Filter Page* contains the following fields:

- **Filter Name** — Contains a list of user-defined notification filters.
- **Object ID Subtree** — Displays the OID for which notifications are sent or blocked. If a filter is attached to an OID, traps or informs are generated and sent to the trap recipients. OIDs are selected from either the *Select from* field or the *Object ID* field.
- **Filter Type** — Indicates whether to send traps or informs relating to the selected OID.
 - *Excluded* — Does not send traps or informs.
 - *Included* — Sends traps or informs.
- **Remove** — Deletes filters.
 - Checked — Deletes the selected filter.
 - Unchecked — Maintains the list of filters.

2. Click **Create**. The *Add SNMP Notification Filter Page* opens:

Figure 114: Add SNMP Notification Filter Page

Add SNMP Notification Filter

Filter Name

New Object Identifier Tree

Select from List

system

interfaces

ip

icmp

tcp

Up

Down

Object ID

Filter Type

Included

Submit

- 3. Define the *Filter Name*, *New Object Identifier Tree*, and *Filter Type* fields.
- 4. Click **Submit**. The SNMP notification filter is defined, and the device is updated.

Defining SNMP Notification Recipients

The *SNMP Notification Receiver Page* contains information for defining filters that determine whether traps are sent to specific users, and the trap type sent. SNMP notification filters provide the following services:

- Identifying Management Trap Targets
- Trap Filtering
- Selecting Trap Generation Parameters
- Providing Access Control Checks

To define SNMP notification filters:

1. Click **System > SNMP > Notification > Notification Receiver**. The *SNMP Notification Receiver Page* opens:

Figure 115: SNMP Notification Receiver Page



The *SNMP Notification Receiver Page* is divided into the following tables:

- SNMPv1,2c Notification Recipient
- SNMPv3 Notification Recipient

SNMPv1,2c Notification Recipient

The *SNMPv1,2 cNotification Recipient* table contains the following fields:

- **Recipients IP** — Displays the IP address to which the traps are sent.
- **Notification Type** — Displays the notification sent. The possible field values are:
 - *Trap* — Indicates traps are sent.
 - *Inform* — Indicates informs are sent.
- **Community String** — Displays the community string of the trap manager.
- **Notification Version** — Displays the trap type. The possible field values are:
 - *SNMP V1* — Indicates that SNMP Version 1 traps are sent.
 - *SNMP V2c* — Indicates that SNMP Version 2 traps are sent.
- **UDP Port** — Displays the UDP port used to send notifications. The default is 162.
- **Filter Name** — Indicates if the SNMP filter for which the SNMP Notification filter is defined.
- **Timeout** — Indicates the amount of time (in seconds) the device waits before re-sending informs. The default is 15 seconds.
- **Retries** — Indicates the amount of times the device re-sends an inform request. The default is 3 seconds.
- **Remove** — Deletes the currently selected recipient. The possible field values are:
 - *Checked* — Removes the selected recipient from the list of recipients.
 - *Unchecked* — Maintains the list of recipients.

SNMPv3 Notification Recipient

The *SNMPv3 Notification Recipient* table contains the following fields:

- **Recipient IP** — Displays the IP address to which the traps are sent.
- **Notification Type** — Displays the type of notification sent. The possible field values are:
 - *Trap* — Indicates that traps are sent.
 - *Inform* — Indicates that informs are sent.
- **User Name** — Displays the user to which SNMP notifications are sent.
- **Security Level** — Displays the means by which the packet is authenticated. The possible field values are:
 - *No Authentication* — Indicates that the packet is neither authenticated nor encrypted.
 - *Authentication* — Indicates that the packet is authenticated.
- **UDP Port** — The UDP port used to send notifications. The field range is 1-65535. The default is 162.
- **Filter Name** — Includes or excludes SNMP filters.
- **Timeout** — The amount of time (seconds) the device waits before resending informs. The field range is 1-300. The default is 10 seconds.
- **Retries** — The amount of times the device resends an inform request. The field range is 1-255. The default is 3.
- **Remove** — Deletes the currently selected recipient. The possible field values are:
 - *Checked* — Removes the selected recipient from the list of recipients.
 - *Unchecked* — Maintains the list of recipients.

2. Click **Create**. The *Add SNMP Notification Receiver Page* opens:

Figure 116: Add SNMP Notification Receiver Page

Add SNMP Notification Receiver

Recipient IP

Notification Type

☒ SNMPv1,2

Community String

Notification Version

☐ SNMPv3

User Name


Security Level

UDP Port

Filter Name

Timeout (sec)

Retries

3. Define the *Recipient IP*, *Notification Type*, *SNMPV1,v2c* or *SNMPv3*, *UPD Port*, *Filter Name*, *Timeout*, and *Retries* fields.
4. Click . The SNMP Notification recipients are defined, and the device is updated.

To modify SNMP notification recipients:




1. Click **System > SNMP > Notification > Notification Receiver**. The *SNMP Notification Receiver Page* opens.
2. Click . The *SNMP Notification Receiver Settings Page* opens:

Figure 117: SNMP Notification Receiver Settings Page



The image shows the 'SNMP Notification Receiver Settings' page. It contains several sections for configuring SNMP settings. The first section has 'Recipient IP' set to '4.4.4.4' and 'Notification Type' set to 'Traps'. The second section is for 'SNMPv1,2' with 'Community String' set to 'public' and 'Notification Version' set to 'SNMPv2'. The third section is for 'SNMPv3' with 'User Name' set to 'admin' and 'Security Level' set to 'NoAuthentication'. The fourth section has 'UDP Port' set to '162', 'Filter Name' set to '1', 'Timeout' set to '15', and 'Retries' set to '3'. A 'Submit' button is at the bottom.

SNMP Notification Receiver Settings	
Recipient IP	4.4.4.4
Notification Type	Traps
SNMPv1,2	
Community String	public
Notification Version	SNMPv2
SNMPv3	
User Name	admin
Security Level	NoAuthentication
UDP Port	162
Filter Name	1
Timeout	15
Retries	3
Submit	

3. Modify the *Notification Type*, *SNMPV1,v2c* or *SNMPv3*, *UPD Port*, *Filter Name*, *Timeout*, and *Retries* fields.
4. Click . The SNMP notification recipients are defined, and the device is updated.

Section 15. Configuring Quality of Service

Quality of Service (QoS) provides the ability to implement QoS and priority queuing within a network. For example, certain types of traffic that require minimal delay, such as Voice, Video, and real-time traffic can be assigned a high priority queue, while other traffic can be assigned a lower priority queue. The result is an improved traffic flow for traffic with high demand. QoS is defined by:

- **Classification** — Specifies which packet fields are matched to specific values. All packets matching the user-defined specifications are classified together.
- **Action** — Defines traffic management where packets are forwarded are based on packet information, and packet field values such as *VLAN Priority Tag (VPT)* and *DiffServ Code Point (DSCP)*.

VPT Classification Information

VLAN Priority Tags (VPT) are used to classify packets by mapping packets to one of the egress queues. VPT-to-queue assignments are user-definable. Packets arriving untagged are assigned a default VPT value, which is set on a per-port basis. The assigned VPT is used to map the packet to the egress queue. The table below details the VPT-to-queue default settings:

Table 16: CoS to Queue Mapping Table Default values

CoS Value	Forwarding Queue Values
0	q1 (Lowest Priority)
1	q0 (Lowest Priority)
2	q0 (Lowest Priority)
3	q1 (Lowest Priority)
4	q2
5	q2
6	q3
7	q3

DSCP values can be mapped to priority queues. DSCP mapping is enabled on a per-system basis. The following table contains the default DSCP mapping to egress queue values:

Table 17: DSCP to Queue Mapping Table Default Values

DSCP Value	Forwarding Queue Values
0-15	q1 (Lowest Priority)
16-31	q2
32-47	q3
48-63	q4

CoS Services

After packets are assigned to a specific egress queue, CoS services can be assigned to the queue. Egress queues are configured with a scheduling scheme by one of the following methods:

- **Strict Priority** — Ensures that time-sensitive applications are always forwarded. Strict Priority (SP) allows the prioritization of mission-critical, time-sensitive traffic over less time-sensitive applications. For example, under SP, voice over IP (VoIP) traffic can be prioritized so that it is forwarded before FTP or e-mail (SMTP) traffic.
- **Weighted Round Robin** — Ensures that a single application does not dominate the device forwarding capacity. Weighted Round Robin (WRR) forwards entire queues in a round robin order. All queues can participate in WRR, except SP queues. SP queues are serviced before WRR queues. If the traffic flow is minimal, and SP queues do not occupy the whole bandwidth allocated to a port, the WRR queues can share the bandwidth with the SP queues. This ensures that the remaining bandwidth is distributed according to the weight ratio. If WRR is selected, the following weights are assigned to the queues: 1, 2, 4, 8.

The *Basic Setup > Quality of Service* tab provides links to the following topics:

- General Settings
- Queue Mapping

Configuring Quality of Service General Settings

This section contains information for defining QoS global parameters, QoS queue settings, and QoS interface settings, and contains the following topics:


- Defining QoS Settings
- Defining Bandwidth Settings
- Defining Queue Settings
- Mapping QoS Queues

Defining QoS Settings

The *QoS General Settings Page* contains fields for enabling or disabling CoS. In addition, the Trust mode can be selected. The Trust mode relies on predefined fields within the packet to determine the egress queue settings. To define the QoS settings:


1. Click **Basic Setup > Quality of Service > General Settings > General Settings**. The *QoS General Settings Page* opens.

Figure 118: QoS General Settings Page



The *QoS General Settings Page* displays the following fields:

- **Quality of Service** — Determines whether QoS is enabled on the interface. The possible values are:
 - *Enable* — Enables QoS on the interface.
 - *Disable* — Disables QoS on the interface.

- **Trust Mode** — Defines which packet fields to use for classifying packets entering the device. When no rules are defined, the traffic containing the predefined packet CoS field is mapped according to the relevant trust modes table. Traffic not containing a predefined packet field is mapped to best effort. The possible Trust Mode field values are:
 - *CoS* — Classifies traffic based on the CoS tag value.
 - *DSCP* — Classifies traffic based on the DSCP tag value.
- 2. Select *Enable* in the *Quality of Service* field.
- 3. Define the *Trust Mode* field.
- 4. Click . Quality of Service is enabled on the device.

Defining Bandwidth Settings

The *Bandwidth Settings Page* defines the bandwidth settings for a specified egress interface. Modifying queue scheduling affects the queue settings globally. To define the bandwidth settings:

1. Click **Basic Setup > Quality of Service > General Settings > Bandwidth Settings**. The *Bandwidth Settings Page* opens.

Figure 119: Bandwidth Settings Page

#	Port	Ingress Rate Limit		Egress Shaping Rates	Edit
		Status	Rate Limit	CIR	
1	1				
2	2				
3	3				
4	4				
5	5				
6	6				
7	7				
8	8				
9	9				
10	10				

The *Bandwidth Settings Page* displays the following fields:


- **Status** — Indicates if rate limiting is enabled on the interface. The possible field values are:
 - *Enable* — Indicates that rate limiting is enabled on the interface.
 - *Disable* — Indicates that rate limiting is disabled on the interface.
 - **Rate Limit** — Configures the rate to which traffic is limited. The range is 70 – 285,000 kbps.
 - **Committed Information Rate (CIR)** — Defines the CIR rate. The possible field range is 4096-1,000,000,000.
2. Define the fields.
 3. Click **Submit**. The bandwidth settings are defined, and the device is updated.

Modifying QoS Interface Settings

The *QoS Interface Page* allows network managers to modify the QoS settings assigned to a specific interface. To set the QoS interface settings:

1. Click **System > QoS > General Settings > Interface Settings**. The *QoS Interface Page* opens.

Figure 120: QoS Interface Page



The *QoS Interface Page* contains the following fields:


- **Interface** — The port or LAG for which the default CoS policy is defined.
- **Trust Mode** — Indicates whether or not Trust Mode is enabled on the interface. The possible field values are:
 - *Not enabled* — Trust mode is not enabled on the interface.
 - *Enabled* — Trust mode is enabled on the interface.
- **Default CoS for Incoming Traffic** — The default CoS value for incoming packets for which a VLAN tag is not defined. The possible field values are 0-7. The default CoS is 0.

2. Click . The *Edit Interface Settings Page* opens:

Figure 121:Edit Interface Settings Page

Interface	<input checked="" type="radio"/> Port	1	<input type="radio"/> LAG	
Disable "Trust" Mode on Interface	<input type="checkbox"/>			
Set Default CoS For Incoming Traffic To	0			

Submit


3. Define the *Disable Trust Mode*, *Default CoS*, and *Restore Defaults* fields.
4. Click . The QoS Interface settings are modified, and the device is updated.

Defining Queue Settings

The *Queue Page* contains fields for defining the QoS queue forwarding types. To set the queue settings:

1. Click **Basic Setup > Quality of Service > General Settings > Queue**. The *Queue Page* opens.

Figure 122: Queue Page



The *Queue Page* contains the following fields:

- **Strict Priority** — Specifies whether traffic scheduling is based strictly on the queue priority.
 - **WRR** — Assigns WRR weights to queues. This field is enabled only for queues in WRR queue mode. If a queue is set to 0 weight, the queue is not operational and is effectively closed. Each queue has a weight range, queues 1-3 have the range 0-255, and queue 4 has the range 1-255.
2. Select *Strict Priority* or *WRR Fields*.
 3. Click **Submit**. The queue settings are set, and the device is updated.

Mapping QoS Queues

This section contains information for mapping QoS queues, and includes the following topics:

- Mapping CoS Values to Queues
- Mapping DSCP Values to Queues

Mapping CoS Values to Queues

The *CoS to Queue Page* contains fields for mapping CoS values to traffic queues. To map CoS values to queues:

1. Click **Basic Setup > Quality of Service > Queue Mapping > CoS to Queue**. The *CoS to Queue Page* opens.

Figure 123: CoS to Queue Page

#	Class of Service	Queue
1	0	2
2	1	1
3	2	1
4	3	2
5	4	3
6	5	3
7	6	4
8	7	4

Restore Defaults ☐

Submit

The *CoS to Queue Page* contains the following fields:

- **Class of Service** — Specifies the CoS priority tag values, where zero is the lowest and 7 is the highest.
 - **Queue** — Defines the traffic forwarding queue to which the CoS priority is mapped. Four traffic priority queues are supported.
 - **Restore Defaults** — Restores the device factory defaults for mapping CoS values to a forwarding queue.
2. Define the queue number in the *Queue* field next to the required CoS value.
 3. Click **Submit**. The CoS value is mapped to a queue, and the device is updated.

Mapping DSCP Values to Queues

The *DSCP to Queue Page* contains fields for mapping DSCP settings to traffic queues. For example, a packet with a DSCP tag value of 3 can be assigned to queue 2. To map CoS values to queues:

1. Click **Basic Setup > Quality of Service > Queue Mapping > DSCP to Queue**. The *DSCP to Queue Page* opens.

Figure 124: DSCP to Queue Page

The screenshot shows the D-Link web interface for the DES-3010FA/GA switch. The left sidebar contains a navigation tree with the following structure:

- System
 - 10.6.39.150
 - Interface
 - Interface Configuration
 - Interface Properties
 - IP Configuration
 - VLAN
 - Quality of Service
 - General Settings
 - General Settings
 - Bandwidth Settings
 - Interface Settings
 - Queue
 - Queue Mapping
 - CoS to Queue
 - DSCP to Queue

The main content area is titled "D-Link" and shows a "10/100 Fast Ethernet Switch" configuration. The "DSCP to Queue" page displays a table with the following data:

DSCP In	Queue
0	1
1	1
2	1
3	1
4	1
5	1
6	1
7	1
8	1
9	1
10	1
11	1
12	1
13	1
14	1
15	1
16	2
17	2
18	2
19	2

The *DSCP to Queue Page* contains the following fields:

- **DSCP In** — Displays the incoming packet's DSCP value.
 - **Queue** — Specifies the traffic forwarding queue to which the DSCP priority is mapped. Four traffic priority queues are supported.
2. Define the queue number in the *Queue* field next to the required DSCP value.
 3. Click **Submit**. The DSCP value is mapped to a queue, and the device is updated.

Section 16. Managing System Files

File maintenance includes both configuration file management as well as device access. This section contains the following topics:

- File Management Overview
- Downloading System Files
- Uploading System Files
- Copying Files

File Management Overview

The configuration file structure consists of the following configuration files:

- **Startup Configuration File** — Contains the commands required to reconfigure the device to the same settings as when the device is powered down or rebooted. The Startup file is created by copying the configuration commands from the Running Configuration file or the Backup Configuration file.
- **Running Configuration File** — Contains all configuration file commands, as well as all commands entered during the current session. After the device is powered down or rebooted, all commands stored in the Running Configuration file are lost. During the startup process, all commands in the Startup file are copied to the Running Configuration File and applied to the device. During the session, all new commands entered are added to the commands existing in the Running Configuration file. Commands are not overwritten. To update the Startup file, before powering down the device, the Running Configuration file must be copied to the Startup Configuration file. The next time the device is restarted, the commands are copied back into the Running Configuration file from the Startup Configuration file.
- **Image files** — Software upgrades are used when a new version file is downloaded. The file is checked for the right format, and that it is complete. After a successful download, the new version is marked, and is used after the device is reset.

Downloading System Files

There are two types of files, firmware files and configuration files. The firmware files manage the device, and the configuration files configure the device for transmissions. Only one type of download can be performed at any one time. To download a file:

- Click **System > File Management > File Download**. The *File Download Page* opens.

Figure 125: File Download Page

D-Link

D-Link DES-9010D4 10/100 Fast Ethernet Switch

Power Diagnostic BR-232 Console DCE, 9600, 8, 0, 1

1 2 3 4 5 6 7 8

Link Act Speed Link Act Speed Link Act Speed

Q1 Link Act Q2

System Basic Setup Advanced Setup Help Logout

10.6.39.150

- General
- Description
- Time
- Reset
- SNTP
- Syslog
- Management Security
- File Management
 - File Download
 - File Upload
 - Copy Files
- SNMP
- Diagnostics

Firmware Download ☒

Configuration Download ☐

Firmware Download

TFTP Server IP Address

Source File Name

Destination File 1259x781

Configuration Download

TFTP Server IP Address

Source File Name

Destination File

The *File Download Page* is divided into the following sections:

- Firmware Download
- Configuration Download

Firmware Download

The *Firmware Download* section contains the following fields:

- **Firmware Download** — Indicates that the download is for firmware. If *Firmware Download* is selected, the Configuration Download fields are grayed out.
- **TFTP Server IP Address** — Specifies the TFTP Server IP Address from which files are downloaded.
- **Source File Name** — Specifies the file to be downloaded.
- **Destination File** — Specifies the destination file type to which the file is downloaded. The possible field values are:
 - *Software Image* — Downloads the Image file.


- *Boot Code* — Downloads the Boot file.
- **Download to Master Only** — Downloads the system file only to the Master
- **Download to All Units** — Downloads the system file to all units

Configuration Download

The *Configuration Download* section contains the following fields:

- **Configuration Download** — Indicates that the download is for configuration files. If *Configuration Download* is selected, the Firmware Download fields are grayed out.
- **TFTP Server IP Address** — Specifies the TFTP Server IP Address from which the configuration files are downloaded.
- **Source File Name** — Specifies the configuration files to be downloaded.
- **Destination File** — Specifies the destination file to which the configuration file is downloaded. The possible field values are:
 - *Running Configuration* — Downloads commands into the Running Configuration file.
 - *Startup Configuration* — Downloads the Startup Configuration file, and overwrites the old Startup Configuration file.

To Download files:

1. Open the *File Download Page*.
2. Select the file type.
3. Define the TFTP server address.
4. Define the *Source File Name* and *Destination File* fields.
5. Click . The files are downloaded.

Uploading System Files

The *File Upload Page* contains fields for uploading the software from the device to the TFTP server. To upload a system file:

1. Click **System > File Management > File Upload**. The *File Upload* page opens:

Figure 126: File Upload Page

The screenshot shows the D-Link web interface for file upload. The top header includes the D-Link logo and a status bar with device information. The left sidebar contains a navigation tree with 'File Upload' selected. The main content area is divided into two sections: 'Software Image Upload' and 'Configuration Upload'. The 'Software Image Upload' section has fields for 'TFTP Server IP Address' and 'Destination File Name'. The 'Configuration Upload' section has fields for 'TFTP Server IP Address', 'Destination File Name', and 'Transfer file name' (with a dropdown menu showing 'Running Configuration'). A 'Submit' button is located at the bottom of the form.

The *File Upload Page* is divided into the following sections:

- Software Image Upload
- Configuration Upload

Upload Type

The *Upload Type* section contains the following fields:

- **Firmware Upload** — Specifies that the software image file is uploaded. If *Firmware Upload* is selected, the Configuration Upload fields are grayed out.
- **Configuration Upload** — Specifies that the Configuration file is uploaded. If *Configuration Upload* is selected, the Software Image Upload fields are grayed out.

Software Image Upload

The *Software Image Upload* section contains the following fields:


- **TFTP Server IP Address** — Specifies the TFTP Server IP Address to which the Software Image is uploaded.
- **Destination File Name** — Specifies the software image file path to which the file is uploaded.

Configuration Upload

The *Configuration Upload* section contains the following fields:

- **TFTP Server IP Address** — Specifies the TFTP Server IP Address to which the Configuration file is uploaded.
- **Destination File Name**— Specifies the file name to which the Startup Configuration file is uploaded.
- **Transfer file name** — Specifies the Configuration file name that is uploaded. The possible field values are:
 - *Running Configuration* — Uploads the Running Configuration file.
 - *Startup Configuration* — Uploads the Startup Configuration file.

To upload files:


1. Open the *File Upload Page*.
2. Define the file type to upload.
3. Define the fields.
4. Click . The software is uploaded to the device.

Copying Files

Files can be copied and deleted from the *Copy Files Page*. To copy files:

1. Click **System > File Management > Copy Files**. The *Copy Files Page* opens:

Figure 127: Copy Files Page



The *Copy Files Page* contains the following fields:

- **Copy Configuration** — Copies the Running Configuration file to the Startup Configuration file.
 - **Source** — Indicates the Running Configuration file is selected.
 - **Destination** — Indicates the Startup Configuration file is selected.
 - **Restore Configuration Factory Defaults** — Resets the Configuration file to the factory defaults. The factory defaults are reset after the device is reset. When unselected, the device maintains the current Configuration file.
2. Select *Copy Configuration*.
 3. Click **Submit**. The file is copied.

Restoring the Default Configuration File

1. Click **System > File Management > Copy Files**. The *Copy Files Page* opens.
2. Select *Restore Configuration Factory Defaults*.
3. Click **Submit**. The factory defaults are restored, and the device is updated.

Section 17. Managing System Logs

This section provides information for managing system logs. The system logs enable viewing device events in real time, and recording the events for later usage. System Logs record and manage events and report errors and informational messages.

Event messages have a unique format, as per the Syslog protocols recommended message format for all error reporting. For example, Syslog and local device reporting messages are assigned a severity code, and include a message mnemonic, which identifies the source application generating the message. It allows messages to be filtered based on their urgency or relevancy. Each message severity determines the set of event logging devices that are sent per each event message.

The following table lists the log severity levels:

Table 18: System Log Severity Levels

Severity	Level	Message
Emergency	Highest (0)	The system is not functioning.
Alert	1	The system needs immediate attention.
Critical	2	The system is in a critical state.
Error	3	A system error has occurred.
Warning	4	A system warning has occurred.
Notice	5	The system is functioning properly, but a system notice has occurred.
Informational	6	Provides device information.
Debug	7	Provides detailed information about the log. If a Debug error occurs, contact Customer Tech Support.

This section includes the following topics:

- Enabling System Logs
- Viewing the Device Memory Logs
- Viewing the FLASH Logs
- Defining Servers Log Parameters

Enabling System Logs

The *Syslog Properties Page* contains fields for defining which events are recorded to which logs. It contains fields for enabling logs globally, and parameters for defining logs. Log messages are listed from the highest severity to the lowest severity level. To define system log parameters:

1. Click **System > Syslog > Properties**. The *Syslog Properties Page* opens.

Figure 128: Syslog Properties Page

Severity	Console	RAM Logs	Log File
Emergency	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Alert	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Critical	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Error	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Warning	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Notice	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Informational	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Debug	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

The *Syslog Properties Page* contains the following fields:

- **Enable Logging** — Indicates if device global logs for Cache, File, and Server Logs are enabled. Console logs are enabled by default. The possible field values are:
 - *Checked* — Enables device logs.
 - *Unchecked* — Disables device logs.
- **Severity** — The following are the available log severity levels:
 - *Emergency* — The highest warning level. If the device is down or not functioning properly, an emergency log message is saved to the specified logging location.
 - *Alert* — The second highest warning level. An alert log is saved, if there is a serious device malfunction; for example, all device features are down.
 - *Critical* — The third highest warning level. A critical log is saved if a critical device malfunction occurs; for example, two device ports are not functioning, while the rest of the device ports remain functional.
 - *Error* — A device error has occurred, for example, if a single port is offline.
 - *Warning* — The lowest level of a device warning. The device is functioning, but an operational problem has occurred.

- *Notice* — Provides device information.
- *Informational* — Provides device information.
- *Debug* — Provides debugging messages.



Note

When a severity level is selected, all severity level choices above the selection are selected automatically.


- **Console** — Defines the minimum severity level from which logs are sent to the console.
 - **RAM Logs** — Defines the minimum severity level from which logs are sent to the RAM Log kept in RAM (Cache).
 - **Log File**— Defines the minimum severity level from which logs are sent to the log file kept in FLASH memory.
2. Define the *Logging*, *Enable*, and *Severity* fields.
 3. Click. The global log parameters are set, and the device is updated.

Viewing the Device Memory Logs

The *Device Memory Log Page* contains all system logs in a chronological order that are saved in RAM (Cache). To open the *Device Memory Log Page*:

- Click **System > Syslog > Memory**. The *Device Memory Log Page* opens.

Figure 129: Device Memory Log Page



# Log Index	Log Time	Severity	Description
1 2147480269	01-Jan-2000 01:17:13	Emergency	%OOS_CLI-F-GETFSWTBL: Failed to get #5wEntry, #index = 11 ***** FATAL ERROR ***** Reporting Task: SNMP Software Version: 1.0.0.31 (date: 23-Mar-2005 time: 17:48:35) ***** END OF FATAL ERROR *****
2 2147480730	01-Jan-2000 01:08:36	Emergency	%OOS_CLI-F-GETFSWTBL: Failed to get #5wEntry, #index = 11 ***** FATAL ERROR ***** Reporting Task: SNMP Software Version: 1.0.0.31 (date: 23-Mar-2005 time: 17:48:35) ***** END OF FATAL ERROR *****
3 2147480892	01-Jan-2000 01:06:58	Error	%ERHG-E-SEND: PGPPCS: Trying to set tag doOedAggIndex\$select which does not exist in the page.
4 2147481363	01-Jan-2000 01:16:59	Emergency	%OOS_CLI-F-GETFSWTBL: Failed to get #5wEntry, #index = 11 ***** FATAL ERROR ***** Reporting Task: SNMP Software Version: 1.0.0.31 (date: 23-Mar-2005 time: 17:48:35) ***** END OF FATAL ERROR *****
5 2147481523	01-Jan-2000 01:05:52	Error	%ERHG-E-SEND: ERROR - in <RL_scalarGet> tag, can not get the MB scalar: rAAAAUnlockUserName
6 2147481683	01-Jan-2000 01:05:31	Error	%ERHG-E-SEND: ERROR - in <RL_scalarGet> tag, can not get the MB scalar: rAAAAUnlockUserName
7 2147481843	01-Jan-2000 02:53:29	Error	%ERHG-E-SEND: ERROR - in <RL_scalarGet> tag, can not get the MB scalar: rAAAAUnlockUserName
8 2147482003	01-Jan-2000 02:53:21	Error	%ERHG-E-SEND: ERROR - in <RL_scalarGet> tag, can not get the MB scalar: rAAAAUnlockUserName
9 2147482163	01-Jan-2000 02:52:33	Error	%ERHG-E-SEND: ERROR - in <RL_scalarGet> tag, can not get the MB scalar: rAAAAUnlockUserName
10 2147482264	01-Jan-2000 01:03:47	Error	%UNT-E-AppErr: Errors occurred during initialization
11 2147482409	01-Jan-2000 01:01:37	Error	%ERHG-E-SEND: Int: Port key is not a port-channel #index:
12 2147482534	01-Jan-2000 01:01:37	Error	%ERHG-E-SEND: Int: Port key is not a port-channel #index:
13 2147482655	01-Jan-2000 01:03:47	Error	%UNT-E-AppErr: Errors occurred during initialization

The *Device Memory Log Page* contains the following fields:

- Log Index** — Displays the log number.
- Log Time** — Displays the time at which the log was generated.
- Severity** — Displays the log severity.
- Description** — Displays the log message text.

Clearing Device Memory Logs

Message logs can be cleared from the *Device Memory Log Page*. To clear message logs:


- Click **System > Syslog > Memory**. The *Device Memory Log Page* opens.
- Click **Clear Logs**. The message logs are cleared.

Viewing the FLASH Logs

The *Syslog Flash Page* contains information about log entries saved to the log file in Flash, including the time the log was generated, the log severity, and a description of the log message. The message log is available after reboot. To view the message logs:

- Click **System > Syslog > Flash**. The **Syslog Flash Page** opens:

Figure 130: Syslog FLASH Page



The *Syslog Flash Page* contains the following fields:

- Log Index** — Displays the log number.
- Log Time** — Displays the time at which the log was generated.
- Severity** — Displays the log severity.
- Description** — Displays the log message text.

Clearing FLASH Logs

Message logs can be cleared from the *Syslog Flash Page*. To clear message logs:


- Click **System > Syslog > Flash**. The **Flash Page** opens.
- Click **Clear Logs**. The message logs are cleared.

Defining Servers Log Parameters

The *Log Server Settings Page* contains information for viewing and configuring the remote log servers. New log servers can be defined, and the log severity sent to each server. To open the *Log Server Settings Page*:

1. Click **System > Syslog > Servers**. The *Log Server Settings Page* opens.

Figure 131: Log Server Settings Page



The *Log Server Settings Page* contains the following fields:

- **Server** — Specifies the server to which logs can be sent.
 - **UDP Port** — Defines the UDP port to which the server logs are sent. The possible range is 1 - 65535. The default value is 514.
 - **Facility** — Defines an application from which system logs are sent to the remote server. Only one facility can be assigned to a single server. If a second facility level is assigned, the first facility is overridden. All applications defined for a device utilize the same facility on a server. The field default is Local 7. The possible field values are *Local 0 - Local 7*.
 - **Description** — A user-defined server description.
 - **Minimum Severity** — Indicates the minimum severity from which logs are sent to the server. For example, if *Notice* is selected, all logs with a severity level of *Notice* and higher are sent to the remote server.
 - **Remove** — Deletes the currently selected server from the Servers list. The possible field values are:
 - *Checked* — Removes the selected server from the *Servers Log Parameters Page*. Once removed, logs are no longer sent to the removed server.
 - *Unchecked* — Maintains the remote servers.
2. Click. The server log parameters are set, and the device is updated.

Section 18. Managing Device Diagnostics

This section contains the following topics:

- Configuring Port Mirroring
- Viewing Integrated Cable Tests
- Viewing Optical Transceivers
- Viewing the CPU Utilization

Configuring Port Mirroring

Port mirroring monitors and mirrors network traffic by forwarding copies of incoming and outgoing packets from one port to a monitoring port. Port mirroring can be used as a diagnostic tool as well as a debugging feature. Port mirroring also enables switch performance monitoring.

Network administrators can configure port mirroring by selecting a specific port from which to copy all packets, and other ports to which the packets copied.

To enable port mirroring:

1. Click **System > Diagnostics > Port Mirroring**. The *Port Mirroring Page* opens:

Figure 132: Port Mirroring Page



The *Port Mirroring Page* contains the following fields:

- **Destination Port** — Defines the port number to which port traffic is copied.
- **Transmit Packets** — Defines the how the packets are mirrored. The possible field values are:
 - *Untagged* — Mirrors packets as untagged VLAN packets. This is the default value.
 - *Tagged* — Mirrors packets as tagged VLAN packets.
- **Source Port** — Indicates the port from which the packets are mirrored.
- **Type** — Indicates the port mode configuration for port mirroring. The possible field values are:
 - *RX* — Defines the port mirroring on receiving ports.
 - *TX* — Defines the port mirroring on transmitting ports.
 - *Both* — Defines the port mirroring on both receiving and transmitting ports. This is the default value.
- **Status** — Indicates if the port is currently monitored. The possible field values are:




- *Active* — Indicates the port is currently monitored.
 - *Ready* — Indicates the port is not currently monitored.
 - **Remove** — Removes the port mirroring session. The possible field values are:
 - *Checked* — Removes the selected port mirroring sessions.
 - *Unchecked* — Maintains the port mirroring session.
2. Click . The *Add Port Mirroring Page* opens:

Figure 133: Add Port Mirroring Page



The screenshot shows the 'Add Port Mirroring' page. It has a title 'Add Port Mirroring' in blue. Below the title is a form with two fields: 'Source Port' and 'Type'. The 'Source Port' field is a dropdown menu with a small arrow icon. The 'Type' field is a dropdown menu with 'Tx and Rx' selected. Below the form is a 'Submit' button.

3. Select a port in the *Source Port* field.
4. Select a port type in the *Type* field.
5. Click . The port mirroring session is defined, and the device is updated.

To edit the port mirroring settings:



1. Click **System > Diagnostics > Port Mirroring**. The *Port Mirroring Page* opens.
2. Click . The *Port Mirroring Settings Page* opens:

Figure 134: Port Mirroring Settings Page



The screenshot shows the 'Port Mirroring Settings' page. It has a title 'Port Mirroring Settings' in blue. Below the title is a form with two fields: 'Source Port' and 'Type'. The 'Source Port' field is a dropdown menu. The 'Type' field is a dropdown menu with 'Tx and Rx' selected. Below the form is a 'Submit' button.

3. Modify the *Type* field.
4. Click . The port mirroring settings are modified, and the device is updated.

Viewing Integrated Cable Tests

The *Cable Tests Page* contains fields for performing tests on copper cables. Cable testing provides information about where errors occurred in the cable, the last time a cable test was performed, and the type of cable error, which occurred. The tests use Time Domain Reflectometry (TDR) technology to test the quality and characteristics of a copper cable attached to a port. Cables up to 120 meters long can be tested. Cables are tested when the ports are in the down state, with the exception of the Approximated Cable Length test. To test cables:

1. Click **System > Diagnostics > Copper Cable**. The *Cable Tests Page* opens:

Figure 135: Cable Tests Page



The *Cable Tests Page* contains the following fields:

- **Port** — Specifies the port to which the cable is connected.
 - **Test Result** — Displays the cable test results. Possible values are:
 - *No Cable* — Indicates that a cable is not connected to the port.
 - *Open Cable* — Indicates that a cable is connected on only one side.
 - *Short Cable* — Indicates that a short has occurred in the cable.
 - *OK* — Indicates that the cable passed the test.
 - **Cable Fault Distance** — Indicates the distance from the port where the cable error occurred.
 - **Last Update** — Indicates the last time the port was tested.
 - **Cable Length** — Indicates the approximate cable length. This test can only be performed when the port is up and operating at 1 Gbps.
2. Click **Test**. The test results are displayed.

Viewing Optical Transceivers

The Optical Transceiver page allows network managers to perform tests on Fiber Optic cables. Optical transceiver diagnostics can be performed only when the link is present. To test cables:

- Click **Advanced Setup > Diagnostics > Optical Transceivers** tab. The **Optical Transceivers Page** opens:

Figure 136: Optical Transceivers Page



The *Optical Transceivers Page* contains the field:


- **Port** — Displays the port IP address on which the cable is tested.
- **Temperature** — Displays the temperature (C) at which the cable is operating.
- **Voltage** — Displays the voltage at which the cable is operating.
- **Current** — Displays the current at which the cable is operating.
- **Output Power** — Indicates the rate at which the output power is transmitted.
- **Input Power** — Indicates the rate at which the input power is transmitted.
- **Transmitter Fault** — Indicates if a fault occurred during transmission.
- **Loss of Signal** — Indicates if a signal loss occurred in the cable.
- **Data Ready** — Indicates the transceiver has achieved power up and data is ready.

Viewing the CPU Utilization

The *CPU Utilization Page* contains information about the system's CPU utilization. To view the CPU Utilization:

- Click **System > Diagnostics > CPU Utilization**. The *CPU Utilization Page* opens:

Figure 137: CPU Utilization Page



The *CPU Utilization Page* contains the following fields:

- Refresh Rate** — Amount of time that passes before the statistics are refreshed.
- Usage Percentages** — Indicates the percentage of the CPU's resources consumed by the device.
- Time** — Indicates the time, in 15 second intervals, the usage samples are taken.

Section 19. Configuring System Time

This section provides information for configuring system time parameters, including:

- Configuring Daylight Savings Time
- Configuring SNTP

Configuring Daylight Savings Time

The *Time Page* contains fields for defining system time parameters for both the local hardware clock and the external SNTP clock. If the system time is kept using an external SNTP clock, and the external SNTP clock fails, the system time reverts to the local hardware clock. Daylight Savings Time can be enabled on the device.

The following is a list of Daylight Savings Time start and end times in specific countries:

- **Albania** — From the last weekend of March until the last weekend of October.
- **Australia** — From the end of October until the end of March.
- **Australia - Tasmania** — From the beginning of October until the end of March.
- **Armenia** — From the last weekend of March until the last weekend of October.
- **Austria** — From the last weekend of March until the last weekend of October.
- **Bahamas** — From April to October, in conjunction with Daylight Savings Time in the United States.
- **Belarus** — From the last weekend of March until the last weekend of October.
- **Belgium** — From the last weekend of March until the last weekend of October.
- **Brazil** — From the third Sunday in October until the third Saturday in March. During the period of Daylight Saving Time, Brazilian clocks go forward one hour in most of the Brazilian southeast.
- **Chile** — In Easter Island, from March 9 until October 12. In the rest of the country, from the first Sunday in March or after 9th March.
- **China** — China does not use Daylight Saving Time.
- **Canada** — From the first Sunday in April until the last Sunday of October. Daylight Saving Time is usually regulated by provincial and territorial governments. Exceptions may exist in certain municipalities.
- **Cuba** — From the last Sunday of March to the last Sunday of October.
- **Cyprus** — From the last weekend of March until the last weekend of October.
- **Denmark** — From the last weekend of March until the last weekend of October.
- **Egypt** — From the last Friday in April until the last Thursday in September.
- **Estonia** — From the last weekend of March until the last weekend of October.
- **Finland** — From the last weekend of March until the last weekend of October.
- **France** — From the last weekend of March until the last weekend of October.
- **Germany** — From the last weekend of March until the last weekend of October.
- **Greece** — From the last weekend of March until the last weekend of October.
- **Hungary** — From the last weekend of March until the last weekend of October.
- **India** — India does not use Daylight Saving Time.
- **Iran** — From Farvardin 1 until Mehr 1.
- **Iraq** — From April 1 until October 1.
- **Ireland** — From the last weekend of March until the last weekend of October.
- **Israel** — Varies year-to-year.
- **Italy** — From the last weekend of March until the last weekend of October.
- **Japan** — Japan does not use Daylight Saving Time.
- **Jordan** — From the last weekend of March until the last weekend of October.
- **Latvia** — From the last weekend of March until the last weekend of October.
- **Lebanon** — From the last weekend of March until the last weekend of October.
- **Lithuania** — From the last weekend of March until the last weekend of October.
- **Luxembourg** — From the last weekend of March until the last weekend of October.
- **Macedonia** — From the last weekend of March until the last weekend of October.

- **Mexico** — From the first Sunday in April at 02:00 to the last Sunday in October at 02:00.
- **Moldova** — From the last weekend of March until the last weekend of October.
- **Montenegro** — From the last weekend of March until the last weekend of October.
- **Netherlands** — From the last weekend of March until the last weekend of October.
- **New Zealand** — From the first Sunday in October until the first Sunday on or after March 15.
- **Norway** — From the last weekend of March until the last weekend of October.
- **Paraguay** — From April 6 until September 7.
- **Poland** — From the last weekend of March until the last weekend of October.
- **Portugal** — From the last weekend of March until the last weekend of October.
- **Romania** — From the last weekend of March until the last weekend of October.
- **Russia** — From the last weekend of March until the last weekend of October.
- **Serbia** — From the last weekend of March until the last weekend of October.
- **Slovak Republic** - From the last weekend of March until the last weekend of October.
- **South Africa** — South Africa does not use Daylight Saving Time.
- **Spain** — From the last weekend of March until the last weekend of October.
- **Sweden** — From the last weekend of March until the last weekend of October.
- **Switzerland** — From the last weekend of March until the last weekend of October.
- **Syria** — From March 31 until October 30.
- **Taiwan** — Taiwan does not use Daylight Saving Time.
- **Turkey** — From the last weekend of March until the last weekend of October.
- **United Kingdom** — From the last weekend of March until the last weekend of October.
- **United States of America** — From the first Sunday in April at 02:00 to the last Sunday in October at 02:00.

To configure the system time:

1. Click **System > General > Time**. The *Time Page* opens.


Figure 138: Time Page

The screenshot shows the D-Link web interface for configuring system time. The top navigation bar includes 'System', 'Basic Setup', and 'Advanced Setup'. The left sidebar lists various configuration categories: General, Description, Time, Reset, SNTP, Properties, Authentication, Servers, Interface Settings, Syslog, Management Security, File Management, SNMP, and Diagnostics. The main content area is titled 'Time' and contains the following fields:

- Clock Source:** A dropdown menu set to 'None'.
- Local Settings:**
 - Date:** A text field showing '01/Jan/00' with a format '(DD-MMM-YY)'.
 - Local Time:** A text field showing '02:34:33' with a format '(HH:MM:SS)'.
 - Time Zone Offset:** A dropdown menu set to 'GMT'.
 - Daylight Saving:** A checkbox labeled 'Daylight Saving' is unchecked. Below it are radio buttons for 'USA', 'European', and 'Other'.
 - Time Set Offset:** A text field showing '60' with a unit '(Min)'.
 - From:** Two text fields for date and time, both showing '00-MMM-YY' and '(HH:MM)'.
 - To:** Two text fields for date and time, both showing '00-MMM-YY' and '(HH:MM)'.
 - Recurring:** A section with two rows of date and time pickers. Each row has 'Day' (Sun), 'Week' (First), 'Month' (Jan), and 'Time' (HH:MM) fields.
- Submit:** A button at the bottom of the form.

The *Time Page* contains the following sections:

- **Clock Source** — The source used to set the system clock. The possible field values are:
 - *None* — Indicates that a clock source is not used. The clock is set locally.
 - *SNTP* — Indicates that the system time is set via an SNTP server.
- **Date** — The system date. The field format is Day/Month/Year. For example: 04/May/50 (May 4, 2050).
- **Local Time** — The system time. The field format is HH:MM:SS. For example: 21:15:03.
- **Time Zone Offset** — The difference between Greenwich Mean Time (GMT) and local time. For example, the Time Zone Offset for Paris is GMT +1, while the Time Zone Offset for New York is GMT –5.
- **Daylight Savings** — Enables automatic Daylight Savings Time (DST) on the device based on the device's location. There are two types of daylight settings, either by a specific date in a particular year or a recurring setting irrespective of the year. For a specific setting in a particular year complete the *Daylight Savings* area, and for a recurring setting, complete the *Recurring* area. The possible field values are:
 - *USA* — Enables switching to DST at 2:00 a.m. on the first Sunday of April, and reverts to standard time at 2:00 a.m. on the last Sunday of October.
 - *European* — Enables switching to DST at 1:00 am on the last Sunday in March and reverts to standard time at 1:00 am on the last Sunday in October. The *European* option applies to EU members, and other European countries using the EU standard.
 - *Other* — Indicates the DST definitions are user-defined based on the device locality. If *Other* is selected, the *From* and *To* fields must be defined.
- **Time Set Offset (1-1440)** — Used for non-USA and European countries to set the amount of time for DST (in minutes). The default time is 60 minutes.

- **From** — Indicates the time that DST begins in countries other than the USA and Europe, in the format Day/Month/Year in one field and HH:MM in another. For example, if DST begins on October 25, 2007 at 5:00 am, the two fields should be set to 25/Oct/07 and 05:00. The possible field values are:
 - *Date* — The date on which DST begins. The possible field range is 1-31.
 - *Month* — The month of the year in which DST begins. The possible field range is Jan-Dec.
 - *Year* — The year in which the configured DST begins.
 - *Time* — The time at which DST begins. The field format is HH:MM. For example: 05:30.
 - **To** — Indicates the time that DST ends in countries other than the USA and Europe, in the format Day/Month/Year in one field and HH:MM in another. For example, if DST ends on March 23, 2008 at midnight, the two fields should be 23/Mar/08 and 00:00. The possible field values are:
 - *Date* — The date on which DST ends. The possible field range is 1-31.
 - *Month* — The month of the year in which DST ends. The possible field range is Jan-Dec.
 - *Year* — The year in which the configured DST ends.
 - *Time* — The time at which DST starts. The field format is HH:MM. For example: 05:30.
 - **Recurring** — Enables user-defined DST for countries in which DST is constant from year to year, other than the USA and Europe.
 - **From** — The time that DST begins each year. In the example, DST begins locally every first Sunday in April at midnight. The possible field values are:
 - *Day* — The day of the week from which DST begins every year. The possible field range is Sunday-Saturday.
 - *Week* — The week within the month from which DST begins every year. The possible field range is 1-5.
 - *Month* — The month of the year in which DST begins every year. The possible field range is Jan-Dec.
 - *Time* — The time at which DST begins every year. The field format is Hour:Minute. For example: 02:10.
 - **To** — The time that DST ends each year. In the example, DST ends locally every first Sunday in October at midnight. The possible field values are:
 - *Day* — The day of the week at which DST ends every year. The possible field range is Sunday-Saturday.
 - *Week* — The week within the month at which DST ends every year. The possible field range is 1-5.
 - *Month* — The month of the year in which DST ends every year. The possible field range is Jan-Dec.
 - *Time* — The time at which DST ends every year. The field format is HH:MM. For example: 05:30.
2. Define the *Date*, *Local Time* and *Time Zone Offset* fields.
 3. To configure the device to automatically switch to DST, select *Daylight Savings* and select either *USA*, *European*, or *Other*. If you select *Other*, you must define its *From* and *To* fields. To configure DST parameters that will recur every year, select *Recurring* and define its *From* and *To* fields.
 4. Click.  The DST settings are saved, and the device is updated.

Configuring SNTP

The device supports the Simple Network Time Protocol (SNTP). SNTP assures accurate network device clock time synchronization up to the millisecond. Time synchronization is performed by a network SNTP server. The device operates only as an SNTP client, and cannot provide time services to other systems. The device can poll the following server types for the server time:

- Unicast
- Anycast
- Broadcast

Time sources are established by stratum. Stratum defines the accuracy of the reference clock. The higher the stratum (where zero is the highest), the more accurate the clock. The device receives time from stratum 1 and above.

The following is an example of stratum:

- **Stratum 0** — A real time clock (such as a GPS system) is used as the time source.
- **Stratum 1** — A server that is directly linked to a Stratum 0 time source is used. Stratum 1 time servers provide primary network time standards.
- **Stratum 2** — The time source is distanced from the Stratum 1 server over a network path. For example, a Stratum 2 server receives the time over a network link, via NTP, from a Stratum 1 server.

Information received from SNTP servers is evaluated based on the Time level and server type. SNTP time definitions are assessed and determined by the following time levels:

- **T1** — The time at which the original request was sent by the client.
- **T2** — The time at which the original request was received by the server.
- **T3** — The time at which the server sent the client a reply.
- **T4** — The time at which the client received the server's reply.

Polling for Unicast Time Information

Polling for Unicast information is used for polling a server for which the IP address is known. T1 - T4 are used to determine the server time. This is the preferred method for synchronizing device time.

Polling for Anycast Time Information

Polling for Anycast information is used when the server IP address is unknown. The first Anycast server to return a response is used to set the time value. Time levels T3 and T4 are used to determine the server time. Using Anycast time information for synchronizing device time is preferred to using Broadcast time information.

Broadcast Time Information

Broadcast information is used when the server IP address is unknown. When a broadcast message is sent from an SNTP server, the SNTP client listens for the response. The SNTP client neither sends time information requests nor receives responses from the Broadcast server.

Message Digest 5 (MD5) Authentication safeguards device synchronization paths to SNTP servers. MD5 is an algorithm that produces a 128-bit hash. MD5 is a variation of MD4, and increases MD4 security. MD5 verifies the integrity of the communication, authenticates the origin of the communication.

This section contains the following topics:

- Defining SNTP Global Settings
- Defining SNTP Authentication
- Defining SNTP Servers
- Defining SNTP Interface Settings

Defining SNMP Global Settings

The *SNTP Properties Page* provides information for defining SNMP parameters globally. To define SNMP global parameters:

1. Click **System > SNMP > Properties**. The *SNTP Properties Page* opens:


Figure 139: SNMP Properties Page



The *SNTP Properties Page* contains the following fields:

- **Poll Interval** — Defines the interval (in seconds) at which the SNMP server is polled for Unicast information. The Poll Interval default is 1024 seconds.
- **Enable Receive Broadcast Servers Updates** — Defines whether or not the device monitors the SNMP servers for Broadcast server time information on the selected interfaces. The possible values are:
 - *Enable* — Enables the device to receive Broadcast server updates.
 - *Disable* — Disables the device from receiving Broadcast server updates.
- **Enable Receive Anycast Servers Updates** — Defines whether or not the device polls the SNMP server for Anycast server time information. If both the *Enable Receive Anycast Servers Update* and the *Enable Receive Broadcast Servers Update* fields are enabled, the system time is set according the Anycast server time information. The possible values are:
 - *Enable* — Enables the device to receive Anycast server updates.
 - *Disable* — Disables the device from receiving Anycast server updates.
- **Enable Receive Unicast Servers Updates** — Defines whether or not the device polls the SNMP server for Unicast server time information. If the *Enable Receive Broadcast Servers Updates*, *Enable Receive Anycast*

Servers Updates, and *Enable Receive Unicast Servers Updates* fields are all enabled, the system time is set according the Unicast server time information. The possible values are:

- *Enable* — Enables the device to receive Unicast server updates.
 - *Disable* — Disables the device from receiving Unicast server updates.
 - **Enable Poll Unicast Servers** — Defines whether or not the device sends SNTP Unicast forwarding information to the SNTP server. The possible values are:
 - *Enable* — Enables the device to receive Poll Unicast server updates.
 - *Disable* — Disables the device from receiving Poll Unicast server updates.
2. Define the *Poll Interval*, *Enable Receive Broadcast Servers Update*, *Enable Receive Anycast Servers Update*, *Enable Receive Unicast Servers Update*, and *Enable Poll Unicast Servers* fields and select at least one of the *Enable* fields.
 3. Click . The SNTP global settings are defined, and the device is updated.

Defining SNTP Authentication

The *SNTP Authentication Page* provides parameters for defining the means by which the SNTP server is authenticated. To define SNTP authentication:

1. Click **System > SNTP > Authentication**. The *SNTP Authentication Page* opens:

Figure 140: SNTP Authentication Page




The *SNTP Authentication Page* contains the following fields:

- **Enable SNTP Authentication** — Indicates if authenticating an SNTP session between the device and an SNTP server is enabled on the device. The possible field values are:
 - *Checked* — Authenticates SNTP sessions between the device and SNTP server.
 - *Unchecked* — Disables authenticating SNTP sessions between the device and SNTP server.
 - **Encryption Key ID** — Indicates if the encryption key identification is used to authenticate the SNTP server and device. The field value is up to 4294967295.
 - **Authentication Key** — Indicates the key used for authentication.
 - **Trusted Key** — Indicates the encryption key used (Unicast/Anycast) or elected (Broadcast) to authenticate the SNTP server.
 - **Remove** — Removes Encryption Key IDs. The possible field values are:
 - *Checked* — Removes the selected Encryption Key ID
 - *Unchecked* — Maintains the Encryption Key IDs. This is the default value.
2. To enable SNTP Authentication, select *Enable SNTP Authentication* and click **Submit**. SNTP Authentication is defined, and the device is updated.

To define SNTP authentication parameters:

1. Click **Create**. The *Add SNTP Authentication* page opens:

Figure 141: Add SNTP Authentication



The screenshot shows a web form titled "Add SNTP Authentication" in blue text. Below the title is a table with three rows: "Encryption Key ID", "Authentication Key", and "Trusted Key". Each row has a corresponding input field. The "Trusted Key" row has a checkbox instead of a text field. Below the table are two buttons: "Yes" and "No".

Add SNTP Authentication	
Encryption Key ID	<input type="text"/>
Authentication Key	<input type="text"/>
Trusted Key	<input type="checkbox"/>

2. Define the *Encryption Key ID*, *Authentication Key*, and *Trusted Key* fields.
3. Click **Yes**. The SNTP Authentication Key is added, and the device is updated.

Defining SNTP Servers

The *SNTP Servers Page* contains information for enabling SNTP servers, as well as adding new SNTP servers. In addition, the *SNTP Servers Page* enables the device to request and accept SNTP traffic from a server. To define an SNTP server:

1. Click **System > SNTP > Servers**. The *SNTP Servers Page* opens:

Figure 142: SNTP Servers Page




The *SNTP Servers Page* contains the following fields:

- **SNTP Server** — Displays user-defined SNTP server IP addresses. Up to eight SNTP servers can be defined.
- **Poll Interval** — Indicates whether or not the device polls the selected SNTP server for system information.
- **Encryption Key ID** — Displays the encryption key identification used to communicate between the SNTP server and device. The field range is 1-4294967295.
- **Preference Status** — Displays the SNTP server operating status.
- **Last Response** — Displays the last time a response was received from the SNTP server.
- **Offset** — Indicates the time difference between the device local clock and the acquired time from the SNTP server.
- **Delay** — Indicates the amount of time it takes for a device request to reach the SNTP server.
- **Remove** — Removes SNTP servers from the SNTP server list. The possible field values are:
 - *Checked* — Removes the SNTP server.
 - *Unchecked* — Maintains the SNTP server. This is the default value.

2. Click **Create** . The *Add SNTP Server Page* opens:

Figure 143: Add SNTP Server Page



Add SNTP Server

SNTP Server	<input type="text"/>
<input type="checkbox"/> Enable Poll Interval	<input type="checkbox"/>
<input type="checkbox"/> Encryption Key ID	<input type="text" value="11"/>

Submit

3. Define the *SNTP Server*, *Enable Poll Interval*, and *Encryption Key ID* fields.
4. Click **Submit** . The SNTP Server is added, and the device is updated.

Defining SNTP Interface Settings

The *SNTP Interface Settings Page* contains fields for setting SNTP on different interfaces. To define SNTP interface settings:

1. Click **System > SNTP > Interface Settings**. The *SNTP Interface Settings Page* opens:

Figure 144: SNTP Interface Settings Page



The *SNTP Interface Settings Page* contains the following fields:

- **Interface** — Indicates the interface on which SNTP can be enabled. The possible field values are:
 - *Port* — Indicates the specific port number on which SNTP is enabled.
 - *LAG* — Indicates the specific LAG number on which SNTP is enabled.
 - *VLAN* — Indicates the specific VLAN number on which SNTP is enabled.
- **Receive Servers Updates** — Enables the server to receive or not receive updates.
- **Remove** — Removes SNTP interfaces.
 - *Checked* — Removes the selected SNTP interface.
 - *Unchecked* — Maintains the selected SNTP interfaces.

2. Click **Create**. The *Add SNTP Interface Page* opens.

Figure 145: Add SNTP Interface Page

Add SNTP Interface

Interface ☒ Port ☐ LAG ☐ VLAN 1

Receive Server Updates ☐

Submit

3. Define the *Interface* and *Receive Server Updates* fields.
4. Click. **Submit**. The SNTP interface is added, and the device is updated.

Section 20. Viewing Statistics

This section provides device statistics for RMON, interfaces, GVRP, EAP, and Etherlike statistics. This section contains the following topics:

- Viewing Interface Statistics
- Managing RMON Statistics

Viewing Interface Statistics

This section contains the following topics:

- Viewing Device Interface Statistics
- Viewing Etherlike Statistics
- Viewing GVRP Statistics
- Viewing EAP Statistics

Viewing Device Interface Statistics

The *Interface Statistics Page* contains statistics for both received and transmitted packets.

1. Click **Advanced Setup > Interface Statistics > Interface**. The *Interface Statistics Page* opens.

Figure 146: Interface Statistics Page



The *Interface Statistics Page* contains the following fields:

- **Interface** — Indicates the device for which statistics are displayed. The possible field values are:
 - **Port** — Defines the specific port for which interface statistics are displayed.
 - **LAG** — Defines the specific LAG for which interface statistics are displayed.
- **Refresh Rate** — Defines the amount of time that passes before the interface statistics are refreshed. The possible field values are:
 - **15 Sec** — Indicates that the Interface statistics are refreshed every 15 seconds.
 - **30 Sec** — Indicates that the Interface statistics are refreshed every 30 seconds.
 - **60 Sec** — Indicates that the Interface statistics are refreshed every 60 seconds.
 - **No Refresh** — Indicates that the Interface statistics are not refreshed.


Receive Statistics

- **Total Bytes (Octets)** — Displays the number of octets received on the selected interface.
- **Unicast Packets** — Displays the number of Unicast packets received on the selected interface.
- **Multicast Packets** — Displays the number of Multicast packets received on the selected interface.
- **Broadcast Packets** — Displays the number of Broadcast packets received on the selected interface.
- **Packets with Errors** — Displays the number of error packets received from the selected interface.

Transmit Statistics

- **Total Bytes (Octets)** — Displays the number of octets transmitted from the selected interface.
 - **Unicast Packets** — Displays the number of Unicast packets transmitted from the selected interface.
 - **Multicast Packets** — Displays the number of Multicast packets transmitted from the selected interface.
 - **Broadcast Packets** — Displays the number of Broadcast packets transmitted from the selected interface.
2. Select an interface in the *Interface* field. The interface statistics are displayed.

Resetting Interface Statistics Counters

1. Open the *Interface Statistics Page*.
2. Click . The interface statistics counters are cleared.

Viewing Etherlike Statistics

The *Etherlike Statistics Page* contains interface statistics. To view Etherlike Statistics:

1. Click **Advanced Setup > Interfaces Statistics > Etherlike**. The *Etherlike Statistics Page* opens:


Figure 147: Etherlike Statistics Page



The *Etherlike Statistics Page* contains the following fields:

- **Interface** — Indicates the device for which statistics are displayed. The possible field values are:
 - *Port* — Defines the specific port for which Etherlike statistics are displayed.
 - *LAG* — Defines the specific LAG for which Etherlike statistics are displayed.
 - **Refresh Rate** — Defines the amount of time that passes before the interface statistics are refreshed. The possible field values are:
 - *15 Sec*—Indicates that the Etherlike statistics are refreshed every 15 seconds.
 - *30 Sec*—Indicates that the Etherlike statistics are refreshed every 30 seconds.
 - *60 Sec*—Indicates that the Etherlike statistics are refreshed every 60 seconds.
 - *No Refresh*—Indicates that the Etherlike statistics are not refreshed.
 - **Frame Check Sequence (FCS) Errors** — Displays the number of FCS errors received on the selected interface.
 - **Single Collision Frames** — Displays the number of single collision frames received on the selected interface.
 - **Late Collisions** — Displays the number of late collision frames received on the selected interface.
 - **Excessive Collisions** — Displays the number of excessive collisions received on the selected interface.
 - **Internal MAC Transmit Errors** — Displays the number of internal MAC transmit errors on the selected interface.
 - **Oversize Packets** — Displays the number of oversized packet errors on the selected interface.
 - **Internal MAC Receive Errors** — Number of internal MAC received errors on the selected interface.
 - **Receive Pause Frames** — Displays the number of received paused frames on the selected interface.
 - **Transmitted Paused Frames** — Displays the number of paused frames transmitted from the selected interface.
2. Select an interface in the *Interface* field. The Etherlike statistics are displayed.

Resetting Etherlike Statistics Counters


1. Open the *Etherlike Statistics Page*.
2. Click . The Etherlike statistics counters are cleared.

Viewing GVRP Statistics

The *GVRP Statistics Page* contains device statistics for GVRP. To view GVRP statistics:

- Click **Advanced Setup > Interface Statistics > GVRP**. The *GVRP Statistics Page* opens.

Figure 148: GVRP Statistics Page



The *GVRP Statistics Page* contains the following fields:

- Interface**—Specifies the interface type for which the statistics are displayed.
 - Port*—Indicates port statistics are displayed.
 - LAG*—Indicates LAG statistics are displayed.
- Refresh Rate**—Indicates the amount of time that passes before the GVRP statistics are refreshed. The possible field values are:
 - 15 Sec*—Indicates that the GVRP statistics are refreshed every 15 seconds.
 - 30 Sec*—Indicates that the GVRP statistics are refreshed every 30 seconds.
 - 60 Sec*—Indicates that the GVRP statistics are refreshed every 60 seconds.
 - No Refresh*—Indicates that the GVRP statistics are not refreshed.
- Join Empty**—Displays the device GVRP Join Empty statistics.
- Empty**—Displays the device GVRP Empty statistics.
- Leave Empty**—Displays the device GVRP Leave Empty statistics.
- Join In**—Displays the device GVRP Join In statistics.
- Leave In**—Displays the device GVRP Leave in statistics.
- Leave All**—Displays the device GVRP Leave all statistics.

- **Invalid Protocol ID**—Displays the device GVRP Invalid Protocol ID statistics.
 - **Invalid Attribute Type**—Displays the device GVRP Invalid Attribute ID statistics.
 - **Invalid Attribute Value**—Displays the device GVRP Invalid Attribute Value statistics.
 - **Invalid Attribute Length**—Displays the device GVRP Invalid Attribute Length statistics.
 - **Invalid Event**—Displays the device GVRP Invalid Event statistics.
3. Select an interface in the *Interface* field. The GVRP statistics are displayed.

Resetting GVRP Statistics Counters

1. Open the *GVRP Statistics Page*.
2. Click . The GVRP statistics counters are cleared.

Viewing EAP Statistics

The *EAP Statistics Page* contains information about EAP packets received on a specific port. To view the EAP Statistics:

- Click **Advanced Setup > Interface Statistics > EAP**. The *EAP Statistics Page* opens.

Figure 149: EAP Statistics Page



The *EAP Statistics Page* contains the following fields:

- **Port**—Indicates the port, which is polled for statistics.
- **Refresh Rate**—Indicates the amount of time that passes before the EAP statistics are refreshed. The possible field values are:
 - **15 Sec**—Indicates that the EAP statistics are refreshed every 15 seconds.
 - **30 Sec**—Indicates that the EAP statistics are refreshed every 30 seconds.
 - **60 Sec**—Indicates that the EAP statistics are refreshed every 60 seconds.
 - **No Refresh**—Indicates that the EAP statistics are not refreshed.

- **Frames Receive** — Indicates the number of valid EAPOL frames received on the port.
- **Frames Transmit** — Indicates the number of EAPOL frames transmitted via the port.
- **Start Frames Receive** — Indicates the number of EAPOL Start frames received on the port.
- **Log off Frames Receive** — Indicates the number of EAPOL Logoff frames that have been received on the port.
- **Respond ID Frames Receive** — Indicates the number of EAP Resp/Id frames that have been received on the port.
- **Respond Frames Receive** — Indicates the number of valid EAP Response frames received on the port.
- **Request ID Frames Transmit** — Indicates the number of EAP Req/Id frames transmitted via the port.
- **Request Frames Transmit** — Indicates the number of EAP Request frames transmitted via the port.
- **Invalid Frames Receive** — Indicates the number of unrecognized EAPOL frames that have been received by on this port.
- **Length Error Frames Receive** — Indicates the number of EAPOL frames with an invalid Packet Body Length received on this port.
- **Last Frame Version** — Indicates the protocol version number attached to the most recently received EAPOL frame.
- **Last Frame Source** — Indicates the source MAC address attached to the most recently received EAPOL frame.

Managing RMON Statistics

This section contains the following topics:

- Viewing RMON Statistics
- Configuring RMON History
- Configuring RMON Events
- Defining RMON Alarms

Viewing RMON Statistics

The *Viewing RMON Statistics* contains fields for viewing information about device utilization and errors that occurred on the device. To view RMON statistics:

1. Click **Advanced Setup > RMON > Statistics**. The *RMON Statistics Page* opens.

Figure 150: RMON Statistics Page




The *RMON Statistics Page* contains the following fields:

- **Interface** — Indicates the device for which statistics are displayed. The possible field values are:
 - **Port** — Defines the specific port for which RMON statistics are displayed.
 - **LAG** — Defines the specific LAG for which RMON statistics are displayed.
- **Refresh Rate** — Defines the amount of time that passes before the interface statistics are refreshed. The possible field values are:
 - **15 Sec** — Indicates that the RMON statistics are refreshed every 15 seconds.
 - **30 Sec** — Indicates that the RMON statistics are refreshed every 30 seconds.
 - **60 Sec** — Indicates that the RMON statistics are refreshed every 60 seconds.
- **Drop Events** — Displays the number of dropped events that have occurred on the interface since the device was last refreshed.
- **Received Bytes (Octets)** — Displays the number of octets received on the interface since the device was last refreshed. This number includes bad packets and FCS octets, but excludes framing bits.
- **Received Packets** — Displays the number of packets received on the interface, including bad packets, Multicast and broadcast packets, since the device was last refreshed.

- **Broadcast Packets Received** — Displays the number of good broadcast packets received on the interface since the device was last refreshed. This number does not include Multicast packets.
 - **Multicast Packets Received** — Displays the number of good Multicast packets received on the interface since the device was last refreshed.
 - **CRC & Align Errors** — Displays the number of CRC and Align errors that have occurred on the interface since the device was last refreshed.
 - **Undersize Packets** — Displays the number of undersized packets (less than 64 octets) received on the interface since the device was last refreshed.
 - **Oversize Packets** — Displays the number of oversized packets (over 1518 octets) received on the interface since the device was last refreshed.
 - **Fragments** — Displays the number of fragments (packets with less than 64 octets, excluding framing bits, but including FCS octets) received on the interface since the device was last refreshed.
 - **Jabbers** — Displays the total number of received packets that were longer than 1518 octets. This number excludes frame bits, but includes FCS octets that had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral octet (Alignment Error) number. The field range to detect jabbers is between 20 ms and 150 ms.
 - **Collisions** — Displays the number of collisions received on the interface since the device was last refreshed.
 - **Frames of xx Bytes** — Number of xx-byte frames received on the interface since the device was last refreshed.
2. Select an interface in the *Interface* field. The RMON statistics are displayed.

Resetting RMON Statistics Counters

1. Open the *RMON Statistics Page*.
2. Click . The RMON statistics counters are cleared.

Configuring RMON History

This section contains the following topics:


- Defining RMON History Control
- Viewing the RMON History Table

Defining RMON History Control

The *RMON History Control Page* contains information about samples of data taken from ports. For example, the samples may include interface definitions or polling periods. To view RMON history information:

1. Click **Advanced Setup > RMON > History > History Control**. The *RMON History Control Page* opens.

Figure 151: RMON History Control Page



The *RMON History Control Page* contains the following fields:

- **History Entry No.** — Displays the entry number for the History Control Table page.
- **Source Interface** — Displays the interface from which the history samples were taken. The possible field values are:
 - *Port* — Specifies the port from which the RMON information was taken.
 - *LAG* — Specifies the port from which the RMON information was taken.
- **Sampling Interval** — Indicates in seconds the time that samplings are taken from the ports. The field range is 1-3600. The default is 1800 seconds (equal to 30 minutes).
- **Samples Requested** — Displays the number of samples to be saved. The field range is 1-65535. The default value is 50.

- **Current No. of Samples in List** — Displays the current number of samples taken.
 - **Owner** — Displays the RMON station or user that requested the RMON information. The field range is 0-20 characters.
 - **Remove** — Removes History Control entries. The possible field values are:
 - *Checked* — Removes the selected History Control entry.
 - *Unchecked* — Maintains the current History Control entries.
2. Click **Create**. The *RMON History Control Settings Page* opens:

Figure 152: RMON History Control Settings Page

Add History Control Entry

History Entry No.	<input type="text"/>
Source Interface	<input type="text"/>
Sampling Interval	<input type="text"/>
Samples Requested	<input type="text"/>
Current Samples	<input type="text"/>
Owner	<input type="text"/>


3. Complete the *History Entry No.*, *Source Interface*, *Owner*, *Samples Requested*, and *Current Sampling* fields.
4. Click **Submit**. The entry is added to the *RMON History Control Page*, and the device is updated.

Viewing the RMON History Table

The *RMON History Table Page* contains interface specific statistical network samplings. Each table entry represents all counter values compiled during a single sample. To view the RMON History Table:

1. Click Advanced Setup > **RMON** > **History** > **History Table**. The *RMON History Table Page* opens.

Figure 153: RMON History Table Page



The *RMON History Table Page* contains the following fields:

- **History Entry No.** — Displays the entry number for the History Control Table page.
- **Owner** — Displays the RMON station or user that requested the RMON information. The field range is 0-20 characters.
- **Sample Number**— Indicates the sample number from which the statistics were taken.
- **Drop Events** — Displays the number of dropped events that have occurred on the interface since the device was last refreshed.
- **Received Bytes (Octets)** — Displays the number of octets received on the interface since the device was last refreshed. This number includes bad packets and FCS octets, but excludes framing bits.
- **Received Packets** — Displays the number of packets received on the interface since the device was last refreshed, including bad packets, Multicast and Broadcast packets.
- **Broadcast Packets** — Displays the number of good Broadcast packets received on the interface since the device was last refreshed. This number does not include Multicast packets.
- **Multicast Packets** — Displays the number of good Multicast packets received on the interface since the device was last refreshed.

- **CRC Align Errors** — Displays the number of CRC and Align errors that have occurred on the interface since the device was last refreshed.
- **Undersize Packets** — Displays the number of undersized packets (less than 64 octets) received on the interface since the device was last refreshed.
- **Oversize Packets** — Displays the number of oversized packets (over 1518 octets) received on the interface since the device was last refreshed.
- **Fragments** — Displays the number of fragments (packets with less than 64 octets, excluding framing bits, but including FCS octets) received on the interface since the device was last refreshed.

- **Jabbers** — Displays the total number of received packets that were longer than 1518 octets. This number excludes frame bits, but includes FCS octets that had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral octet (Alignment Error) number. The field range to detect jabbers is between 20 ms and 150 ms.
 - **Collisions** — Displays the number of collisions received on the interface since the device was last refreshed.
 - **Utilization** — Displays the percentage of the interface utilized.
2. Select an entry in the *History Entry* field. The Statistics are displayed.

Configuring RMON Events

This section includes the following topics:


- Defining RMON Events Control
- Viewing the RMON Events Logs

Defining RMON Events Control

The *RMON Events Control Page* contains fields for defining RMON events. To view RMON events:

- Click **Advanced Setup > RMON > Events > Events Control**. The *RMON Events Control Page* opens.

Figure 154:RMON Events Control Page



The *RMON Events Control Page* contains the following fields:

- **Event Entry** — Displays the event.
- **Community** — Displays the community to which the event belongs.
- **Description** — Displays the user-defined event description.
- **Type** — Describes the event type. Possible values are:
 - *Log* — Indicates that the event is a log entry.
 - *Trap* — Indicates that the event is a trap.
 - *Log and Trap* — Indicates that the event is both a log entry and a trap.
 - *None* — Indicates that no event occurred.
- **Time** — Displays the time that the event occurred.
- **Owner** — Displays the device or user that defined the event.
- **Remove** — Removes a RMON event. The possible field values are:
 - *Checked* — Removes a selected RMON event.
 - *Unchecked* — Maintains RMON events.

Viewing the RMON Events Logs

The *RMON Events Logs Page* contains a list of RMON events. To view RMON event logs:

- Click **Advanced Setup > RMON > Events > Events Logs**. The *RMON Events Logs Page* opens.

Figure 155: RMON Events Logs Page



The *RMON Events Logs Page* contains the following fields:

- **Event** — Displays the RMON Events Log entry number.
- **Log No.** — Displays the log number.
- **Log Time** — Displays the time when the log entry was entered.
- **Description** — Displays the log entry description.

Defining RMON Alarms

The *RMON Alarm Page* contains fields for setting network alarms. Network alarms occur when a network problem, or event, is detected. Rising and falling thresholds generate events. To set RMON alarms:

1. Click **Advanced Setup > RMON > Alarm**. The *RMON Alarm Page* opens.

Figure 156: RMON Alarm Page




The *RMON Alarm Page* contains the following fields:

- **Alarm Entry** — Indicates a specific alarm.
- **Counter Name** — Displays the selected MIB variable.
- **Interface** — Displays interface for which RMON statistics are displayed. The possible field values are:
 - *Port* — Displays the RMON statistics for the selected port.
 - *LAG* — Displays the RMON statistics for the selected LAG.
- **Counter Value** — Displays the selected MIB variable value.
- **Sample Type** — Defines the sampling method for the selected variable and comparing the value against the thresholds. The possible field values are:
 - *Delta* — Subtracts the last sampled value from the current value. The difference in the values is compared to the threshold.
 - *Absolute* — Compares the values directly with the thresholds at the end of the sampling interval.
- **Rising Threshold** — Displays the rising counter value that triggers the rising threshold alarm. The rising threshold is presented on top of the graph bars. Each monitored variable is designated a color.
- **Rising Event** — Displays the mechanism in which the alarms are reported. The possible field values are:
 - *LOG* — Indicates there is not a saving mechanism for either the device or in the management system. If the device is not reset, the entry remains in the Log Table.
 - *TRAP* — Indicates that an SNMP trap is generated, and sent via the Trap mechanism. The Trap can also be saved using the Trap mechanism.
 - *Both* — Indicates that both the Log and Trap mechanism are used to report alarms.
- **Falling Threshold** — Displays the falling counter value that triggers the falling threshold alarm. The falling threshold is graphically presented on top of the graph bars. Each monitored variable is designated a color.
- **Falling Event** — Displays the mechanism in which the alarms are reported.

- **Startup Alarm** — Displays the trigger that activates the alarm generation. Rising is defined by crossing the threshold from a low-value threshold to a higher-value threshold.
- **Interval** — Defines the alarm interval time in seconds.
- **Owner** — Displays the device or user that defined the alarm.
- **Remove** — Removes the RMON Alarms Table entry.


2. Click  . The *RMON Alarms Definition Page* opens:

Figure 157: RMON Alarms Definition Page



Alarm Entry	
Interface	
Counter Name	
Counter Value	
Sample Type	Absolute ▼
Rising Threshold	
Rising Event	▼
Falling Threshold	
Falling Event	▼
Startup Alarm	Rising Alarm ▼
Interval	
Owner	

Submit

3. Complete *Sample Type*, *Rising Threshold*, *Rising Event*, *Falling Threshold*, *Falling Event*, *Startup Alarm*, *Interval*, and *Owner* fields.
4. Click  . The RMON alarm is added, and the device is updated.

Troubleshooting

This section describes problems that may arise when installing the and how to resolve these issue. This section includes the following topics:

- **Problem Management** — Provides information about problem management with DES-3010FA/GA.
- **Troubleshooting Solutions** — Provides a list of troubleshooting issues and solutions for using DES-3010FA/GA.

Problem Management

Problem management includes isolating problems, quantifying the problems, and then applying the solution. When a problem is detected, the exact nature of the problem must be determined. This includes how the problem is detected, and what are the possible causes of the problem. With the problem known, the effect of the problem is recorded with all known results from the problem. Once the problem is quantified, the solution is applied. Solutions are found either in this chapter, or through customer support. If no solution is found in this chapter, contact Customer Support.

Troubleshooting Solutions

Listed below are some possible troubleshooting problems and solutions. These error messages include:

- Cannot connect to management using RS-232 serial connection
- Cannot connect to switch management using Telnet, HTTP, SNMP, etc.
- Self-test exceeds 15 seconds
- No connection is established and the port LED is on
- Device is in a reboot loop
- No connection and the port LED is off
- Add and Edit pages do not open.
- Lost password.

Problems	Possible Cause	Solution
Cannot connect to management using RS-232 serial connection		Be sure the terminal emulator program is set to VT-100 compatible, 9600 baud rate, no parity, 8 data bits and one stop bit Use the included cable, or be sure that the pin-out complies with a standard null-modem cable
Cannot connect to switch management using Telnet, HTTP, SNMP, etc.		Be sure the switch has a valid IP address, subnet mask and default gateway configured Check that your cable is properly connected with a valid link light, and that the port has not been disabled Ensure that your management station is plugged into the appropriate VLAN to manage the device If you cannot connect using Telnet or the web, the maximum number of connections may already be open. Please try again at a later time.
No response from the terminal emulation software	Faulty serial cable Incorrect serial cable Software settings	Replace the serial cable Replace serial cable for a pin-to-pin straight/flat cable Reconfigure the emulation software connection settings.
Response from the terminal emulations software is not readable	Faulty serial cable Software settings	Replace the serial cable Reconfigure the emulation software connection settings.

Problems	Possible Cause	Solution
Self-test exceeds 15 seconds	The device may not be correctly installed.	Remove and reinstall the device. If that does not help, consult your technical support representative.
No connection is established and the port LED is on	Wrong network address in the workstation No network address set Wrong or missing protocol Faulty ethernet cable Faulty port Faulty module Incorrect initial configuration	Configure the network address in the workstation Configure the network address in the workstation Configure the workstation with IP protocol Replace the cable Replace the module Replace the module Erase the connection and reconfigure the port
Device is in a reboot loop	Software fault	Download and install a working or previous software version from the console
No connection and the port LED is off	Incorrect ethernet cable, e.g., crossed rather than straight cable, or vice versa, split pair (incorrect twisting of pairs) Fiber optical cable connection is reversed Bad cable Wrong cable type	Check pinout and replace if necessary Change if necessary. Check Rx and Tx on fiber optic cable Replace with a tested cable Verify that all 10 Mbps connections use a Cat 5 cable Check the port LED or zoom screen in the NMS application, and change setting if necessary

Problems	Possible Cause	Solution
Add and Edit pages do not open.	A pop-up blocker is enabled.	Disable pop-up blockers.
Lost password		<p>The Password Recovery Procedure enables the user to override the current password configuration, and disables the need for a password to access the console.</p> <p>The password recovery is effective until the device is reset. If the password/user name has been forgotten or lost. The password must be reconfigured using either the CLI commands or via the Embedded Web Interface.</p> <p>The Password Recovery Procedure is invoked from the Startup menu:</p> <ol style="list-style-type: none"> 1. Reboot the system either by disconnecting the power supply, or enter the command <code>reboot</code>, the following message is displayed: <pre>Console> reload Are you sure you want to reboot the system (y/n)[n]?</pre> 2. Enter Y. The device reboots. After the POST, when the text "Autoboot in 2 seconds - press RETURN or Esc. to abort and enter prom." is displayed, press <Enter>. The Startup Menu is displayed. <pre>[1] Download software [2] Erase flash file [3] Erase flash sectors [4] Password Recovery Procedure [5] Enter Diagnostic Mode [6] Back</pre> 3. Enter 4 within 15 seconds after the bootup process from the StartUp menu. If the startup menu option is not selected within 15 seconds, the accessibility requirements are erased, and the system continues to load. The password is defined using the CLI mode. 4. Enter the CLI configuration mode. 5. Enter the password commands: <code>username, enable password, or password [line]</code>. For example: <code>enable password level 1 password *****</code> 6. Enter the command <code>exit</code>. The CLI mode is exited.

Contacting D-Link Technical Support

Software updates and user documentation can be found on the D-Link website. D-Link provides free technical support for customers within the United States and within Canada for the warranty duration.

For more information on locating the D-Link office in your region, see [International Offices](#) .

Technical Support

You can find software updates and user documentation on the D-Link website.

D-Link provides free technical support for customers within the United States and within Canada for the duration of the warranty period on this product.

U.S. and Canadian customers can contact D-Link technical support through our website, or by phone.

Tech Support for customers within the United States:

D-Link Technical Support over the Telephone:

(888) 843-6100

Hours of Operation: 8:00AM to 6:00PM PST

D-Link Technical Support over the Internet:

<http://support.dlink.com>

[email:support@dlink.com](mailto:support@dlink.com)

Tech Support for customers within Canada:

D-Link Technical Support over the Telephone:

(800) 361-5265

Monday to Friday 7:30am to 12:00am EST

D-Link Technical Support over the Internet:

<http://support.dlink.ca>

[email:support@dlink.ca](mailto:support@dlink.ca)



Technical Support

You can find software updates and user documentation on the D-Link websites.

D-Link provides free technical support for customers within Canada, the United Kingdom, and Ireland.

Customers can contact D-Link technical support through our websites, or by phone.

For Customers within The United Kingdom & Ireland:

D-Link UK & Ireland Technical Support over the Telephone:

(08456 12 0003 (United Kingdom)

+44 8456 12 0003 (Ireland)

Monday to Friday 8:00 am to 10:00 pm GMT

Sat & Sun 10.00 am to 7.00 pm GMT

D-Link UK & Ireland Technical Support over the Internet:

<http://www.dlink.co.uk>

<ftp://ftp.dlink.co.uk>

For Customers within Canada:

D-Link Canada Technical Support over the Telephone:

1-800-361-5265 (Canada)

Monday to Friday 7:30 am to 12:00 am EST

D-Link Canada Technical Support over the Internet:

<http://support.dlink.ca>

email: support@dlink.ca

D-Link®
Building Networks for People

Technische Unterstützung

Aktualisierte Versionen von Software und Benutzerhandbuch finden Sie auf der Website von D-Link.

D-Link bietet kostenfreie technische Unterstützung für Kunden innerhalb Deutschlands, Österreichs, der Schweiz und Osteuropas.

Unsere Kunden können technische Unterstützung über unsere Website, per E-Mail oder telefonisch anfordern.

Web: <http://www.dlink.de>

E-Mail: support@dlink.de

Telefon: +49 (1805)2787

0,12€/Min aus dem Festnetz der Deutschen Telekom.

Telefonische technische Unterstützung erhalten Sie Montags bis Freitags von 09.00 bis 17.30 Uhr.

Wenn Sie Kunde von D-Link außerhalb Deutschlands, Österreichs, der Schweiz und Osteuropas sind, wenden Sie sich bitte an die zuständige Niederlassung aus der Liste im Benutzerhandbuch.



Assistance technique

Vous trouverez la documentation et les logiciels les plus récents sur le site web **D-Link**.

Le service technique de **D-Link** est gratuit pour les clients aux Etats-Unis durant la période de garantie.

Ceux-ci peuvent contacter le service technique de **D-Link** par notre site internet ou par téléphone.

Support technique destiné aux clients établis en France:

Assistance technique D-Link par téléphone :

0 820 0803 03

Assistance technique D-Link sur internet :

<http://www.dlink.fr>

e-mail : support@dlink.fr

Support technique destiné aux clients établis au Canada :

Assistance technique D-Link par téléphone :

(800) 361-5265

Lun.-Ven. 7h30 à 21h00 HNE.

Assistance technique D-Link sur internet :

<http://support.dlink.ca>

e-mail : support@dlink.ca

D-Link®
Building Networks for People

Asistencia Técnica

Puede encontrar el software más reciente y documentación para el usuario en el sitio web de **D-Link**. **D-Link** ofrece asistencia técnica gratuita para clientes dentro de España durante el periodo de garantía del producto. Los clientes españoles pueden ponerse en contacto con la asistencia técnica de **D-Link** a través de nuestro sitio web o por teléfono.

Asistencia Técnica de D-Link por teléfono:
902 304545

de lunes a viernes desde las 9:00 hasta las 14:00 y de las 15:00 hasta las 18:00

Asistencia Técnica de D-Link a través de Internet:
<http://www.dlink.es>
email: sosporte@dlink.es



Supporto tecnico

Gli ultimi aggiornamenti e la documentazione sono disponibili sul sito D-Link.

Supporto tecnico per i clienti residenti in Italia

D-Link Mediterraneo S.r.L.

Via N. Bonnet 6/B 20154 Milano

Supporto Tecnico dal lunedì al venerdì dalle ore
9.00 alle ore 19.00 con orario continuato
Telefono: 02-39607160

URL : <http://www.dlink.it/supporto.html>
Email: tech@dlink.it



Technical Support

You can find software updates and user documentation on the D-Link website.

D-Link provides free technical support for customers within Benelux for the duration of the warranty period on this product.

Benelux customers can contact D-Link technical support through our website, or by phone.

Tech Support for customers within the Netherlands:

D-Link Technical Support over the Telephone:

0900 501 2007

Monday to Friday 8:00 am to 10:00 pm

D-Link Technical Support over the Internet:

www.dlink.nl

Tech Support for customers within Belgium:

D-Link Technical Support over the Telephone:

+32(0)2 717 3248

Monday to Friday 8:00 am to 10:00 pm

D-Link Technical Support over the Internet:

www.dlink.be

Tech Support for customers within Luxembourg:

D-Link Technical Support over the Telephone:

+352 342 080 82 13

Monday to Friday 8:00 am to 10:00 pm

D-Link Technical Support over the Internet:

www.dlink.be



Pomoc techniczna

Najnowsze wersje oprogramowania i dokumentacji użytkownika można znaleźć w serwisie internetowym firmy D-Link.

D-Link zapewnia bezpłatną pomoc techniczną klientom w Polsce w okresie gwarancyjnym produktu.

Klienci z Polski mogą się kontaktować z działem pomocy technicznej firmy D-Link za pośrednictwem Internetu lub telefonicznie.

Telefoniczna pomoc techniczna firmy D-Link:
+49 (1805)-2787

Pomoc techniczna firmy D-Link świadczona przez Internet:

URL: <http://www.dlink.pl>
e-mail: pomoc_techiczna@dlink.de



Technická podpora

Aktualizované verze software a uživatelských příruček najdete na webové stránce firmy D-Link.

D-Link poskytuje svým zákazníkům bezplatnou technickou podporu

Zákazníci mohou kontaktovat oddělení technické podpory přes webové stránky, mailem nebo telefonicky

Web: <http://www.dlink.de>

E-Mail: support@dlink.de

Telefon: +49 (1805)-2787

Telefonická podpora je v provozu:

PO-ČT od 08.00 do 19.00

PÁ od 08.00 do 17.00



Technikai Támogatás

Meghajtó programokat és frissítéseket a **D-Link** Magyarország weblapjáról tölthet le.
Telefonon technikai segítséget munkanapokon hétfőtől-csütörtökig 9.00 – 16.00 óráig és pénteken 9.00 – 14.00 óráig kérhet a **(1) 461-3001** telefonszámon vagy a **support@dlink.hu** emailcímen.

Magyarországi technikai támogatás :

D-Link Magyarország

1074 Budapest, Alsóerdősor u. 6. – R70 Irodaház 1 em.

Tel. : 06 1 461-3001

Fax : 06 1 461-3004

email : support@dlink.hu

URL : <http://www.dlink.hu>

D-Link®
Building Networks for People

Teknisk Support

Du kan finne programvare oppdateringer og bruker dokumentasjon på D-Links web sider.

D-Link tilbyr sine kunder gratis teknisk support under produktets garantitid.

Kunder kan kontakte D-Links teknisk support via våre hjemmesider, eller på tlf.

Teknisk Support:

D-Link Teknisk telefon Support:

800 10 610
(Hverdager 08:00-20:00)

D-Link Teknisk Support over Internett:

<http://www.dlink.no>



Teknisk Support

Du finder software opdateringer og bruger-dokumentation på D-Link's hjemmeside.

D-Link tilbyder gratis teknisk support til kunder i Danmark i hele produktets garantiperiode.

Danske kunder kan kontakte D-Link's tekniske support via vores hjemmeside eller telefonisk.

D-Link teknisk support over telefonen:

Tlf. 7026 9040

Åbningstider: kl. 08:00 – 20:00

D-Link teknisk support på Internettet:

<http://www.dlink.dk>

[email:support@dlink.dk](mailto:support@dlink.dk)

D-Link®
Building Networks for People

Teknistä tukea asiakkaille Suomessa:

D-Link tarjoaa teknistä tukea asiakkailleen.
Tuotteen takuun voimassaoloajan.
Tekninen tuki palvelee seuraavasti:

Arkisin klo. 9 - 21
numerosta
0800-114 677

Internetin kautta
Ajurit ja lisätietoja tuotteista.
<http://www.dlink.fi>

Sähköpostin kautta
voit myös tehdä kyselyitä.
support@dlink.fi

D-Link®
Building Networks for People

Teknisk Support

På vår hemsida kan du hitta mer information om mjukvaru uppdateringar och annan användarinformation.

D-Link tillhandahåller teknisk support till kunder i Sverige under hela garantitiden för denna produkt.

Teknisk Support för kunder i Sverige:

D-Link Teknisk Support via telefon:

0770-33 00 35

Vardagar 08.00-20.00

D-Link Teknisk Support via Internet:

<http://www.dlink.se>

[email:support@dlink.se](mailto:support@dlink.se)



Technical Support

You can find software updates and user documentation on the D-Link website.

Tech Support for customers within Australia:

D-Link Technical Support over the Telephone:

1300-766-868

Monday to Friday 8:00am to 8:00pm EST

Saturday 9:00am to 1:00pm EST

D-Link Technical Support over the Internet:

<http://www.dlink.com.au>

email: support@dlink.com.au

Tech Support for customers within New Zealand:

D-Link Technical Support over the Telephone:

0800-900-900

Monday to Friday 8:30am to 8:30pm

Saturday 9:00am to 5:00pm

D-Link Technical Support over the Internet:

<http://www.dlink.co.nz>

email: support@dlink.co.nz



Technical Support

You can find software updates and user documentation on the D-Link website.

Tech Support for customers within South Eastern Asia and Korea:

D-Link South Eastern Asia and Korea Technical Support over the Telephone:

+65-6895-5355

Monday to Friday 9:00am to 12:30pm, 2:00pm-6:00pm
Singapore Time

D-Link Technical Support over the Internet:

email: support@dlink.com.sg



Technical Support

You can find software updates and user documentation on the D-Link website.

Tech Support for customers within India

D-Link Technical Support over the Telephone:

+91-22-26526741

+91-22-26526696 –ext 161 to 167

Monday to Friday 9:30AM to 7:00PM

D-Link Technical Support over the Internet:

<http://www.dlink.co.in>

<http://www.dlink.co.in/dlink/drivers/support.asp>

<ftp://support.dlink.co.in>

email: techsupport@dlink.co.in



Technical Support

You can find software updates and user documentation on the D-Link website.

D-Link provides free technical support for customers for the duration of the warranty period on this product.

Customers can contact D-Link technical support through our web site or by phone.

Tech Support for customers within the Russia

D-Link Technical Support over the Telephone:

(095) 744-00-99

Monday to Friday 10:00am to 6:30pm

D-Link Technical Support over the Internet

<http://www.dlink.ru>

email: support@dlink.ru



Technical Support

You can find software updates and user documentation on the D-Link website.

Tech Support for customers within the U.A.E & North Africa:

D-Link Technical Support over the Telephone:

(971) 4-391-6480 (U.A.E)

Sunday to Wednesday 9:00am to 6:00pm GMT+4

Thursday 9:00am to 1:00pm GMT+4

D-Link Middle East & North Africa

D-Link Technical Support over the Internet:

<http://support.dlink-me.com>

email: support@dlink-me.com

Tech Support for customers within Israel:

D-Link Technical Support over the Telephone:

(972) 971-5701

Sunday to Thursday 9:00am to 5:00pm

D-Link Technical Support over the Internet:

<http://www.dlink.co.il/forum>

e-mail: support@dlink.co.il

Tech Support for customers within Turkey:

D-Link Technical Support over the Telephone:

(+90) 212-289 56 59

Monday to Friday 9:00am to 6:00pm

D-Link Technical Support over the Internet:

<http://www.dlink.com.tr>

e-mail: turkiye@dlink-me.com

Tech Support for customers within Egypt:

D-Link Technical Support over the Telephone:

(202) 414-4295

Sunday to Thursday 9:00am to 5:00pm

D-Link Technical Support over the Internet:

<http://support.dlink-me.com>

e-mail: amostafa@dlink-me.com



Technical Support

You can find software updates and user documentation on the D-Link website.

Tech Support for customers within South Africa and Sub Sahara Region:

D-Link South Africa and Sub Sahara Technical Support over the Telephone:

+27-12-665-2165

08600 DLINK (For South Africa only)

Monday to Friday 8:30am to 9:00pm South Africa Time

D-Link Technical Support over the Internet:

<http://www.d-link.co.za>

[email:support@d-link.co.za](mailto:support@d-link.co.za)



Technical Support

You can find updates and user documentation on the D-Link website

Tech Support for Latin America customers:

D-Link Technical Support over the followings Telephones:

Argentina: 0800-666 1442	Monday to Friday 09:00am to 22:00pm
Chile: 800-214 422	Monday to Friday 08:00am to 21:00pm
Colombia: 01800-700 1588	Monday to Friday 07:00am to 20:00pm
Ecuador: 1800-777 711	Monday to Friday 07:00am to 20:00pm
El Salvador: 800-6137	Monday to Friday 06:00am to 19:00pm
Guatemala: 1800-300 0017	Monday to Friday 06:00am to 19:00pm
Panama: 0800-560 0193	Monday to Friday 07:00am to 20:00pm
Peru: 0800-52049	Monday to Friday 07:00am to 20:00pm
Venezuela: 0800-100 3470	Monday to Friday 08:00am to 21:00pm

D-Link Technical Support over the Internet:

www.dlinkla.com
www.dlinklatinamerica.com
email: support@dlink.cl

Tech Support for customers within Brazil:

D-Link Technical Support over the Telephone:

0800-7014104
Monday to Friday 8:30am to 18:30pm

D-Link Technical Support over the Internet:

www.dlinkbrasil.com.br
email: suporte@dlinkbrasil.com.br

D-Link®
Building Networks for People

Техническая поддержка

Обновления программного обеспечения и документация доступны на Интернет-сайте D-Link.

D-Link предоставляет бесплатную поддержку для клиентов в течение гарантийного срока.

Клиенты могут обратиться в группу технической поддержки D-Link по телефону или через Интернет.

Техническая поддержка D-Link:
(095) 744-00-99

Техническая поддержка через Интернет
<http://www.dlink.ru>
email: support@dlink.ru



Asistencia Técnica

D-Link Latin América pone a disposición de sus clientes, especificaciones, documentación y software mas reciente a través de nuestro Sitio Web

www.dlinklatinamerica.com

El servicio de soporte técnico tiene presencia en numerosos países de la Región Latino América, y presta asistencia gratuita a todos los clientes de D-Link, en forma telefónica e internet, a través de la casilla

soporte@dlinkla.com

Soporte Técnico Help Desk Argentina:

Teléfono: 0800-6661442 Lunes a Viernes 09:00 am a 22:00 pm

Soporte Técnico Help Desk Chile:

Teléfono: 800-214422 Lunes a Viernes 08:00 am a 21:00 pm

Soporte Técnico Help Desk Colombia:

Teléfono: 01800-7001588 Lunes a Viernes 07:00 am a 20:00 pm

Soporte Técnico Help Desk Ecuador:

Teléfono: 1800-777 711 Lunes a Viernes 07:00 am a 20:00 pm

Soporte Técnico Help Desk El Salvador:

Teléfono: 800-6137 Lunes a Viernes 06:00 am a 19:00 pm

Soporte Técnico Help Desk Guatemala:

Teléfono: 1800-300 0017 Lunes a Viernes 06:00 am a 19:00 pm

Soporte Técnico Help Desk Panamá:

Teléfono: 0800-560 0193 Lunes a Viernes 07:00 am a 20:00 pm

Soporte Técnico Help Desk Perú:

Teléfono: 0800-52049 Lunes a Viernes 07:00 am a 20:00 pm

Soporte Técnico Help Desk Venezuela:

Teléfono: 0800-1003470 Lunes a Viernes 08:00 am a 21:00 pm



Suporte Técnico

Você pode encontrar atualizações de software e documentação de usuário no site da D-Link Brasil www.dlinkbrasil.com.br.

A D-Link fornece suporte técnico gratuito para clientes no Brasil durante o período de vigência da garantia deste produto.

Suporte Técnico para clientes no Brasil:

Telefone

São Paulo (11) 2185-9301

Segunda à sexta

Das 8h30 às 18h30

Demais Regiões do Brasil 0800 70 14 104

E-mail:

[email:suporte@dlinkbrasil.com.br](mailto:suporte@dlinkbrasil.com.br)



友冠技術支援

台灣地區用戶可以透過我們的網站，電子郵件或電話與友冠資訊技術支援人員聯絡。

支援服務時間從
週一到週五，上午8:30 a.m. 到 7:00 p.m

Web: <http://www.dlinktw.com.tw/>
FAQ: <http://www.dlinktw.com.tw/support.asp>
Email: dssqa_service@dlinktw.com.tw

Phone: 0800-002-615

如果您是台灣地區以外的用戶，請參考使用手冊中記載的D-Link 全球各地分公司的聯絡資訊取得支援服務。

產品維修與保固相關資訊，請參考友冠資訊網頁說明：
<http://www.dlinktw.com.tw/suppQuick.asp>



技术支持

办公地址：北京市朝阳区建国路 71 号惠通时代广场 C1 座
202 室 邮编: 100025

技术支持中心电话：8008868192/(028)85176977

技术支持中心传真：(028)85176948

维修中心地址：北京市海淀区中关村南大街 9 号理工大厦
1107 室 邮编:100081

维修中心电话：(010)68477035/68477036/68477037

维修中心传真：(010)68477036

网址：<http://www.dlink.com.cn>

办公时间：周一到周五，早09:00到晚18:00



Subject to the terms and conditions set forth herein, D-Link Systems, Inc. ("D-Link") provides this Limited Warranty:

- Only to the person or entity that originally purchased the product from D-Link or its authorized reseller or distributor, and
- Only for products purchased and delivered within the fifty states of the United States, the District of Columbia, U.S. Possessions or Protectorates, U.S. Military Installations, or addresses with an APO or FPO.

Limited Warranty: D-Link warrants that the hardware portion of the D-Link product described below ("Hardware") will be free from material defects in workmanship and materials under normal use from the date of original retail purchase of the product, for the period set forth below ("Warranty Period"), except as otherwise stated herein.

Limited Lifetime Warranty for the product is defined as follows:

Hardware: For as long as the original customer/end user owns the product, or five (5) years after product discontinuance, whichever occurs first (excluding power supplies and fans)

Power supplies and fans: Three (3) Year

Spare parts and spare kits: Ninety (90) days

The customer's sole and exclusive remedy and the entire liability of D-Link and its suppliers under this Limited Warranty will be, at D-Link's option, to repair or replace the defective Hardware during the Warranty Period at no charge to the original owner or to refund the actual purchase price paid. Any repair or replacement will be rendered by D-Link at an Authorized D-Link Service Office. The replacement hardware need not be new or have an identical make, model or part. D-Link may, at its option, replace the defective Hardware or any part thereof with any reconditioned product that D-Link reasonably determines is substantially equivalent (or superior) in all material respects to the defective Hardware. Repaired or replacement hardware will be warranted for the remainder of the original Warranty Period or ninety (90) days, whichever is longer, and is subject to the same limitations and exclusions. If a material defect is incapable of correction, or if D-Link determines that it is not practical to repair or replace the defective Hardware, the actual price paid by the original purchaser for the defective Hardware will be refunded by D-Link upon return to D-Link of the defective Hardware. All Hardware or part thereof that is replaced by D-Link, or for which the purchase price is refunded, shall become the property of D-Link upon replacement or refund.

Limited Software Warranty: D-Link warrants that the software portion of the product ("Software") will substantially conform to D-Link's then current functional specifications for the Software, as set forth in the applicable documentation, from the date of original retail purchase of the Software for a period of ninety (90) days ("Software Warranty Period"), provided that the Software is properly installed on approved hardware and operated as contemplated in its documentation. D-Link further warrants that, during the Software Warranty Period, the magnetic media on which D-Link delivers the Software will be free of physical defects. The customer's sole and exclusive remedy and the entire liability of D-Link and its suppliers under this Limited Warranty will be, at D-Link's option, to replace the non-conforming Software (or defective media) with software that substantially conforms to D-Link's functional specifications for the Software or to refund the portion of the actual purchase price paid that is attributable to the Software. Except as otherwise agreed by D-Link in writing, the replacement Software is provided only to the original licensee, and is subject to the terms and conditions of the license granted by D-Link for the Software. Replacement Software will be warranted for the remainder of the original Warranty Period and is subject to the same limitations and exclusions. If a material non-conformance is incapable of correction, or if D-Link determines in its sole discretion that it is not practical to replace the non-conforming Software, the price paid by the original licensee for the non-conforming Software will be refunded by D-Link; provided that the non-conforming Software (and all copies thereof) is first returned to D-Link. The license granted respecting any Software for which a refund is given automatically terminates.

Non-Applicability of Warranty: The Limited Warranty provided hereunder for Hardware and Software portions of D-Link's products will not be applied to and does not cover any refurbished product and any product purchased through the inventory clearance or liquidation sale or other sales in which D-Link, the sellers, or the liquidators

expressly disclaim their warranty obligation pertaining to the product and in that case, the product is being sold "As-Is" without any warranty whatsoever including, without limitation, the Limited Warranty as described herein, notwithstanding anything stated herein to the contrary.

Submitting A Claim: The customer shall return the product to the original purchase point based on its return policy. In case the return policy period has expired and the product is within warranty, the customer shall submit a claim to D-Link as outlined below:

- The customer must submit with the product as part of the claim a written description of the Hardware defect or Software nonconformance in sufficient detail to allow D-Link to confirm the same, along with proof of purchase of the product (such as a copy of the dated purchase invoice for the product) if the product is not registered.
- The customer must obtain a Case ID Number from D-Link Technical Support at 1-877-453-5465, who will attempt to assist the customer in resolving any suspected defects with the product. If the product is considered defective, the customer must obtain a Return Material Authorization ("RMA") number by completing the RMA form and entering the assigned Case ID Number at <https://rma.dlink.com/>.
- After an RMA number is issued, the defective product must be packaged securely in the original or other suitable shipping package to ensure that it will not be damaged in transit, and the RMA number must be prominently marked on the outside of the package. Do not include any manuals or accessories in the shipping package. D-Link will only replace the defective portion of the product and will not ship back any accessories.

The customer is responsible for all in-bound shipping charges to D-Link. No Cash on Delivery ("COD") is allowed. Products sent COD will either be rejected by D-Link or become the property of D-Link. Products shall be fully insured by the customer and shipped to D-Link Systems, Inc., 17595 Mt. Herman, Fountain Valley, CA 92708. D-Link will not be held responsible for any packages that are lost in transit to D-Link. The repaired or replaced packages will be shipped to the customer via UPS Ground or any common carrier selected by D-Link. Return shipping charges shall be prepaid by D-Link if you use an address in the United States, otherwise we will ship the product to you freight collect. Expedited shipping is available upon request and provided shipping charges are prepaid by the customer.

D-Link may reject or return any product that is not packaged and shipped in strict compliance with the foregoing requirements, or for which an RMA number is not visible from the outside of the package. The product owner agrees to pay D-Link's reasonable handling and return shipping charges for any product that is not packaged and shipped in accordance with the foregoing requirements, or that is determined by D-Link not to be defective or non-conforming.

What Is Not Covered: The Limited Warranty provided herein by D-Link does not cover: Products that, in D-Link's judgment, have been subjected to abuse, accident, alteration, modification, tampering, negligence, misuse, faulty installation, lack of reasonable care, repair or service in any way that is not contemplated in the documentation for the product, or if the model or serial number has been altered, tampered with, defaced or removed; Initial installation, installation and removal of the product for repair, and shipping costs; Operational adjustments covered in the operating manual for the product, and normal maintenance; Damage that occurs in shipment, due to act of God, failures due to power surge, and cosmetic damage; Any hardware, software, firmware or other products or services provided by anyone other than D-Link; and Products that have been purchased from inventory clearance or liquidation sales or other sales in which D-Link, the sellers, or the liquidators expressly disclaim their warranty obligation pertaining to the product. While necessary maintenance or repairs on your Product can be performed by any company, we recommend that you use only an Authorized D-Link Service Office. Improper or incorrectly performed maintenance or repair voids this Limited Warranty.

Disclaimer of Other Warranties: EXCEPT FOR THE LIMITED WARRANTY SPECIFIED HEREIN, THE PRODUCT IS PROVIDED "AS-IS" WITHOUT ANY WARRANTY OF ANY KIND WHATSOEVER INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT. IF ANY IMPLIED WARRANTY CANNOT BE DISCLAIMED IN ANY TERRITORY WHERE A PRODUCT IS SOLD, THE DURATION OF SUCH IMPLIED WARRANTY SHALL BE LIMITED TO NINETY (90) DAYS. EXCEPT AS EXPRESSLY COVERED UNDER THE LIMITED WARRANTY PROVIDED

HEREIN, THE ENTIRE RISK AS TO THE QUALITY, SELECTION AND PERFORMANCE OF THE PRODUCT IS WITH THE PURCHASER OF THE PRODUCT.

Limitation of Liability: TO THE MAXIMUM EXTENT PERMITTED BY LAW, D-LINK IS NOT LIABLE UNDER ANY CONTRACT, NEGLIGENCE, STRICT LIABILITY OR OTHER LEGAL OR EQUITABLE THEORY FOR ANY LOSS OF USE OF THE PRODUCT, INCONVENIENCE OR DAMAGES OF ANY CHARACTER, WHETHER DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL (INCLUDING, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF GOODWILL, LOSS OF REVENUE OR PROFIT, WORK STOPPAGE, COMPUTER FAILURE OR MALFUNCTION, FAILURE OF OTHER EQUIPMENT OR COMPUTER PROGRAMS TO WHICH D-LINK'S PRODUCT IS CONNECTED WITH, LOSS OF INFORMATION OR DATA CONTAINED IN, STORED ON, OR INTEGRATED WITH ANY PRODUCT RETURNED TO D-LINK FOR WARRANTY SERVICE) RESULTING FROM THE USE OF THE PRODUCT, RELATING TO WARRANTY SERVICE, OR ARISING OUT OF ANY BREACH OF THIS LIMITED WARRANTY, EVEN IF D-LINK HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THE SOLE REMEDY FOR A BREACH OF THE FOREGOING LIMITED WARRANTY IS REPAIR, REPLACEMENT OR REFUND OF THE DEFECTIVE OR NON-CONFORMING PRODUCT. THE MAXIMUM LIABILITY OF D-LINK UNDER THIS WARRANTY IS LIMITED TO THE PURCHASE PRICE OF THE PRODUCT COVERED BY THE WARRANTY. THE FOREGOING EXPRESS WRITTEN WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ANY OTHER WARRANTIES OR REMEDIES, EXPRESS, IMPLIED OR STATUTORY.

Governing Law: This Limited Warranty shall be governed by the laws of the State of California. Some states do not allow exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the foregoing limitations and exclusions may not apply. This Limited Warranty provides specific legal rights and you may also have other rights which vary from state to state.

Trademarks: D-Link is a registered trademark of D-Link Systems, Inc. Other trademarks or registered trademarks are the property of their respective owners.

Copyright Statement: No part of this publication or documentation accompanying this product may be reproduced in any form or by any means or used to make any derivative such as translation, transformation, or adaptation without permission from D-Link Corporation/D-Link Systems, Inc., as stipulated by the United States Copyright Act of 1976 and any amendments thereto. Contents are subject to change without prior notice. Copyright 2004 by D-Link Corporation/D-Link Systems, Inc. All rights reserved.

CE Mark Warning: This is a Class A product. In a residential environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

FCC Statement: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a commercial installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. Operation of this equipment in a residential environment is likely to cause harmful interference to radio or television reception. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

For detailed warranty information applicable to products purchased outside the United States, please contact the corresponding local D-Link office.

Product Registration

D-Link products can be registered online at <http://support.dlink.com/register/>. Product registration is entirely voluntary and failure to complete or return this form will not diminish your warranty rights.

International Offices

U.S.A

17595 Mt. Herrmann Street
Fountain Valley, CA. 92708
TEL: 714-885-6000
Fax 866-743-4905
URL: www.dlink.com

Canada

2180 Winston Park Drive
Oakville, Ontario, L6H 5W1
Canada
TEL: 1-905-8295033
FAX: 1-905-8295223
URL: www.dlink.ca

Europe (U. K.)

4th Floor, Merit House
Edgware Road, Colindale
London NW9 5AB

U.K.

TEL: 44-20-8731-5555
FAX: 44-20-8731-5511
URL: www.dlink.co.uk

Germany

Schwalbacher Strasse 74
D-65760 Eschborn
Germany
TEL: 49-6196-77990
FAX: 49-6196-7799300
URL: www.dlink.de

France

Le Florilege #.2, Allee de la Fresnerie
78330 Fontenay le Fleury
France
TEL: 33-1-30238688
FAX: 33-1-30238689
URL: www.dlink-france.fr

Netherlands

Weena 290
3012 NJ Rotterdam
Netherlands
Tel: +31-10-282-1445
Fax: +31-10-282-1331
URL: www.dlink-benelux.com

Belgium

Rue des Colonies 11
B-1000 Brussels
Belgium
Tel: +32(0)2 517 7111
Fax: +32(0)2 517 6500
URL: www.dlink-benelux.com

Italy

Via Nino Bonnet n. 6/b
20154 ñ Milano,
Italy
TEL: 39-02-2900-0676
FAX: 39-02-2900-1723
URL: www.dlink.it

Sweden

P.O. Box 15036, S-167 15 Bromma
Sweden
TEL: 46-(0)8564-61900
FAX: 46-(0)8564-61901
URL: www.dlink.se

Denmark

Naverland 2, DK-2600
Glostrup, Copenhagen,
TEL: 45-43-969040
FAX: 45-43-424347
URL: www.dlink.dk

Norway

Karihaugveien 89
1086 Oslo
Norway
TEL: 47-23-897189
FAX: 47-22-309085
URL: www.dlink.no

Finland

Pakkalankuja 7A
01510 Vantaa,
Finland
TEL : +358-9-2707 5080
FAX: + 358-9-2707 5081
URL: www.dlink.fi

Iberia

C/Sabino De Arana,
56 Bajos
08028 Barcelona
TEL: 34 93 4090770
FAX: 34 93 4910795
URL: www.dlinkiberia.es

Singapore

1 International Business Park
#03-12 The Synergy
Singapore 609917
TEL: 65-6774-6233
FAX: 65-6774-6322
URL: www.dlink-intl.com

Australia

1 Giffnock Avenue,
North Ryde, NSW 2113
Australia
TEL: 61-2-8899-1800
FAX: 61-2-8899-1868
URL: www.dlink.com.au

India

D-Link House, Kurla Bandra Complex
Road,
Off CST Road, Santacruz (East), Mumbai -
400098.

India

TEL: 91-022-26526696/56902210
FAX: 91-022-26528914
URL: www.dlink.co.in

Middle East (Dubai)

P.O.Box: 500376
Office No.:103, Building:3
Dubai Internet City
Dubai, United Arab Emirates
Tel:+971-4-3916480
Fax:+971-4-3908881
URL: www.dlink-me.com

Turkey

Regus Offices
Beybi Giz Plaza, Ayazaga Mah. Meydan
Sok.
No:28
Maslak 34396, Istanbul-Turkiye
TEL: +90 212 335 2553
FAX: +90 212 335 2500
URL: www.dlink.com.tr

Egypt

19 El-Shahed Helmy, El Masri
Al-Maza, Heliopolis
Cairo, Egypt.
TEL: +202 414 4295
FAX: +202 415 6704
URL: www.dlink-me.com

Israel

11 Hamanofim Street
Ackerstein Towers, Regus Business
Center
P.O.B 2148, Hertzelia-Pituach 46120.
Israel
TEL: +972-9-9715700
FAX: +972-9-9715601
URL: www.dlink.co.il

Latin America

Isidora Goyechea 2934 of 702,
Las Condes
Santiago ñ Chile S.A.
TEL: 56-2-232-3185
FAX: 56-2-232-0923
URL: www.dlink.cl

Brasil

Av das Nacoes Unidas,
11857 - 14 - andar - cj 141/142
Brooklin Novo
Sao Paulo - SP - Brazil
CEP 04578-000
TEL: +55 11 55039320
FAX: +55 11 55039322
URL: www.dlinkbrasil.com.br

South Africa

Einstein Park II
Block B
102-106 Witch-Hazel Avenue
Highveld Technopark
Centurion
Gauteng
Republic of South Africa
TEL: 27-12-665-2165
FAX: 27-12-665-2186
URL: www.d-link.co.za

Russia

Grafsky per., 14, floor 6
Moscow
129626 Russia
TEL: 7-095-744-0099
FAX: 7-095-744-0099 #350
URL: www.dlink.ru

China

No.202,C1 Building, Huitong Office Park,
No.71, Jianguo Road, Chaoyang District,
Beijing,
100025, China.
TEL +86-10-58635800
FAX: +86-10-58635799
URL: www.dlink.com.cn

Taiwan

2F, No. 119, Pao-Chung Rd.
Hsin-Tien, Taipei
Taiwan
TEL: 886-2-2910-2626
FAX: 886-2-2910-1515
URL: www.dlinktw.com.tw

Headquarters

2F, No. 233-2, Pao-Chiao Rd.
Hsin-Tien, Taipei
Taiwan
TEL: 886-2-2916-1600
FAX: 886-2-2914-6299
URL: www.dlink.com