



Firmware Version: 1.00rc011
Published Date: 2018/04/23

Content:

Upgrading Instructions:..... 2

 Upgrading by using Web-UI..... 2

New Features:..... 3

Changes of MIB & D-View Module:..... 3

Problems Fixed: 3

Known Issues: 3

Related Documentation: 3

Revision History and System Requirement:

Firmware Version	Date	Model	Hardware Version


Upgrading Instructions:

D-Link AP supports firmware upgrading via Web-UI. You may download the firmware from D-Link web site <http://tsd.dlink.com.tw>.

Upgrading by using Web-UI

1. Connect a work station to the LAN port of Access Point.
2. Open the web browser of work station and entering the IP address of the AP. The system default IP address is 192.168.0.50.
3. Enter administrator's username and password, user name is "admin" and leave the password field blank by default.

To update the AP's firmware, click **Maintenance > Firmware and SSL Certification Upload**



The screenshot displays the D-Link DAP-2680 Web-UI interface. The top navigation bar includes links for Home, Maintenance, Configuration, System, Logout, and Help. The left sidebar shows a tree view with DAP-2680, Basic Settings, Advanced Settings, and Status. The main content area is titled "System Information" and lists the following details:

Model Name	DAP-2680
Firmware Version	1.00 18:13:22 01/08/2018
System Name	D-Link DAP-2680
Location	
System Time	01/01/1970 08:00:28
Up Time	0 Days, 00:00:29
Operation Mode(2.4GHz)	Access Point
Operation Mode(5GHz)	Access Point
MAC Address(2.4GHz)	00:15:a9:2c:a5:00
MAC Address(5GHz)	00:15:a9:2c:a5:08
IP Address	192.168.0.50

New Features:

First Release

Changes of MIB & D-View Module:

First Release

Problems Fixed:

Firmware Version	Problems Fixed
V1.00	None

Known Issues:

Firmware Version	Known Issues
V1.00	None

Related Documentation:

- DAP-2680 User Manual v1.00