



Firmware Version: 2.01r098

Published Date: 2019/11/25

Content:

Upgrading Instructions:..... 2

 Upgrading by using Web-UI..... 2

New Features:..... 3

Changes of MIB & D-View Module:..... 3

Problems Fixed: 3

Known Issues: 3

Related Documentation: 3

Revision History and System Requirement:


Firmware Version	Date	Model	Hardware Version
1.05rc047	2016/09/29	DAP-3662	A1/A2

Upgrading Instructions:

D-Link AP supports firmware upgrading via Web-UI. You may download the firmware from D-Link web site <http://tsd.dlink.com.tw>.

Upgrading by using Web-UI

1. Connect a work station to the LAN port of Access Point.
2. Open the web browser of work station and entering the IP address of the AP. The system default IP address is 192.168.0.50.
3. Enter administrator's username and password, user name is "admin" and leave the password field blank by default.
To update the AP's firmware, click **Maintenance > Firmware and SSL Certification Upload**



New Features:

1. Use QCA's WDS
2. Remove AP Array
3. Support Nuclias Connect
4. Support DDPv5/APP
5. In default settings, the network IP address setting is Dynamic IP
6. Support MDNS
7. Modify Time zone settings
8. Update country selection table
9. Move IP filter settings page from Captive Portal to Filter folder, behind WLAN Partition (AP GUI). IP filter function is independent feature and can work with all non-captive portal attenuation
10. Default admin user name/password is admin/admin
11. Add setup Wizard when first login
12. WPA/WPA2 throughput issue

Changes of MIB & D-View Module:

None

Problems Fixed:

Firmware Version	Problems Fixed
V2.01	None

Known Issues:

Firmware Version	Known Issues
V2.01	None

Related Documentation:

DAP-3662 Manual v2.00