



Firmware Version: V1.00
Prom Code Version: N/A
Published Date: 2017/02/06

Content:

Upgrading Instructions:..... 2

New Features:..... 2

Problems Fixed: 2

Known Issues: 2

Related Documentation: 2

Revision History and System Requirement:

Firmware Version	Date	Model	Hardware Version
V1.00	2017/02/06	DCS-4622	A1

Upgrading Instructions:

Follow the steps below to upgrade the firmware:

1. Download the latest firmware file to your hard drive from the D-Link website.
2. Log-in camera web UI and go to **Maintenance / Firmware** web page upgrade
3. Locate the file (upgraded firmware) on your hard drive by clicking **Choose File**.
4. Click **Upload** to upgrade the firmware on your camera.

New Features:

Fireware Version	New Features
V1.00	1.New model MP FW release

Problems Fixed:

Firmware Version	Problems Fixed
	N/A

Known Issues:

Firmware Version	Known Issues
	N/A

Related Documentation:

N/A