



3

**Firmware Version:** V1.01.01  
**Prom Code Version:** N/A  
**Published Date:** 2019/01/08

**Content:**

Upgrading Instructions:..... 2

New Features:..... 2

Problems Fixed:..... 2

Known Issues: ..... 2

Related Documentation: ..... 2

## Revision History and System Requirement:

| Firmware Version | Date       | Model      | Hardware Version |
|------------------|------------|------------|------------------|
| V1.00            | 2017/12/01 | DCS-4633EV | A1               |
| V1.01.01         | 2019/01/08 | DCS-4633EV | A1               |

## Upgrading Instructions:

1. Download the latest firmware file from the D-Link website. The file is in ".pkg" file format.
2. Log-in camera web UI and enter Setup/Advanced Setup/System configuration/Firmware upgrade
3. Click Browse... and specify the firmware file.
4. Click Upload. The camera starts to upgrade and will reboot automatically when the upgrade completes.

## New Features:

| Fireware Version | New Features  |
|------------------|---------------|
| V1.00            | First release |

## Problems Fixed:

| Firmware Version | Problems Fixed                                           |
|------------------|----------------------------------------------------------|
| V1.01.01         | 1. Updated new digital signature.<br>2. Minor bug fixed. |
|                  |                                                          |
|                  |                                                          |

## Known Issues:

| Firmware Version | Known Issues |
|------------------|--------------|
|                  | N/A          |

## Related Documentation:

N/A