



Firmware Version: V1.10
Prom Code Version: N/A
Published Date: 2015/1/5

Content:

Upgrading Instructions:..... 2
New Features:..... 2
Problems Fixed: 2
Known Issues: 2
Related Documentation: 2

Revision History and System Requirement:

| Firmware Version | Date | Model | Hardware Version |
|------------------|-----------|----------|------------------|
| V1.00 | 2012/8/9 | DCS-7413 | A1 |
| V1.01 | 2013/6/13 | DCS-7413 | A1 |
| V1.10 | 2015/1/5 | DCS-7413 | A1 |

Upgrading Instructions:

Follow the steps below to upgrade the firmware:

1. Download the latest firmware file from the D-Link website. The file is in .bin file format.
2. Log-in camera web UI and enter setup/Maintenance/Firmware upgrade
3. Click Browse... and specify the firmware file.
4. Click Upgrade. The camera starts to upgrade and will reboot automatically when the upgrade completes.

New Features:

| Firmware Version | New Features |
|------------------|--------------|
| | N/A |

Problems Fixed:

| Firmware Version | Problems Fixed |
|------------------|---|
| V1.01.02 | <ol style="list-style-type: none"> 1. Remove the "guest" account 2. Fixed the UPNP security issue. 3. RTSP Authentication default enable |
| V1.10.00 | <ol style="list-style-type: none"> 1. Fixed the security of SSL 3.0. 2. Fixed the security of getting the snapshot without authentication |

Known Issues:

| Firmware Version | Known Issues |
|------------------|--------------|
| | N/A |

Related Documentation:

N/A