


Quick Installation Guide



What's in the Box



2K QHD Indoor Wi-Fi Camera
(DCS-8350LH)



MicroUSB Power Adapter



Mounting Screws



Quick Installation Guide

Simple Setup


Note: Please set up your device before mounting it.

- 1] Get the **mydlink** app on the App Store or on Google Play. Launch the app, then **Sign In** or **Create a New Account**.




- 2] **Power on** the device and wait for the Status LED to flash orange.


Note: Make sure that your mobile device's Bluetooth is on.



- 3] Place your device next to your mobile device. A prompt will appear - tap **Add Device**, then follow the app instructions.



LED Behavior



- Connected to network and mydlink
- Booting up
- ☀ Ready for setup
- 🌈 Firmware being updated - do not power off
- ☀ Wi-Fi connection lost
- 🔴 Timeout for setup - please power cycle the device

Setup Code



This is a backup of your device's Setup Code. Please keep it as future reference for your device.




Mounting

To get the most out of your camera's view and features, please take the following placement guidelines into consideration.


Height: Place the camera 1.5 - 2 meters (4 to 6.5 feet) from the ground.

Person Detection: Person Detection works best when the subject is between 2 to 5 meters (6.5 - 16 feet) away from the camera.




Pole Mounting

Note: Cable ties are not included with this product.




Place the mounting bracket against the pole where you would like to mount the camera, and make sure the arrow is pointing upwards.

Note: The mounting bracket is attached to the bottom of the device. Turn the mounting bracket counterclockwise to detach it.




Thread the cable ties through the slots on the mounting bracket. Make sure the textured side of the cable ties is facing the pole to avoid slippage. Then fasten the plastic ties around the pole to secure the mounting bracket.



Align the arrow on the camera base with the dot on the mounting bracket and turn clockwise to secure them together.


Wall Mounting

The device can be mounted on a wall or on the ceiling.




Align the mounting bracket so that the arrow is pointing up. Use a pencil to make marks in the two holes.


Note: The mounting bracket is attached to the bottom of the device. Turn the mounting bracket counterclockwise to detach it.




Use a 6 mm drill bit to drill two 26 mm deep holes over the pencil marks.




Hammer in the plastic anchors to support the screws.



Align the mounting bracket's holes over the plastic anchors. Drive the screws into the anchors to secure the mounting bracket.



Align the arrow on the camera base with the dot on the mounting bracket and turn clockwise to secure them together.



Adjust your camera via its tilt and rotation options until you're satisfied with the view point.

FAQ

What do I do if my device is not working properly?

Reset and reinstall your device. Use a paper clip to press the recessed **Reset** button and the LED will turn solid red. During installation, ensure that:

- Your router is connected to the Internet and Wi-Fi is enabled
- Your mobile device is connected to your router's Wi-Fi and Bluetooth is enabled
- Your mydlink device is in range of your Wi-Fi network

How can I use voice commands to control my device?

The device will work with both Amazon Alexa and the Google Assistant. For setup instructions on these services, visit the following websites:

Amazon Alexa

dlink.com/en/alexa

The Google Assistant:

dlink.com/en/google-assistant

Why is my microSD card not working/not supported?

The microSD card must be formatted into the correct file system (FAT32) before it can be used with this product. This can be done in the mydlink app by selecting the **Format** function in the storage menu under the device settings.

What is my username and password for setting up my device with an ONVIF system?

To connect your device to an ONVIF system, key in "**admin**" as the username and use the PIN code of your mydlink device as the password. You can find the PIN code on your device's label.

What is Color Night Vision and how does it work?

Color Night Vision is enabled by default and allows you to see color images while viewing the live feed in low light scenarios.

Need Help?

Having trouble installing your new product?

D-Link's website contains the latest user documentation and software updates for D-Link products. Customers can contact D-Link Technical Support through our website by choosing the relevant region.

Contact Us

www.dlink.com/en/contact-us

