D-Link Quick Installation Guide

This product can be set up using any current Web browser, i.e., Internet Explorer 6 or Netscape Navigator 6 or above.



DSA-3100 Airspot[™] Public/ Private Gateway

Before You Begin

You will need the following:

- \bullet Computer with an Ethernet adapter and a Windows, Mac, or Unix based operating system.
- Internet Explorer or Netscape Navigator, version 6.0 or above, with JavaScript enabled.

Check Your Package Contents

These are the items included with your DSA-3100 purchase:



If any of the above items are missing, please contact your reseller.

©2006 D-Link Systems, Inc. All rights reserved. Trademarks or registered trademarks are the property of their respective holders. Software and specifications subject to change without notice. DSA-3100. 03062006

Connecting The DSA-3100 To Your Network







- A. Power on the DSA-3100.
- B. Connect an Ethernet cable from the Public LAN port to a switch or wireless access point on your public network. The Public LAN LED will illuminate to indicate a proper connection. If the Public LAN LED doesn't light up, please check the connections.
- C. Connect an Ethernet cable from the **Private LAN** port to an Ethernet port on your private network's switch. If properly connected, the Private LAN LED will illuminate. (Note: For configuration purposes a computer can be connected directly to this port using a standard Ethernet cable)
- D. Attach an Ethernet cable to the WAN port on the back panel of the DSA-3100. Connect the other end to a router or directly to a broadband modem. The WAN LED light will illuminate to indicate proper connection.

When you have completed the steps in this *Quick Installation Guide*, your connected network should look similar to this:





Connect the computer you will be using for configuration to the Private Network or directly to the Private LAN Port.

To obtain a new IP address from the DSA-3100 you may need to restart your computer or release and renew your IP address. Make sure that the network adapter in your computer is configured properly. Instructions for configuring the network adapter to obtain an IP address automatically from the DSA-3100 can be found in the Appendix.

The DSA-3100 provides Web based configuration. You can configure your DSA-3100 using a Web browser such as Internet Explorer or Netscape Navigator in Windows, Macintosh, or UNIX based environments.

Open your Web browser and type https://192.168.0.40 into the URL address box. Then press the Enter or Return key.



Be sure to use **https** instead of http when typing in the URL address. This ensures that a secure connection is made between your system and the DSA-3100.

(The IP Address shown in the example above is the default setting. If you've changed the IP Address of the DSA-3100 to conform to a network then input that IP Address instead of the default IP Address.)

	D-Link	DSA-3100 Airspot Public/Private Gateway		
Type admin for both the username and password.	Us Pa	Administrator tr Name:		
Click Enter				



Once you have logged in, the home screen will appear.

Click Run Wizard

Brand Brand

🌁 http://10.2.3.69 - Wizard - Microsoft Internet Explorer _ 🗆 🗙 You have the option to establish a new D-Link **DSA-3100** Setup Wizard password for the admin account. Step 1: Change Admin's Password You may change the Admin's password by entering in a new password. Click Next to continue. Admin Password Enter a new admin password Verify Password and retype it for verification Click Next 🍯 (1 item rema 📕 Interne

Select the appropriate time zone for your location.

Click Next





Done

Enter the system information:

- Succeed Page: The URL users are directed to when successfully authenticated.
- **Time Server:** Specify an external time server for time synchronization.
- DNS Server IP: IP address of the Domain Name Server.

M Inter

Click Next

Select the type of Internet connection that you have.

Select an Option

Click Next



Configure the Public LAN Port:

- IP Address: The IP address used for the DSA-3100 on the Public LAN.
- Subnet Mask: The Subnet Mask of the DSA-3100 on the Public LAN.
- DHCP Server Enabled/Disabled: With DHCP Server enabled, IP addresses are provided automatically to clients on the Public LAN.



Click Next



Using The Setup Wizard (continued)

Specify the DHCP Server Settings.

Specify a range of IP addresses to assign the DHCP clients. The range is entered in the format "Start IP – End IP" i.e. 192.168.0.101 – 192.168.0.200. Enter the Domain Name and Primary DNS Server settings for the clients. Entering a Secondary DNS Server is optional.



Select the User Manager based on the authentication methods you are using. For the purpose of this Quick Installation Guide we will select the Local User authentication method.

🛂 Wizard - Micros	oft Internet Explorer		
D-Link	DSA-3100	Setup Wiza	rd
Step 5: S	et Public LAN	Port's DHCP	Server
DHCP Settings.	Click Next to continu	IE.	
	DHCP Scope		
	Start IP Address	192.168.1.101	*
	End IP Address	192.168.1.200	*
	Domain Name	dlink.com	*
F	Primary DNS Server	4.2.2.2	•
Sec	ondary DNS Server		
		Ba	Ck Next Exit

Difficulty	
DIME	DSA-3100 Setup Wizard
Step 6	: Select Authentication Types
Select User Auth	nentication Types. Click Next to continue.
	Cocal User
	C POP3 User
	C RADIUS User
	C LDAP User
	200
	G 🖉 🖉
	Back Next Ex
Done	👔 Internet

Click Next

Click Next

Enter a User Name and Password information as necessary. User Accounts can be restricted to specific MAC addresses if desired. Click Add after entering each User Account. Repeat this step for each user.





Setup Wizard Complete Click Restart to complete your configuration. Click Restart to Complete your Click Restart to Save the current setings and reboot the DSA-3100. Click Restart to save the current setings and reboot the DSA-3100. Click Restart to save the current setings and reboot the DSA-3100.

Appendix - IP Configuration

To connect to the network, make sure the network adapter in your computer is configured properly. Here's how to configure the network adapter to obtain an IP address automatically from the DSA-3100 *Air*spot[™]Public/Private Gateway.

Microsoft Windows XP:

Go to Start > right click on My Network Places > select Properties > Right-click on the Network Connection of the Ethernet adapter connecting to the DSA-3100 and select Properties.





Appendix - IP Configuration (continued)

Apple Mac OS X:

Go to the **Apple Menu** and **Select System Preferences.**







The IP address information, the Subnet Mask, the DSA-3100 IP address and the Ethernet adapter address will appear.

Click on Apply Now

11247 741	Displays Sour	d Network Starts	ip Disk		
		Location: Aut	tomatic	•	
Show: (Built-in Ethern	iet			
_		TCP/IP PPPoE	AppleTalk	Proxies	
	Configure:	Using DHCP			
			Doma	in Name Serv	ers (Optional)
	IP Address:	192.168.0.160 (Provided by DHCP	Server)		
	Subnet Mask:	255.255.255.0			
	Router:	192.168.0.1	Searc	h Domains	(Optional)
D	HCP Client ID:	(Optional)			
Eth	ernet Address:	00:06:96:79:de	Examp 5a	le: apple.com, e	arthlink.net

<u>Notes</u>

Technical Support

You can find software updates and user documentation on the D-Link website.

D-Link provides free technical support for customers within the United States and within Canada for the duration of the warranty period on this product.

U.S. and Canadian customers can contact D-Link technical support through our website, or by phone.

Tech Support for customers within the United States:

D-Link Technical Support over the Telephone:

(877) 453-5465 6am-6pm PST, Mon-Fri.

D-Link Technical Support over the Internet: http://support.dlink.com email:support@dlink.com

Tech Support for customers within Canada:

D-Link Technical Support over the Telephone: (800) 361-5265 Monday to Friday 8:30am to 9:00pm EST

D-Link Technical Support over the Internet: http://support.dlink.ca

email:support@dlink.ca

