



Have peace of mind and get alerted to changes at home



DCH-S220 mydlink® Wi-Fi Siren

Features

- Use with mydlink-enabled smart devices to sound the siren based on leak, motion, sound or other actions
- Easy setup with connection to your existing Wi-Fi network
- Controlled by the free mydlink® Home mobile app
- 6 alarm sounds to create unique audible alerts based on different triggers
- Up to 100 decibels with adjustable volume control using the mobile app
- Wall plug design (AC powered)

Overview

The DCH-S220 mydlink® Wi-Fi Siren is a wireless siren that helps keep your home safe. Pair the siren with the mydlink Wi-Fi Motion or Water Sensor (DCH-S150/DCH-S160) so when either motion or water is detected, you can be notified. When the siren is triggered, it will generate a 100 dB (max) audio alarm and it will send push notifications to your smartphone so you know what is going on at home from anywhere.

Works well with other D-Link Connected Home Devices

The mydlink® Wi-Fi Siren can be used with other D-Link Connected Home devices such as a water sensor or a motion sensor, so you can customize your own home automation system to fit your needs. Install a DCH-S150 motion sensor and as motion is detected, the siren will go off to alert you of a potential danger.

Easy Setup

The DCH-S220 can be easily set up. Download the free mydlink® Home app and follow the step-by-step instructions to quickly configure the DCH-S220. Connecting to your Wi-Fi network is as easy as a push of a button: simply push the Wi-Fi Protected Setup (WPS) and you are ready to go.

DCH-S220

mydlink® Wi-Fi Siren

Technical Specifications		
Functionality		
Alarm Sounds	6 different built-in sounds: • Emergency • Fire • Ambulance • Police • Door Chime • Arm/Disarm	
Alarm volume	Selectable volume via mobile app: • 100 / 90 / 80 dB	
Features	• Sound alarm based on trigger from other mydlink compatible devices • Receive mobile push notification • Schedule alarm sound at certain times	
Mobile app	• mydlink® Home app for iPhone, iPad and Android smartphones and tablets Requires iOS 7 or above or Android 4.0 or above	
Compatible devices	• Wi-Fi Motion Sensor (DCH-S150) • Wi-Fi Water Sensor (DCH-S160) • Wi-Fi Smart Plug (DSP-W110) • Wi-Fi Smart Plug (DSP-W215)	mydlink Wi-Fi Cameras: DCS-935L
General		
Wireless	• 802.11n/g	
Wireless Frequency Range	• 2.4GHz to 2.4835GHz	
Maximum Operating Range	• Within wireless coverage from existing Wi-Fi network	
Antennas	• Two internal antennas	
LED	• Status • Warning	
Buttons	• Wi-Fi Protected Setup (WPS) • Reset	
Security	• Wi-Fi Protected Access (WPA/WPA2) • Wi-Fi Protected Setup (WPS)	
Minimum Requirements	• Smartphone or tablet (iOS 7 or above; Android 4.0 or above) • Router with Wi-Fi and internet connection • One available power outlet (125V AC)	
Physical		
Indoor or Outdoor Use	• Indoor use only	
Dimensions	• 2.56 x 2.56 x 2.07 inches	
Weight	• 3.70 ounces	
Power	• Input: 125V AC, 50/60 Hz	
Temperature	• Operating: 32 to 104 °F	• Storage: -4 to 149 °F
Humidity	• Operating: 10% to 90% non-condensing	• Storage: 5% to 95% non-condensing
Certifications	• FCC	• UL

For more information

U.S.A. | 17595 Mt. Herrmann Street | Fountain Valley, CA 92708 | 800.326.1688 | dlink.com

©2015 D-Link Corporation/D-Link Systems, Inc. All rights reserved. D-Link, the D-Link logo, mydlink and the D-link RoHS logo are trademarks or registered trademarks of D-Link Corporation or its subsidiaries in the United States and/or other countries. Other trademarks or registered trademarks are the property of their respective owners. iPhone and iPad are registered trademarks of Apple Inc. Android is a trademark of Google Inc. Windows is a registered trademark of Microsoft Inc.

DCH-S220 mydlink® Wi-Fi Siren

Order Information	
Part Number	DCH-S220
Description	mydlink® Wi-Fi Siren
Warranty	1-year Limited Warranty

¹ iOS7 or above. Android 4.0 or above. For a detailed list please refer to the mobile app store

² Works with DCH-S150, DSP-W110, DSP-W215, DCS-935L, and DCH-S160


How it works:



Works great with:

-  **Wi-Fi Motion Sensor**
Know when unexpected motion is detected.
-  **Wi-Fi Water Sensor**
Be notified when water is detected at home.
-  **Wi-Fi Camera**
Be notified when motion or sound is detected at home.

Side View



Front View



For more information

U.S.A. | 17595 Mt. Herrmann Street | Fountain Valley, CA 92708 | 800.326.1688 | dlink.com

©2015 D-Link Corporation/D-Link Systems, Inc. All rights reserved. D-Link, the D-Link logo, mydlink and the D-link RoHS logo are trademarks or registered trademarks of D-Link Corporation or its subsidiaries in the United States and/or other countries. Other trademarks or registered trademarks are the property of their respective owners. iPhone and iPad are registered trademarks of Apple Inc. Android is a trademark of Google Inc. Windows is a registered trademark of Microsoft Inc.