



**Firmware Version:** V1.00b14  
**Prom Code Version:**  
**Published Date:** 2014/7/10

---

### Content:

Upgrading Instructions:.....	2
New Features:.....	2
Problems Fixed: .....	2
Known Issues: .....	2
Related Documentation: .....	3

## Revision History and System Requirement:

Firmware Version	Date	Model	Hardware Version
V1.00b14	2014/7/10	DCS-6045L	A1

## Upgrading Instructions:

Follow the steps below to upgrade the firmware:

1. Download the latest firmware file from the D-Link website. The file is in .bin file format.
2. Log-in camera web UI and enter setup/Maintenance/Firmware upgrade
3. Click Browse... and specify the firmware file.
3. Click Upgrade. The camera starts to upgrade and will reboot automatically when the upgrade completes.

## New Features:

Firmware Version	New Features
V1.00b14	Initial version.

## Problems Fixed:

Firmware Version	Problems Fixed

## Known Issues:

Firmware Version	Known Issues


**Related Documentation:**

---

N/A