



**Firmware Version:** V1.01

**Published Date:** 2015/1/5

---

### Content:

|                              |   |
|------------------------------|---|
| Upgrading Instructions:..... | 2 |
| New Features:.....           | 2 |
| Problems Fixed: .....        | 2 |
| Known Issues: .....          | 2 |
| Related Documentation: ..... | 2 |

## Revision History and System Requirement:

| Firmware Version | Date      | Model    | Hardware Version |
|------------------|-----------|----------|------------------|
| V1.00            | 2013/7/24 | DCS-6314 | A1               |
| V1.01            | 2015/1/5  | DCS-6314 | A1               |

## Upgrading Instructions:

Follow the steps below to upgrade the firmware:

1. Download the latest firmware file from the D-Link website. The file is in .bin file format.
2. Log-in camera web UI and enter setup/Maintenance/Firmware upgrade
3. Click Browse... and specify the firmware file.
4. Click Upgrade. The camera starts to upgrade and will reboot automatically when the upgrade completes.

## New Features:

| Firmware Version | New Features              |
|------------------|---------------------------|
| V1.00.00         | 1.New model MP FW release |

## Problems Fixed:

| Firmware Version | Problems Fixed   |
|------------------|--|
| V1.01.00         | <ol style="list-style-type: none"> <li>1. Fixed the security of SSL 3.0.</li> <li>2. Fixed the security of getting the snapshot without authentication.</li> </ol> |

## Known Issues:

| Firmware Version | Known Issues |
|------------------|--------------|
|                  | N/A          |

## Related Documentation:

N/A