



**Firmware Version:** V1.00  
**Prom Code Version:** N/A  
**Published Date:** 2014/06/12

---

## Content:

Upgrading Instructions:.....	2
New Features:.....	2
Problems Fixed: .....	2
Known Issues: .....	2
Related Documentation: .....	2

## Revision History and System Requirement:

Firmware Version	Date	Model	Hardware Version
V1.00	2014/06/12	DCS-6315	A1

## Upgrading Instructions:

Follow the steps below to upgrade the firmware:

1. Download the latest firmware file to your hard drive from the D-Link website.
2. Log-in camera web UI and go to **Maintenance/Firmware** web page upgrade
3. Locate the file (upgraded firmware) on your hard drive by clicking **Choose File**.
4. Click **Upload** to upgrade the firmware on your camera.

## New Features:

Firmware Version	New Features
V1.00.05	1.New model MP FW release

## Problems Fixed:

Firmware Version	Problems Fixed
	N/A

## Known Issues:

Firmware Version	Known Issues
	N/A

## Related Documentation:

N/A