



Quick Install Guide

DGL-4500



Remove Contents from the Box



DGL-4500 Gaming Router (3 detachable antennas included)



Power Adapter



CD-ROM (Includes manual and Router Setup Wizard)



Stand



Ethernet Cable

Hardware Installation

TCP/IP Settings

IP Address:

Subnet Mask:

Default Gateway:

Primary DNS:

Secondary DNS:

PPPoE Settings

Name:

Password:

Getting Started

The DGL-4500 includes a Quick Router Setup Wizard CD. **Insert the CD to run the Setup Wizard to guide you quickly through the installation process.** If you would like to manually connect and configure your router, follow the steps below.

- Please configure the router with the computer that was last connected directly to your modem.
- If you were using the USB connection before using the router, then you must turn off your modem, disconnect the USB cable and connect an Ethernet cable to the Internet port on the router, and then turn the modem back on. In some cases, you may need to call your ISP to change connection types (USB to Ethernet).
- If you have DSL and are connecting via PPPoE, make sure you disable or uninstall any PPPoE software such as WinPoet, Broadjump, or Enternet 300 from your computer or you will not be able to connect to the Internet.

1 Unplug the power from your broadband modem and shut down your computer.

2 Disconnect the Ethernet cable connected from your computer to your broadband modem. Leave the end connected to your broadband modem attached.

3 Connect the end of the Ethernet cable removed from your computer to the WAN port on the router.

4 Connect the provided Ethernet cable from a numbered port on the router to your computer.

5 Plug the power back into your broadband modem and wait for the broadband modem to synchronize to the network (refer to the Modem manual for information on this).

6 Plug the power adapter (provided with the router) into the router, then connect the other end to a power outlet and verify that the POWER LED on the router is on.

Note: If the Power LED is not lit, verify that the power adapter is properly connected to the D-Link® Gaming Router and to a working power outlet.

7 Power on your computer.

8 Launch your web browser and type in a web address such as <http://games.dlink.com> to verify that you have an Internet connection.

9 If a web address is not accessible, enter <http://192.168.0.1> in your web browser address bar. Once the main screen appears, press the button labeled **Internet Connection Setup Wizard** and proceed through the wizard.

For additional details on the Internet Connection Setup Wizard, please refer to the User Manual on the CD-ROM

10 Connect the antennas to the router. The large open end of the antenna screws onto the threaded post on the router.



Support
D-Link's website contains the latest user documentation and software updates for D-Link® products. Please refer to the user manual on the CD-ROM and the Help section in the Gaming Router's web-based management interface for support. U.S. and Canadian customers can contact D-Link® Technical Support through our website or by phone.

United States
Telephone • 877-453-5465
World Wide Web • <http://support.dlink.com>

Canada
Telephone • 800-361-5265
World Wide Web • <http://support.dlink.com>

WORLD IN CONFLICT™



TEEN
T Blood
Language
Violence
ESRB CONTENT RATING www.esrb.org

MASSIVE
ENTERTAINMENT

SIERRA

D-Link

GAMERLOUNGE
NETWORKING EVOLVED



lag is no longer an excuse

GAMEFUEL
PRIORITY

powered by gamefuel™

Nothing ruins a frag-fest faster than lag. GameFuel™ allows you to customize your network settings to prioritize game traffic so your roommate doesn't hog all the bandwidth while downloading tracks from his favorite 80's hair band.

XTREME N
GAMING ROUTER