



Full HD Outdoor Wi-Fi Camera



Power Adapter



Mounting Kit



Quick Installation Card



Quick Installation Guide

1

Download the App



Search for **mydlink** and download the app.

Note: This product is incompatible with other mydlink apps such as 'mydlink Home,' 'mydlink Lite,' etc.

2



Log In



Sign In or **Sign Up** for a mydlink account. mydlink Lite users may sign in with the same account.

3


Add the Device




- ① Tap the menu button ≡
- ② Tap **Add a Device**
- ③ Scan the Setup Code on the power cable or on the Quick Install Card, then follow the app instructions




Mounting



Place the baseplate at the desired location, ensuring that it is at least 20cm from the ceiling. Make sure the screw is facing up and the holes are level. Use a pencil to mark the holes.




Using a 6mm drill bit, drill two 25mm deep holes over the pencil marks. For a plaster, drywall, or concrete wall, insert the plastic anchors to support the screws first.




Place the baseplate over the holes. Use the supplied screws to attach the baseplate to the wall.



Mounting



Align the large top screw with the largest hole on the snap mount. Slide the mount down to lock into place.




Attach the back of the camera to the mount. Adjust the angle as desired.



Device Information

Front



Status LED


LED behavior

-  Setup complete, camera is active
-  Live View active
-  Booting up
-  Pairing



Device Information

Bottom



Reset button

Note: The microSD card slot cover in the above diagram has been removed.



FAQ

What do I do if my device is not working properly?

Reset the device and reinstall it. To reset your device, use a paper clip to press and hold the recessed **Reset** button until the LED turns solid red.

During installation, ensure that:

- your router is connected to the Internet and has Wi-Fi enabled
- your mobile device is connected to your router Wi-Fi and has Bluetooth enabled
- your mydlink device is in range of your Wi-Fi network

Why is there a white haze when viewing in night vision mode?


When viewing in night vision mode, the IR lights on your camera may be reflecting off a nearby surface. Try repositioning your camera to avoid glare from IR LEDs.

Why is my microSD card not working/not supported?

The microSD card must be formatted into the correct file system (FAT32) before it can be used with this product. This can be done in the mydlink app by selecting the **Format** function in the storage menu under the Device settings.

Why is there a threaded sleeve on the power cable?

The threaded sleeve is used to attached to the optional cable extension (sold separately). The optional cable extension (DCS-8600LH/CBL) can be purchased on the shop.dlink.ca website.



Support


For troubleshooting tips and more information, visit:
support.dlink.com (USA) or support.dlink.ca (CAN)

For technical support, call:
1-877-453-5465 (USA) or **1-800-361-5265** (CAN)



DCS-8600LH/LT
Full HD Outdoor Wi-Fi Camera

Quick Installation Guide



©2019 All rights reserved. D-Link and the D-Link logo are registered trademarks of D-Link Corporation or its subsidiaries. Product specification, size and shape are subject to change without notice, and actual product appearance may differ from that depicted on the package. Visit dlink.com for more details.

Version 1.01 (NA_EN)_90X130
2019/12/03
610000009989