



Quick Installation Guide




What's in the Box



Outdoor Wi-Fi Smart Plug
(DSP-W320)




Mounting Kit



Quick Installation Guide

LED Behavior



Outlet Power Status LED

- Switched on
- Switched off

System Status LED

- Connected to network and mydlink
- Booting up
- Ready for setup
- Firmware being updated

Simple Setup

[1]

Get the **mydlink** app on the App Store or on Google Play. Launch the app, then **Sign In** or **Create a New Account**.

[2]

Power on the device and wait for the Status LED to flash orange.



Note: Make sure that your mobile device's Bluetooth is on.

[3]

Place your device next to your mobile device. A prompt will appear - tap **Add Device**, then follow the app instructions.



Please set up your device before mounting it.




Mounting




Precautions:


- Electric shock can cause serious injury or death. Install only in a dry environment.
- Do not place near any source of water or potential flooding zones.
- Plug into a grounded electrical outlet. Do not plug into an extension cord or power strip.
- If plugged into an outlet controlled by a wall switch, ensure that the switch is left in the on position and is never turned off.
- Ensure that the plugs in the housing are facing downwards.
- Do not exceed the electrical ratings.
- Keep away from children and pets.
- Do not open the unit to modify or repair it.
- Unplug the device from the wall outlet before cleaning it.




Place at the desired location at least 60 cm from the ground.
Use a pencil to mark the hole behind the mounting tab.



Use a 6 mm drill bit to drill a 26 mm deep hole over the pencil mark.



Hammer in the plastic wall anchor to support the screw.
Twist the screw into the anchor. Leave a quarter of the screw exposed from the wall.



Align the mounting tabs hole over the screw. Slide the mount down to lock the device in place, allowing it to hang.

FAQ

What do I do if my device is not working properly?

Reset and reinstall your device. Press and hold the **Reset** button until the LED turns solid red.



Reset Button

During installation, ensure that:

- Your router is connected to the Internet and Wi-Fi is enabled
- Your mobile device is connected to your router's Wi-Fi and Bluetooth is enabled
- Your mydlink device is in range of your Wi-Fi network

How can I use voice commands to control my device?

The device will work with both Amazon Alexa and the Google Assistant. For setup instructions on these services, visit the following websites:

Amazon Alexa

dlink.com/en/alexa

The Google Assistant:

dlink.com/en/google-assistant

Need Help?

Having trouble installing your new product? D-Link's website contains the latest user documentation and software updates for D-Link products. Customers can contact D-Link Technical Support through our website by choosing the relevant region.

Contact Us

www.dlink.com/en/contact-us

